


IBM

Maintenance Information



IBM 4331 Processor Supplement to MAPs

Preface

This manual contains supplementary information to the MAPs, and must not be used as a stand-alone maintenance document. The PT-CE should use this manual only under guidance of the MAPs or of FSC-personnel.

The manual contains the following major topics:

- Index
- Section 1: Locations
- Section 2: Removals and Replacements
- Section 3: Adjustments
- Section 4: Diagnostic Run Procedures
- Section 5: 53 FD Console Disk File Maintenance Information
- Section 6: Configure Section

Volume Table of Contents

Volume: 13
Title: MI Supplement to MAPS
Machine Type: 4331-2
Power Design Level: 4/5
B/M Number: 5683363

PAGE NUMBER	PART NO.
0 100	4687035
0 120	8488435
0 500	5683372
Divider TAB	8483800
1 000	5683393
1 020	5683394
1 047	5683390
1 085	5683240
1 110	5683391
1 134	5683392
1 185	8488377
Divider TAB	8483801
2 000	8488437
Divider TAB	8483802
3 000	8488438
Divider TAB	8483803
4 000	5683395
4 012	5683396
4 030	8488378
4 050	5683397
4 130	8488380
4 200	5683365

PAGE NUMBER	PART NO.
4 250	5683282
4 320	5683499
4 330	5683288
4 350	5683399
4 380	5683379
4 400	5683284
4 500	8488384
4 512	8488661
4 530	5683287
4 540	8488655
4 545	8488385
4 650	8488386
Divider TAB	8483804
5 000	8488440
5 013	5683234
5 025	5683235
5 100	8488454
Divider TAB	5683256
6 000	5683242
6 018	5683243
6 100	5683244
6 130	5683289
6 165	1570473
6 170	5683246
6 200	5683247
9 980	5683248
9 990	8488441

Safety

Personal Safety

Personal safety cannot be over-emphasized. To ensure your safety and that of co-workers, always observe the safety precautions given during your safety training and adhere to the following:

General Safety Practices

Observe the general safety practices and the procedure for performing artificial respiration that are outlined in CE Safety Practices card, Order No. S229-1264 (shown here).

Machine Warning Labels

Pay attention to the warning labels placed in hazardous areas of the machines.

Danger

Before switching on power, ensure that no person is exposed to risk and that all equipment covers for hazardous areas are closed.

SAFETY NOTICES

CE SAFETY PRACTICES

All Customer Engineers are expected to take every safety precaution possible and observe the following safety practices while maintaining IBM equipment.

- 1. You should not work alone under hazardous conditions or around equipment with dangerous voltage. Always advise your manager if you MUST work alone.
- 2. Remove all power AC and DC when removing or assembling major components, working in immediate area of power supplies, performing mechanical inspection of power supplies and installing changes in machine circuitry.
- 3. Wall box power switch when turned off should be locked or tagged in off position. "Do not Operate" tags, form 229-1266, affixed when applicable. Pull power supply cord whenever possible.
- 4. When it is absolutely necessary to work on equipment having exposed operating mechanical parts or exposed live electrical circuitry anywhere in the machine, the following precautions must be followed.
 - a. Another person familiar with power off controls must be in immediate vicinity.
 - b. Rings, wrist watches, chains, bracelets, metal cuff links, shall not be worn.
 - c. Only insulated pliers and screwdrivers shall be used.
 - d. Keep one hand in pocket.
 - e. When using test instruments be certain controls are set correctly and proper capacity, insulated probes are used.
 - f. Avoid contacting ground potential (metal floor strips, machine frames, etc.—use suitable rubber mats purchased locally if necessary).
- 5. Safety Glasses must be worn when:
 - a. Using a hammer to drive pins, riveting, staking, etc.
 - b. Power hand drilling, reaming, grinding, etc.
 - c. Using spring hooks, attaching springs.
 - d. Soldering, wire cutting, removing steel bands.
 - e. Parts cleaning, using solvents, sprays, cleaners, chemicals, etc.
 - f. All other conditions that may be hazardous to your eyes.REMEMBER, THEY ARE YOUR EYES.
- 6. Special safety instructions such as handling Cathode Ray Tubes and extreme high voltages, must be followed as outlined in CEM's and Safety Section of the Maintenance Manuals.
- 7. Do not use solvents, chemicals, greases or oils that have not been approved by IBM.
- 8. Avoid using tools or test equipment that have not been approved by IBM.
- 9. Replace worn or broken tools and test equipment.
- 10. The maximum load to be lifted is that which in the opinion of you and management does not jeopardize your own health or well-being or that of other employees.
- 11. All safety devices such as guards, shields, signs, ground wires, etc., shall be restored after maintenance.
- 12. Each Customer Engineer is responsible to be certain that no action on his part renders product unsafe or exposes hazards to customer personnel.
- 13. Place removed machine covers in a safe out-of-the-way place where no one can trip over them.
- 14. All machine covers must be in place before machine is returned to customer.
- 15. Always place CE tool 't away from walk areas where no one can trip over it (i.e., under desk or table).
- 16. Avoid touching mechanical moving parts (i.e., when lubricating, checking for play, etc.).
- 17. When using stroboscope — do not touch ANYTHING — it may be moving.

- 18. Avoid wearing loose clothing that may be caught in machinery. Shirt sleeves must be left buttoned or rolled above the elbow.
- 19. Ties must be tucked in shirt or have a tie clasp (preferably non-conductive) approximately 3 inches from end. Tie chains are not recommended.
- 20. Before starting equipment, make certain fellow CE's and customer personnel are not in a hazardous position.
- 21. Maintain good housekeeping in area of machines while performing and after completing maintenance.

ARTIFICIAL RESPIRATION

General Considerations

- 1. Start Immediately, Seconds Count
Do not move victim unless absolutely necessary to remove from danger. Do not wait or look for help or stop to loosen clothing, warm the victim or apply stimulants.
- 2. Check Mouth for Obstructions
Remove foreign objects — Pull tongue forward.
- 3. Loosen Clothing — Keep Warm
Take care of these items after victim is breathing by himself or when help is available.
- 4. Remain in Position
After victim revives, be ready to resume respiration if necessary.
- 5. Call a Doctor
Have someone summon medical aid.
- 6. Don't Give Up
Continue without interruption until victim is breathing without help or is certainly dead.

Rescue Breathing for Adults
Victim on His Back Immediately

- 1. Clear throat of water, food, or foreign matter.
- 2. Tilt head back to open air passage.
- 3. Lift jaw up to keep tongue out of air passage.
- 4. Pinch nostrils to prevent air leakage when you blow.
- 5. Blow until you see chest rise.
- 6. Remove your lips and allow lungs to empty.
- 7. Listen for snoring and gurgling, signs of throat obstruction.
- 8. Repeat mouth to mouth breathings 10-20 times a minute.
Continue rescue breathing until he breathes for himself.



Thumb and finger positions



Final mouth to mouth position

Reprint Courtesy Mine Safety Appliances Co.

Copyright Note

Copyright International Business Machines Corporation (date).

The drawings and specifications contained herein shall not be reproduced in whole or in part without written permission.

IBM has prepared this maintenance manual for the use of IBM customer engineers in order to maintain the specific machines indicated. IBM makes no representations that it is suitable for any other purpose.

Information contained in this manual is subject to change. Any such change will be reported in subsequent revisions.

Requests for copies of IBM publications should be made to your IBM representative or to the IBM branch office servicing your locality.

A form for reader's comments are provided at the back of this publication. If the comment form has been removed, comments may be addressed to (IBM Germany, Publications, Department 3179, 7030 Boeblingen, Schoenaicher Str. 220). Comments become the property of IBM. IBM may use or distribute any information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

Index

A

AC Drive Parts (53FD) 5018
Adapter Test, CA, see Volume 14
Adapter Test, FTA 4350
Adapter Test, RSF 4512
Alter Channel Number 6112
Automatic IRECA Update via Data Bank 4517
Automatic MCTF Update via Data Bank 4517

B

BBA 0/1 Test 4375
BBA 0/1 Log Display 4100
BMPX Adapter Test 4360
BMPX Configuration 6145
BMPX Log Display 4110
BMPX 1 Cable Routing 1100
BMPX 2 Cable Routing 1100
Board (B1) Replacement 2010
Board (22-Position) Replacement 2020
Board Layout 22-Position 1045
BSM Size 6190
Bus Layout I/O Subsystem 1210
Bus Layout Support Subsystem 1190
B1-Board Replacement 2010

C

Cable Check and Replacement Procedure 2010
Cable Layout of IC Bus 0 - Detail A 1114
Cable Layout of IC Bus 0 and 1 1112
Cable Locations for Gate 01A 1070
Cable Locations for Gate 01D 1080
Cabling Layout for Gate 01A 1060
Card EIA/CCITT V24 4504
Card Locations 1050
Central Complex Test Selection 4320
CE Panel 1010
CE Panel Indicator Test 4385
Chaining Selection 4325
Channel Assignments 6018
Channel Number Alteration 6112
Configuration of BMPX 6145
Configuration of Channel Number 6112
Configuration of CA 6160
Configuration of FTA 1 or 3 6130
Configuration of FTA 2 6135

Configuration of HSC 6143
Configuration of I/O Diskette 6126
Configuration of Loop 6165
Configuration of MES Update 6190
Configuration of Native Displays 6124
Configuration of Native Printers 6124
Configuration of Time of Day 6110
Configure Chart 6018
Configure Screens 6008
Control Diskette Configuration 6100
Control Interface Wrap Test 4355
Control Options - Explanation 4430
Control Store Test (Handling) 4331, 4332
Control Store Test Type 0 4331
Control Store Test Type 1 4334
Convergence Test 4590
Copy Configuration 6170
Copy Configure Charts 6172
Copying of Diskette 5140
Cover Assembly (53FD) 5010

D

DCA Control Block Display 4585
DCA Driver Cable Routing 1090
Description of CS Test Type 0 4331
Detailed Log Display 4050
Devices for Subchannels 6144, 6146
Device Restrictions on the 4331 6200
Devices Supported by the ST4300 Diskette 4253
Diagnostic MS Test 4338
Disable Channel Logs 4030
Disk/Tape Inline Test, Flowchart 4440
Disk/Tape Inline Test, Handling 4410
Disk/Tape Inline Tests, General 4400
Diskette Description 5001
Diskette Directory Display 4541
Diskette Drive Control Card (53FD) 5030
Diskette Drive Parts (53FD) 5005
Diskette Drive Tests 5100, 5200
Diskette Formatting 5140
Diskette Handling 5010
Diskette Identification Program 4540
Diskette Safety 5003
Diskette Surface Analysis Test 5130
Diskette Copying 5140

E

EIA Interface Cable Wrap Test 4515
Erase All Logs 4034
Erase Selective Log 4032
Error Messages; See under Configuration of...
ESD Sensitive Parts 2030
Exceptions for Inline Tests 4400
External Modem Interface 4504

F

Format Zero Messages and Sense Bytes 4145
Formatting of Diskettes 5140
FRIEND PRINT LOG Function 4516
FRU Update (IRECA) 4205
FTA (X) Test 4350
FTA Configure Error Messages 6138
FTA Log Display 4140
FTA 1 Cable Routing 1085
FTA 2 Cable Routing 1085
FTA 3 Cable Routing 1090

G

Gate 01D 1080

H

Handling ESD Sensitive Parts 2030
Head Load Solenoid and Bail (53FD) 5015
Head/Carriage Assembly (53FD) 5012
How to Install a MCTF or IRECA Update
How to Load the ST4300 4250
How to Load OLTSEP 4254
How to Select a M/S Program 4010
HSC Adapter Test 4380
HSC Cable Routing 1095
HSC Log Display 4110

Index (continued)

I

IC Bus Adapter Addressing 1110
 IC Bus Configuration 1112
 IC Bus General Information 1110
 IC Bus Log Display 4130
 IC Bus Test 4329
 IC Bus 0 1110, 1116
 IC Bus 0 Ring Lines 1118
 IC Bus 0 Star Lines 1126
 IC Bus 0 Stub Lines 1132
 IC Bus 1 1110, 1134
 IC Bus 1 Ring Lines 1136
 IC Bus 1 Star Lines 1140
 IC Bus 1 Stub Lines 1142
 IM Test, Handling 4339
 IML Log Display 4170
 Indicator Lamp Test 4385, 4650
 Info Box (IRECA) 4202
 Inline Status Display - Examples 4420
 Inline Test Control Option 4413
 Inline Test Exceptions 4400, 4401, 4402
 Inline Test Handling (Flowchart) 4440
 Inline Test Handling 4410
 Inline Test Run Option 4413
 Integrated Modem Interface 4506
 Integrated Refcode Analysis 4200
 Interface Cable Routing 1085
 Introduction to (53FD) 5001
 Introduction to OLTSEP 4254
 IOC Log Display 4120
 I/O Device Address Chart 6016
 I/O Diskette Configuration 6100
 I/O Diskette Drive Tests (53FD) 5100
 I/O Subsystem Bus 1210
 IRECA 4200
 IRECA Update via Remote Link 4517

L

Lamp Test for SP Display Indicators 4385, 4650
 Last Detailed Log Display 4180
 Last PU Stop Log Display 4080
 Layout of the 22-Position Board 1045
 Layout of IC Bus 0 - Detail A 1114
 Layout of IC Bus 0 and 1 1112
 LED and PTX Assemblies (53FD) 5026
 Legend (53FD) 5050
 Line Plate Adjustment Procedure 4507

© Copyright International Business Machines Corporation 1981

Log Distribution Statistics 4040
 Log Mode Selection 4030
 Log Programs 4012
 Loop Configuration 6165

M

Machine Characteristics (53FD) 5001
 Main Storage Test 4338
 Maintenance (53FD) 5001
 Manual MCTF Installation 4530
 MCTF Manual Installation 4530
 MCTF Update via MCTF Diskette 4533
 MCTF Update via Remote Link 4517
 Messages that Appear on Screen 4700
 Message Update (IRECA) 4207
 MES Update Without a New Diskette 6190
 MLX Cross References 4465
 Modem Resetting 4514
 MPX Adapter Test 4360
 MPX Cable Routing 1095
 MPX Log Display 4110
 M/S Program Selection - Overview 4010
 M/S Programs - Handling Overview 4012
 MS Test 4338

N

Native Displays and Printers Configuration 6124

O

OLTSEP 4254
 Operator's Console 1010
 Overall Picture of Configuration 6004

P

Personal Safety 0120, 5003
 Physical Locations 1020
 Pin Numbering 22-Position Board 1040
 Population of Main Storage 6190
 Processor Bus for I/O Subsystem 1210
 Processor Bus for Support Subsystem 1190
 PU Program Log Display 4090
 PU-BSM Test 4330

R

Reference Code Analysis 4200
 Reference Code Intermediate Storing 4516
 Reference Code Log 4040
 Reference Code Update (IRECA) 4203
 Remote Support Facility 4501
 Resetting the Modem to Talk Mode 4514
 Restart Line 1225
 Ring Lines 1118
 ROCF, see Form No. GA33-1545
 RSF Adapter Interface Cards 4503
 RSF Diagnostics 4512
 RSF Line Error Statistics 4509
 RSF Line Plate 4507
 Run Options - Explanation 4525

S

Safety (4331) 0120
 Safety (53FD) 5003
 SBA/Support Bus Test 4370
 SCL IOSS/MSSS Test 4385
 Screen Messages 4700
 Sense Bytes Format Zero 4145
 Set Time of Day Correction 6110
 Signal Flow and Wrap Test 4505
 Signal Names of IC Bus 0 Cables 1116
 Signal Names of IC Bus 1 Cables 1134
 Special Control Store Test (Handling) 4332
 Special Tools (53FD) 5001
 SP Display Indicators 4650
 SP Machine Check Log Display 4070

T

Table of Contents - Section 1 1000
Table of Contents - Section 2 2000
Table of Contents - Section 4 4000
Table of Contents - Section 5 5000
Table of Contents - Section 6 6000
Test Chaining Selection 4325
Test CE Panel Indicator 4385, 4650
Test Programs 4014
Test for Convergence Function 4590
Test for DCA and Attached Devices 4545
Tests for I/O Diskette Drive 5100
Tests for System Diskette Drive 5200
Tests for 53FD 5100, 5200
Theory (53FD) 5006
Time of Day Correction 6110
Tool Programs 4020
Top Connector Numbering 22-Position Board 1040

U

Update of IRECA Tables 4203
Use of the Acoustic Coupler 4514
Use of Cards 1047
Utilities Program Selection 4500

W

Wrap Connectors for Control Interface Test 4355
Wrap Connectors for Standard Interface Test 4365

2

22-Position Board Layout 1045
22-Position Board Replacement 2020

3

3310 Configuration, see Configuration of FTA 1 and 3
3340/44 Configuration, see Configuration of FTA 1 and 3
3370 Configuration, see Configuration of FTA 1 and 3

5

53FD AC Drive Parts 5005
53FD Assembly Removal 5018
53FD Assembly Replacement 5018
53FD Belt Removal 5018
53FD Belt Replacement 5018
53FD Belt Tracking Adjustment 5018
53FD Belt Tracking Service Check 5018
53FD CDF Setup and Removal 5033
53FD Collet Removal 5011
53FD Collet Replacement 5011
53FD Control Card Head Cable Pins 5030
53FD Control Card Interface Description 5031
53FD Control Card Removal 5030
53FD Control Card Replacement 5030
53FD Control Card Socket and Connector Pins 5030
53FD Control Card Test Pins 5030
53FD Cover Assembly 5005
53FD Cover Removal 5010
53FD Cover Replacement 5010
53FD Diskette Drive Control Card 5005
53FD Diskette Insertion 5010
53FD Diskette Removal 5010
53FD Diskette Speed Service Check 5026
53FD Drive Band Adjustment 5024
53FD Drive Band Removal 5025
53FD Drive Band Replacement 5025
53FD Drive Band Service Check 5024
53FD Drive Control Logic 5006
53FD Drive Motor Removal 5018
53FD Electrical Characteristics 5002
53FD FM Scoping Charts 5008
53FD Functional Characteristics 5002
53FD Glossary 5050
53FD Head Load Parts 5005
53FD Head/Carriage Service Check 5012
53FD Head/Carriage Adjustment 5013
53FD Head/Carriage Removal 5014
53FD Head/Carriage Replacement 5014
53FD Idler Assembly Removal 5025
53FD Idler Assembly Replacement 5025
53FD Index Detection Parts 5005
53FD Latch Assembly Removal 5010
53FD Latch Assembly Replacement 5010
53FD LED and PTX Alignment 5026
53FD LED Output Service Check 5027
53FD LED Removal 5027
53FD LED Replacement 5027

53FD Legend 5050
53FD MFM Scoping Charts 5009
53FD Motor Replacement 5018
53FD Parts Location 5005
53FD Physical Characteristics 5002
53FD PTX Amplifier Service Check 5028
53FD PTX Removal 5029
53FD PTX Replacement 5029
53FD Pulley and Clamp Removal 5022
53FD Pulley and Clamp Replacement 5023
53FD Pulley Removal 5018
53FD Pulley Replacement 5018
53FD Read/Write Parts 5005
53FD Read/Write Principles 5007
53FD Sense Byte 2 Explanation 5150
53FD Signal Routing 5032
53FD Solenoid and Bail Adjustment 5016
53FD Solenoid and Bail Removal 5017
53FD Solenoid and Bail Replacement 5017
53FD Solenoid and Bail Service Check 5015
53FD Stepper Drive Parts 5005
53FD Stepper Motor Removal 5020
53FD Stepper Motor Replacement 5021
53FD Test Handling 5100, 5200
53FD Typical Operation 5006
53FD Typical Timing Sequence 5006

8

8809 Configuration, see Configuration of FTA 2

This page has been
intentionally left blank


Supplement to MAPs, Section 1: LOCATIONS

Table of Contents

Title	Page
Cover Page	0100
Preface	0110
Safety	0120
Copyright	0130
Index	0500
Index (continued)	0510
Index (continued)	0520
Blank Page	0530
Table of Contents - Section 1	1000
Operator's Console and CE Panel	1010
Physical Locations	1020
Physical Locations (continued)	1030
Pins and Top Connectors Numbering	
of 22-Position Board	1040
Card Top Connector	1040
Layout of the 22-Position Board	1045
Use of Cards	1047
Card Locations	1050
Card Locations (continued)	1055
Cabling Layout for Gate 01A	1060
Cabling Layout for Gate 01A (continued)	1065
Layout for Board B2 (Version 1, 2, 3)	1065
Cable Locations for Gate 01A	1070
Cable Locations for Gate 01A (continued)	1075
Cable Locations for Gate 01D	1080
Interface Cable Routing:	
Card Pin to Tailgate	1085
FTA 1 Cable Routing	1085
FTA 2 Cable Routing	1085
FTA 3 Cable Routing	1085
External Signal Cable Routing	1090
DCA Driver Cable Routing	1090
HSC Cable Routing	1095
MPX Cable Routing	1095
BMPX 1 Cable Routing	1100
BMPX 2 Cable Routing	1100
IC Bus 0 and 1	1110
General Information	1110
IC Bus Adapter Addressing	1110
IC Bus Configuration	1112
Cable Layout of IC Bus 0 and 1	1112
Cable Layout of IC Bus 0 - Detail A	1114
IC Bus 0	1116
Signal Names of IC Bus 0 Cables	1116

Title	Page
IC Bus 0 Ring Lines	1118
IC Bus 0 Ring Lines (continued)	1120
IC Bus 0 Ring Lines (continued)	1122
IC Bus 0 Ring Lines (continued)	1124
IC Bus 0 Star Lines	1126
IC Bus 0 Star Lines (continued)	1128
IC Bus 0 Star Lines (continued)	1130
IC Bus 0 Stub Lines	1132
IC Bus 1	1134
Signal Names of IC Bus 1 Cables	1134
IC Bus 1 Ring Lines	1136
IC Bus 1 Ring Lines (continued)	1138
IC Bus 1 Star Lines	1140
IC Bus 1 Stub Lines	1142
Blank Page	1144
Blank Page	1185
Processor Bus for Support Subsystem	1190
Bus Layout	1190
Pin Location Charts	1200
Processor Bus for I/O Subsystem	1210
Bus Layout	1210
Pin Location Charts	1220
Support Processor Restart Line	1225

Operators Console and CE-Panel




Function is only active when ALT key is pressed at the same time

* COPY key.



When a console printer is connected save a printout whenever you have an important log/test/tool information on screen, this might be useful in case of support!

Log Printout: The 4300 Friend has the command 'Print Log' to print the Log/Screen picture on the Line Printer.
(See: 4300 Friend page 0175)




Physical Locations

This page shows the maximum configuration for the processor 4331, Model 2.
The maximum configuration for the processor 4331-11 does not include all units shown.




Note: Pictures show maximum configuration.
Not all units shown may be installed.

Physical Locations (continued)




Pins and Top Connectors Numbering of 22 Position Board *




* From Pin Side

Card Top Connector



Layout of the 22 Position Board *



General Pin Assignments:
D08 – Ground
D03 – +5V

* From Pin Side

Use of Cards

On the following pages all cards belonging to a unit are sequentially numbered, for example the cards of the processing unit are named PU card 1 through 7. The following list gives where possible the meaning (use) of the card.

Board	Code Card	Card Number	Use of Card
A1	SF5	IOC card 5	Control store ext. }
	SF5	IOC card 6	Control store ext. }
B1	QA5/QS2	PU card 1	Control store }
	QA5	PU card 2	Control store }
	QC5	PU card 3	Control card }
	QC3	PU card 4	ALU card }
	QC2	PU card 5	Storage interface }
	QC7	PU card 6	Cache store }
	QC9	PU card 7	Data mover }
	QD1	BSM card 1	Storage control }
		BSM card 2	Main store }
		BSM card 3	Main store }
		BSM card 4	Main store }
		BSM card 5	Main store }
		BSM card 6	Main store }
		BSM card 7	Main store }
		BSM card 8	Main store }
		BSM card 9	Main store }
B2	QG3	MPX card 1	SCA interface card
	QG2	MPX card 2	SCA card
	QG3	BMPX (X) card 1	SCA interface card
	QG2	BMPX (X) card 2	SCA card
	QF3	FTA (X) card 1	CTL1 card
	QF2	FTA (X) card 2	Control card
	QF1	FTA (X) card 3	Data card
	QG3	HSC card 1	HSC interface card
	QG5	HSC card 2	HSC adapter card
	QG4	HSC card 3	HSC-IC bus link
C2	SF5	SP card 5	Control store ext.)
	SF5/SF9	SP card 6	Control store ext.)

For card code and P/N refer to PA13 or plug chart in Volume 30.

Notes:

- 1. In case of IOSS Processor (A1 Board):
If the SF5 cards are plugged a QH8 card must be plugged in F2.

In case of MSSS Processor (C2 Board):
If the SF5 cards are plugged a QH7 card must be plugged in G2.
If a SF9 card is plugged it requires a QJ7 in G2.
- 2. 0,5 MB cards QD7 may be replaced by 0,5 MB card QD6, or groups of 0.5 MB cards may be replaced by 1.0 MB cards. Refer to the card plug list in Vol. 30 and table on page 6190 of this manual.
- 3. The PU control store may consist of two 64 KB cards (QA5) or one 128 KB card (QS2).

Card Locations (continued) Board B2

(See Caution Note)

Version 1

YA		YB		YC		YD		YE		YF		YG		YH	
YJ		YK		YL**		YM**		YN		YP		YQ		YR	
A 2	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	R
Spare A4		A3		OG3 BMPX 1 Card 1		OG2 BMPX 1 Card 2		OG1 ACC Card 2		OF3 FTA 1 Card 1		OF2 FTA 1 Card 2		OF1 FTA 1 Card 3	
Spare A4		A3		Spare		Spare		Spare		OG3 BMPX 2 Card 1		OG2 BMPX 2 Card 2		OG1 ACC Card 4 *	
Spare A4		A3		Spare		Spare		Spare		OF3 FTA 3 Card 1 *		OF2 FTA 3 Card 2		OF1 FTA 3 Card 3	
Spare A4		A3		Spare		Spare		Spare		SD3 ACA 2 SD3 ACA 1		OH3 CA BA Card		OG2 MPX Card 2	
Spare A4		A3		Spare		Spare		Spare		OG1 ACC Card 1		OG3 MPX Card 1		OH5 ***	
ZA		ZB		ZC		ZD		ZE		ZF		ZG		ZH	

This Board B2 contains:
Two Block Multiplexer Channels File Tape Adapter 1, 3, Auto Call Adapter, Communication Adapter, Multiplexer Channel and Terminator.

* If feature is not installed
Card QE 20 is plugged in this position

** Terminator cards (QH 9) for IC - Bus 1

*** Terminator card (QH 5) for IC - Bus 0

Warning

The card plug positions B2, E2, L2, P2, and W2 supply a special voltage on a signal pin.
Any other card than the specified one, plugged into these positions can be destroyed.

Version 2

YA		YB		YC		YD		YE		YF		YG		YH	
YJ		YK		YL**		YM**		YN		YP		YQ		YR	
A 2	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	R
Spare A4		A3		OG3 BMPX 1 Card 1		OG2 BMPX 1 Card 2		OG1 ACC Card 2		OF3 FTA 1 Card 1 *		OF2 FTA 1 Card 2		OF1 FTA 1 Card 3	
Spare A4		A3		Spare		Spare		Spare		OF3 FTA 2 Card 1 *		OF2 FTA 2 Card 2		OF1 FTA 2 Card 3	
Spare A4		A3		Spare		Spare		Spare		SD3 ACA 2 SD3 ACA 1		OH3 CA BA Card		OG2 MPX Card 2	
Spare A4		A3		Spare		Spare		Spare		OG1 ACC Card 1		OG3 MPX Card 1		OH5 ***	
ZA		ZB		ZC		ZD		ZE		ZF		ZG		ZH	

The Board B2 contains:
The Block Multiplexer Channel, File Tape Adapter 1, 2, 3, Auto Call Adapter, Communication Adapter, Multiplexer Channel, and Terminator.

Version 3

YA		YB		YC		YD		YE		YF		YG		YH	
YJ		YK		YL**		YM**		YN		YP		YQ		YR	
A 2	B	C	D	E	F	G	H	J	K	L	M	N	P	Q	R
Spare A4		A3		OG3 BMPX 1 Card 1		OG2 BMPX 1 Card 2		OG1 ACC Card 2		OF3 FTA 1 Card 1		OF2 FTA 1 Card 2		OF1 FTA 1 Card 3	
Spare A4		A3		Spare		Spare		Spare		OG3 BMPX 2 Card 1		OG2 BMPX 2 Card 2		OG1 ACC Card 4 *	
Spare A4		A3		Spare		Spare		Spare		OG3 HSC 1		OG5 HSC 2		OG4 HSC 3	
Spare A4		A3		Spare		Spare		Spare		SD3 ACA 2 SD3 ACA 1		OH3 CA BA Card		OG2 MPX Card 2	
Spare A4		A3		Spare		Spare		Spare		OG1 ACC Card 1		OG3 MPX Card 1		OH5 ***	
ZA		ZB		ZC		ZD		ZE		ZF		ZG		ZH	

This Board B2 contains:
Two Block Multiplexer Channels, High Speed Channel, Auto Call Adapter, Communication Adapter, Multiplexer Channel and Terminator.

Cabling Layout for Gate 01A

Notes:

1. For P/Ns of cards refer to 'card plug list' in vol. 30.


2. These two plugs, labeled W2 and X3, are not interchangeable. For more detail ref. To Power manual sec. (REF)

End connector These connectors are interchangeable and can be installed any way.

Support Bus
IC Bus
Processor Bus


Voltagess
Sense Line
Interface

Top connector Cable
Board connector (Paddle - Card Cable)
Top connector Card to Card
These connectors are interchangeable




Cabling Layout for Gate 01A (continued)

Layout for Board B2-Version 1




Layout for Board B2-Version 2



© Copyright International Business Machines Corporation 1979, 1980, 1981

STM

Layout for Board B2-Version 3



Note: 3-position crossover (T-U-V) if CA or CA with MPX installed.
2-position crossover (U-V) if MPX without CA installed.

Cable Locations for Gate 01A

Sequence number	Use of Cable	Location	
		From Board	To
1	Support Bus to I/O	A2 - YE	Board A1 - ZE
2	Processor bus for I/O SS	A1 - ZH	Board A2 - YH
3	Processor bus for I/O SS	A1 - ZG	Board A2 - YG
4	IC Bus 1	A2 - YQ	Board B1 - B4D
5	IC Bus 1	A2 - YR	Board B1 - B4E
6	IC Bus 1	B2 - A3	Board A2 - X3
7	IC Bus 1	B2 - A2	Board A2 - X2
8	IC Bus 0	B1 - D4A	Board B2 - YH
9	IC Bus 0	B1 - D4 (B or C)	Board B2 - YG
10	IC Bus 0	B2 - YF	Board B1 - D4D
11	IC Bus 0	B2 - YE	Board B1 - D4 E
12	IC Bus 1	B1 - B4C	Board B2 - YD
13	IC Bus 1	B1 - B4B	Board B2 - YC
14	Support bus	B1 - A3 (C)	Board A2 - YF
15	Processor bus for MSSS	A2 - YM	Board C2 - YJ
16	Processor bus for MSSS	A2 - YD	Board C2 - YK
17	Displays	A2 - ZD	Coaxial Connectors (0 - 7)
18	Displays	A2 - YC	Coaxial Connectors (8 - 15)
19	System diskette	A2 - ZF	System Diskette Drive
20	User diskette	A2 - ZE	User Diskette Drive
21	CE Panel	C2 - YA	CE Panel D1 - A1
22	ICA-PIO tag	B2 - X4	Board C2 - ZC
	ICA-PIO bus	B2 - X5	Board C2 - ZD
23	Connection of MPX	B2 - W2-W	Gate 01D - D3 (BD)
	Connection of MPX	B2 - W3-X	Gate 01D - D3 (GJ)
	Connection of MPX	B2 - W4-Y	Gate 01D - E3 (BD)
	Connection of MPX	B2 - W5-Z	Gate 01D - E3 (GJ)
24	ACA Interface 1	B2 - YN	Gate 01E - A6 (BD)
	ACA Interface 2	B2 - YP	Gate 01E - A6 (GJ)

Sequence number	Use of Cable	Location	
		From Board	To
25 Version 2	Connection of FTA 2	B2 - ZA	Gate 01D - C2 (BD)
	Connection of FTA 2	B2 - ZB	Gate 01D - C2 (GJ)
	Connection of FTA 2	B2 - ZC	Gate 01D - D2 (BD)
	Connection of FTA 2	B2 - ZD	Gate 01D - D2 (GJ)
26	Connection of FTA 1	B2 - YA	Gate 01D - A2 (BD)
	Connection of FTA 1	B2 - YB	Gate 01D - A2 (GJ)
	Connection of FTA 1	B2 - YJ	Gate 01D - B2 (BD)
	Connection of FTA 1	B2 - YK	Gate 01D - B2 (GJ)
27	Connection of BMPX 1	B2 - B2-W	Gate 01D - F3 (BD)
	Connection of BMPX 1	B2 - B3-X	Gate 01D - F3 (GJ)
	Connection of BMPX 1	B2 - B4-Y	Gate 01D - G3 (BD)
	Connection of BMPX 1	B2 - B5-Z	Gate 01D - G3 (GJ)
28 Version 1, 2	Connection of FTA 3	B2 - ZE	Gate 01D - E2 (BD)
	Connection of FTA 3	B2 - ZF	Gate 01D - E2 (GJ)
	Connection of FTA 3	B2 - ZG	Gate 01D - F2 (BD)
	Connection of FTA 3	B2 - ZH	Gate 01D - F2 (GJ)
29 Version 2, 3	Connection of BMPX 2	B2 - L2-W	Gate 01D - C2 (BD)
	Connection of BMPX 2	B2 - L3-X	Gate 01D - C2 (GJ)
	Connection of BMPX 2	B2 - L4-Y	Gate 01D - D2 (BD)
	Connection of BMPX 2	B2 - L5-Z	Gate 01D - D2 (GJ)
30 Version 3	Connection of HSC	B2 - P2-W	Gate 01D - E2 (BD)
	Connection of HSC	B2 - P3-X	Gate 01D - E2 (GJ)
	Connection of HSC	B2 - P4-Y	Gate 01D - F2 (BD)
	Connection of HSC	B2 - P5-Z	Gate 01D - F2 (GJ)
31	CE Panel	A2 - YB	CE Panel D1 - A3
32	OC Panel	A2 - YK	OCP Connector
33	I/O SS voltages sense	A2 - A4	Board A1 - ZC
34	Power supply 105	PS 105	A2 - YJ
35	Power compartment PS 102	PS 102	A2 - YA
36	Voltage Sense	A2 - A2	Power System
	Voltage Sense	A2 - A3	Power System
	ESD Sense/Control	A2 - A5 Plugged at pin side	Line Filter


Cable Locations for Gate 01A (continued)

Sequence number	Use of Cable	Location	
		From Board	To
37	Standard Power Interface	A2 - ZA	SPI - P00 CON00
38	PC	A2 - ZB	Board C1 - B4
39	CA Interface (line 36)	C2 - YD	Gate 01E - A4 - GJ
	CA Interface (line 37)	C2 - YM	Gate 01E - A5 - BD
	CA Interface (line 34)	C2 - YE	Gate 01E - A3 - GJ
	CA Interface (line 35)	C2 - YN	Gate 01E - A4 - BD
	CA Interface (line 32)	C2 - YF	Gate 01E - A2 - GJ
	CA Interface (line 33)	C2 - YP	Gate 01E - A3 - BD
	CA Interface (line 30)	C2 - YG	Gate 01E - A1 - GJ
	CA Interface (line 31)	C2 - YQ	Gate 01E - A2 - BD
40	Connection of MFCU	A1 - X2 - W	Gate 01D - C1 (GJ)
	Connection of MFCU	A1 - X3 - X	Gate 01D - C1 (BD)
	Connection of MFCU	A1 - X4 - Y	Gate 01D - D1 (BD)
	Connection of MFCU	A1 - X5 - Z	Gate 01D - A1 (BD)
	Connection of MFCU	A1 - W2 - W	Gate 01D - E1 (GJ)
	Connection of MFCU	A1 - W3 - X	Gate 01D - E1 (BD)
	Connection of MFCU	A1 - W4 - Y	Gate 01D - F1 (BD)
	Connection of MFCU	A1 - W5 - Z	Gate 01D - F1 (GJ)
	Connection of MFCU	A1 - YP	Gate 01D - B1 (GJ)
	Connection of MFCU	A1 - YQ	Gate 01D - D1 (GJ)
	Connection of MFCU	A1 - YR	Gate 01D - B1 (BD)
41	Remote link terminal	A2 - ZH	Tailgate 01E - A1 - BD
42	External Signal Bus	B1 - A3B	Gate 01D - G1
43	Voltage sense PU/BSM (PDL 5 only)	B1 - B4A	Board A2 - ZC

Cable Locations for Gate 01D

Sequence number	Use of Cable	Location	
		From Board	To
40	Interface to MFCU	01D-A1, E1, F1	MFCU Board B
41	Interface to MFCU	01D-B1, C1, D1	MFCU Board B
42	External Signals	01D-G1	I/O
43	FTA 1 Interface (Bus)	01D-A2	1st Control Unit
44	FTA 1 Interface (Tag)	01D-B2	1st Control Unit
45	FTA 2 Interface (Bus)	01D-C2	1st Control Unit
46	FTA 2 Interface (Tag)	01D-D2	1st Control Unit
47	MPX Interface (Bus)	01D-D3	1st Control Unit
48	MPX Interface (Tag)	01D-E3	1st Control Unit
49	BMPX 1 Interface (Bus)	01D-F3	1st Control Unit
50	BMPX 1 Interface (Tag)	01D-G3	1st Control Unit
51	BMPX 2 Interface (Bus)	01D-C2	1st Control Unit
52	BMPX 2 Interface (Tag)	01D-D2	1st Control Unit
53	FTA 3 Interface (Bus)	01D-E2	1st Control Unit
54	FTA 3 Interface (Tag)	01D-F2	1st Control Unit
55	HSC Interface (Bus)	01D-E2	1st Control Unit
56	HSC Interface (Tag)	01D-F2	1st Control Unit

Gate 01D



Interface Cable Routing: Card Pin to Tailgate

FTA 1 Cable Routing

SIGNAL NAME	CARD PIN	BOARD PIN	BRD CON.	TAIL GATE	CABLE TYPE
CTL1 BUS OUT BIT P	01A-B2E2-M10	01A-B2A1-A06	YA	01D-A2-B03	BUS
CTL1 BUS OUT BIT 0	01A-B2E2-S11	01A-B2A1-B06	YA	01D-A2-D04	BUS
CTL1 BUS OUT BIT 1	01A-B2E2-P06	01A-B2A1-D08	YA	01D-A2-B05	BUS
CTL1 BUS OUT BIT 2	01A-B2E2-U11	01A-B2A1-E06	YA	01D-A2-D06	BUS
CTL1 BUS OUT BIT 3	01A-B2E2-P12	01A-B2B1-B08	YA	01D-A2-B08	BUS
CTL1 BUS OUT BIT 4	01A-B2E2-P11	01A-B2B1-C06	YA	01D-A2-D09	BUS
CTL1 BUS OUT BIT 5	01A-B2E2-M12	01A-B2B1-D08	YA	01D-A2-B10	BUS
CTL1 BUS OUT BIT 6	01A-B2E2-M11	01A-B2B1-E06	YA	01D-A2-D11	BUS
CTL1 BUS OUT BIT 7	01A-B2E2-P10	01A-B2C1-A08	YA	01D-A2-B12	BUS
CTL1 CE COMM OUT	01A-B2E2-P07	01A-B2A1-E08	YA	01D-A2-B06	BUS
CTL1 CE COMM IN	01A-B2E2-U12				
CTL1 SYNC OUT AD4	01A-B2E2-M13	01A-B2C1-B06	YA	01D-A2-D13	BUS
CTL1 BUS IN BIT P	01A-B2E2-S08	01A-B2C1-E06	YB	01D-A2-G03	BUS
CTL1 BUS IN BIT 0	01A-B2E2-U06	01A-B2D1-A06	YB	01D-A2-J04	BUS
CTL1 BUS IN BIT 1	01A-B2E2-S06	01A-B2D1-C08	YB	01D-A2-G05	BUS
CTL1 BUS IN BIT 2	01A-B2E2-U07	01A-B2D1-D06	YB	01D-A2-J06	BUS
CTL1 BUS IN BIT 3	01A-B2E2-S07	01A-B2E1-A08	YB	01D-A2-G08	BUS
CTL1 BUS IN BIT 4	01A-B2E2-P02	01A-B2E1-B06	YB	01D-A2-J09	BUS
CTL1 BUS IN BIT 5	01A-B2E2-M02	01A-B2E1-C08	YB	01D-A2-G10	BUS
CTL1 BUS IN BIT 6	01A-B2E2-M03	01A-B2E1-D06	YB	01D-A2-J11	BUS
CTL1 BUS IN BIT 7	01A-B2E2-M04	01A-B2E1-E08	YB	01D-A2-G12	BUS
CTL1 SYNC IN	01A-B2F2-B13	01A-B2F1-A06	YB	01D-A2-J13	BUS
CTL1 TAG BUS BIT P	01A-B2E2-M07	01A-B2B1-C11	YJ	01D-B2-D09	TAG
CTL1 TAG BUS BIT 0	01A-B2E2-M06	01A-B2A1-A11	YJ	01D-B2-B03	TAG
CTL1 TAG BUS BIT 4	01A-B2E2-U02	01A-B2A1-D13	YJ	01D-B2-B05	TAG
CTL1 TAG BUS BIT 5	01A-B2E2-S03	01A-B2A1-B11	YJ	01D-B2-D04	TAG
CTL1 TAG BUS BIT 6	01A-B2E2-S02	01A-B2B1-B13	YJ	01D-B2-B08	TAG
CTL1 TAG BUS BIT 7	01A-B2E2-M08	01A-B2A1-E11	YJ	01D-B2-D06	TAG
CTL1 TAG GATE	01A-B2E2-S13	01A-B2B1-D13	YJ	01D-B2-B10	TAG
CTL1 RESPONSE	01A-B2E2-S04	01A-B2C1-A13	YJ	01D-B2-B12	TAG
CTL1 SEL HOLD AD4	01A-B2E2-S05	01A-B2B1-E11	YJ	01D-B2-D11	TAG
CTL1 RECYCLE	01A-B2E2-M09	01A-B2C1-B11	YJ	01D-B2-D13	TAG
CTL1 SELECT ACTIVE	01A-B2E2-U09	01A-B2C1-E11	YK	01D-B2-G03	TAG
CTL1 NORMAL END	01A-B2E2-U10	01A-B2D1-C13	YK	01D-B2-G05	TAG
CTL1 SEL ALERT1	01A-B2E2-P05	01A-B2E1-A13	YK	01D-B2-G08	TAG
CTL1 UNSEL ALERT 1	01A-B2E2-M05	01A-B2E1-E13	YK	01D-B2-G12	TAG
CTL1 TAG VALID	01A-B2E2-S09	01A-B2D1-A11	YK	01D-B2-J04	TAG
CTL1 CHECK END	01A-B2E2-P04	01A-B2D1-D11	YK	01D-B2-J06	TAG
CTL1 SEL ALERT 2	01A-B2E2-S10	01A-B2E1-B11	YK	01D-B2-J09	TAG

FTA 2 Cable Routing

SIGNAL NAME	CARD PIN	BOARD PIN	BRD CON.	TAIL GATE	CABLE TYPE
CTL2 BUS OUT BIT P	01A-B2L2-M10	01A-B2A6-A02	ZA	01D-C2-B03	BUS
CTL2 BUS OUT BIT 0	01A-B2L2-S11	01A-B2A6-B02	ZA	01D-C2-D04	BUS
CTL2 BUS OUT BIT 1	01A-B2L2-P06	01A-B2A6-D04	ZA	01D-C2-B05	BUS
CTL2 BUS OUT BIT 2	01A-B2L2-U11	01A-B2A6-E02	ZA	01D-C2-D06	BUS
CTL2 BUS OUT BIT 3	01A-B2L2-P12	01A-B2B6-B04	ZA	01D-C2-B08	BUS
CTL2 BUS OUT BIT 4	01A-B2L2-P11	01A-B2B6-C02	ZA	01D-C2-D09	BUS
CTL2 BUS OUT BIT 5	01A-B2L2-M12	01A-B2B6-D04	ZA	01D-C2-B10	BUS
CTL2 BUS OUT BIT 6	01A-B2L2-M11	01A-B2B6-E02	ZA	01D-C2-D11	BUS
CTL2 BUS OUT BIT 7	01A-B2L2-P10	01A-B2C6-A04	ZA	01D-C2-B12	BUS
CTL2 CE COMM OUT	01A-B2L2-P07	01A-B2A6-E04	ZA	01D-C2-B06	BUS
CTL2 CE COMM IN	01A-B2L2-U12				
CTL2 SYNC OUT AD2	01A-B2L2-M13	01A-B2C6-B02	ZA	01D-C2-D13	BUS
CTL2 BUS IN BIT P	01A-B2L2-S08	01A-B2C6-E02	ZB	01D-C2-G03	BUS
CTL2 BUS IN BIT 0	01A-B2L2-U06	01A-B2D6-A02	ZB	01D-C2-J04	BUS
CTL2 BUS IN BIT 1	01A-B2L2-S06	01A-B2D6-C04	ZB	01D-C2-G05	BUS
CTL2 BUS IN BIT 2	01A-B2L2-U07	01A-B2D6-D02	ZB	01D-C2-J06	BUS
CTL2 BUS IN BIT 3	01A-B2L2-S07	01A-B2E6-A04	ZB	01D-C2-G08	BUS
CTL2 BUS IN BIT 4	01A-B2L2-P02	01A-B2E6-B02	ZB	01D-C2-J09	BUS
CTL2 BUS IN BIT 5	01A-B2L2-M02	01A-B2E6-C04	ZB	01D-C2-G10	BUS
CTL2 BUS IN BIT 6	01A-B2L2-M03	01A-B2E6-D02	ZB	01D-C2-J11	BUS
CTL2 BUS IN BIT 7	01A-B2L2-M04	01A-B2E6-E04	ZB	01D-C2-G12	BUS
CTL2 SYNC IN	01A-B2M2-B13	01A-B2F6-A02	ZB	01D-C2-J13	BUS
CTL2 TAG BUS BIT P	01A-B2L2-M07	01A-B2H6-A02	ZC	01D-D2-D09	TAG
CTL2 TAG BUS BIT 0	01A-B2L2-M06	01A-B2F6-D02	ZC	01D-D2-B03	TAG
CTL2 TAG BUS BIT 4	01A-B2L2-U02	01A-B2G6-B04	ZC	01D-D2-B05	TAG
CTL2 TAG BUS BIT 5	01A-B2L2-S03	01A-B2F6-E02	ZC	01D-D2-D04	TAG
CTL2 TAG BUS BIT 6	01A-B2L2-S02	01A-B2G6-E04	ZC	01D-D2-B08	TAG
CTL2 TAG BUS BIT 7	01A-B2L2-M08	01A-B2G6-C02	ZC	01D-D2-D06	TAG
CTL2 TAG GATE	01A-B2L2-S13	01A-B2H6-B04	ZC	01D-D2-B10	TAG
CTL2 RESPONSE	01A-B2L2-S04	01A-B2H6-D04	ZC	01D-D2-B12	TAG
CTL2 SEL HOLD AD2	01A-B2L2-S05	01A-B2H6-C02	ZC	01D-D2-D11	TAG
CTL2 RECYCLE	01A-B2L2-M09	01A-B2H6-E02	ZC	01D-D2-D13	TAG
CTL2 SELECT ACTIVE	01A-B2L2-U09	01A-B2J6-C02	ZD	01D-D2-G03	TAG
CTL2 NORMAL END	01A-B2L2-U10	01A-B2K6-A04	ZD	01D-D2-G05	TAG
CTL2 SEL ALERT 1	01A-B2L2-P05	01A-B2K6-D04	ZD	01D-D2-G08	TAG
CTL2 UNSEL ALERT 1	01A-B2L2-M05	01A-B2L6-C04	ZD	01D-D2-G12	TAG
CTL2 TAG VALID	01A-B2L2-S09	01A-B2J6-D02	ZD	01D-D2-J04	TAG
CTL2 CHECK END	01A-B2L2-P04	01A-B2K6-B02	ZD	01D-D2-J06	TAG
CTL2 SEL ALERT 2	01A-B2L2-S10	01A-B2K6-E02	ZD	01D-D2-J09	TAG

FTA 3 Cable Routing

SIGNAL NAME	CARD PIN	BOARD PIN	BRD CON.	TAIL GATE	CABLE TYPE
CTL3 BUS OUT BIT P	01A-B2P2-M10	01A-B2M6-B02	ZE	01D-E2-B03	BUS
CTL3 BUS OUT BIT 0	01A-B2P2-S11	01A-B2M6-C02	ZE	01D-E2-D04	BUS
CTL3 BUS OUT BIT 1	01A-B2P2-P06	01A-B2M6-E04	ZE	01D-E2-B05	BUS
CTL3 BUS OUT BIT 2	01A-B2P2-U11	01A-B2N6-A02	ZE	01D-E2-D06	BUS
CTL3 BUS OUT BIT 3	01A-B2P2-P12	01A-B2N6-C04	ZE	01D-E2-B08	BUS
CTL3 BUS OUT BIT 4	01A-B2P2-P11	01A-B2N6-D02	ZE	01D-E2-D09	BUS
CTL3 BUS OUT BIT 5	01A-B2P2-M12	01A-B2N6-E04	ZE	01D-E2-B10	BUS
CTL3 BUS OUT BIT 6	01A-B2P2-M11	01A-B2P6-A02	ZE	01D-E2-D11	BUS
CTL3 BUS OUT BIT 7	01A-B2P2-P10	01A-B2P6-B04	ZE	01D-E2-B12	BUS
CTL3 CE COMM OUT	01A-B2P2-P07	01A-B2N6-A04	ZE	01D-E2-B06	BUS
CTL3 CE COMM IN	01A-B2P2-U12				
CTL3 SYNC OUT AD1	01A-B2P2-M13	01A-B2P6-C02	ZE	01D-E2-D13	BUS
CTL3 BUS IN BIT P	01A-B2P2-S08	01A-B2Q6-A02	ZF	01D-E2-G03	BUS
CTL3 BUS IN BIT 0	01A-B2P2-U06	01A-B2Q6-B02	ZF	01D-E2-J04	BUS
CTL3 BUS IN BIT 1	01A-B2P2-S06	01A-B2Q6-D04	ZF	01D-E2-G05	BUS
CTL3 BUS IN BIT 2	01A-B2P2-U07	01A-B2Q6-E02	ZF	01D-E2-J06	BUS
CTL3 BUS IN BIT 3	01A-B2P2-S07	01A-B2R6-B04	ZF	01D-E2-G08	BUS
CTL3 BUS IN BIT 4	01A-B2P2-P02	01A-B2R6-C02	ZF	01D-E2-J09	BUS
CTL3 BUS IN BIT 5	01A-B2P2-M02	01A-B2R6-D04	ZF	01D-E2-G10	BUS
CTL3 BUS IN BIT 6	01A-B2P2-M03	01A-B2R6-E02	ZF	01D-E2-J11	BUS
CTL3 BUS IN BIT 7	01A-B2P2-M04	01A-B2S6-A04	ZF	01D-E2-G12	BUS
CTL3 SYNC IN	01A-B2Q2-B13	01A-B2S6-B02	ZF	01D-E2-J13	BUS
CTL3 TAG BUS BIT P	01A-B2P2-M07	01A-B2U6-B02	ZG	01D-F2-D09	TAG
CTL3 TAG BUS BIT 0	01A-B2P2-M06	01A-B2S6-E02	ZG	01D-F2-B03	TAG
CTL3 TAG BUS BIT 4	01A-B2P2-U02	01A-B2T6-C04	ZG	01D-F2-B05	TAG
CTL3 TAG BUS BIT 5	01A-B2P2-S03	01A-B2T6-A02	ZG	01D-F2-D04	TAG
CTL3 TAG BUS BIT 6	01A-B2P2-S02	01A-B2U6-A04	ZG	01D-F2-B08	TAG
CTL3 TAG BUS BIT 7	01A-B2P2-M08	01A-B2T6-D02	ZG	01D-F2-D06	TAG
CTL3 TAG GATE	01A-B2P2-S13	01A-B2U6-C04	ZG	01D-F2-B10	TAG
CTL3 RESPONSE	01A-B2P2-S04	01A-B2U6-E04	ZG	01D-F2-B12	TAG
CTL3 SEL HOLD AD1	01A-B2P2-S05	01A-B2U6-D02	ZG	01D-F2-D11	TAG
CTL3 RECYCLE	01A-B2P2-M09	01A-B2V6-A02	ZG	01D-F2-D13	TAG
CTL3 SELECT ACTIVE	01A-B2P2-U09	01A-B2V6-D02	ZH	01D-F2-G03	TAG
CTL3 NORMAL END	01A-B2P2-U10	01A-B2W6-B04	ZH	01D-F2-G05	TAG
CTL3 SEL ALERT 1	01A-B2P2-P05	01A-B2W6-E04	ZH	01D-F2-G08	TAG
CTL3 UNSEL ALERT 1	01A-B2P2-M05	01A-B2V6-E02	ZH	01D-F2-G12	TAG
CTL3 TAG VALID	01A-B2P2-S09	01A-B2V6-E02	ZH	01D-F2-J04	TAG
CTL3 CHECK END	01A-B2K2-P04	01A-B2V6-D02	ZH	01D-D2-J06	TAG
CTL3 SEL ALERT 2	01A-B2K2-S10	01A-B2X6-A02	ZH	01D-D2-J09	TAG

DCA Driver Cable Routing

CARD PIN	BOARD PIN	BOARD CONN.	DCA PORT
01A-A2J4-J09	01A-A2J6-D04	A2ZD	0
01A-A2J4-J13	01A-A2J6-E02	A2ZD	1
01A-A2J4-G03	01A-A2K6-A04	A2ZD	2
01A-A2J4-G13	01A-A2K6-B02	A2ZD	3
01A-A2J4-D09	01A-A2K6-E02	A2ZD	4
01A-A2J4-B10	01A-A2L6-A04	A2ZD	5
01A-A2J4-D13	01A-A2L6-B02	A2ZD	6
01A-A2J4-D05	01A-A2L6-C04	A2ZD	7
01A-A2J2-J09	01A-A2F1-E08	A2YC	8
01A-A2J2-J13	01A-A2G1-A06	A2YC	9
01A-A2J2-G03	01A-A2G1-B08	A2YC	10
01A-A2J2-G13	01A-A2G1-C06	A2YC	11
01A-A2J2-D09	01A-A2H1-A06	A2YC	12
01A-A2J2-B10	01A-A2H1-B08	A2YC	13
01A-A2J2-D13	01A-A2H1-C06	A2YC	14
01A-A2J2-D05	01A-A2H1-D08	A2YC	15

External Signal Bus Cable Routing

SIGNAL NAME	Board 01A-B1A3-	Gate OLD-G1)GJ)-
External Signal Bus Bit 0	B04	D04
Bit 1	B08	B05
Bit 2	B10	D06
Bit 3	B14	B08
Bit 4	B15	D09
Bit 5	B19	B10
Bit 6	B20	D11
Bit 7	B23	B12

HSC Cable Routing

SIGNAL NAME	CARD TOP CON- NECTOR PIN	TAILGATE PIN	CABLE TYP
BUS OUT BIT P	01A-B2P2-W03	01D-E2-B03	BUS
BUS OUT BIT 0	01A-B2P2-W24	01D-E2-D04	BUS
BUS OUT BIT 1	01A-B2P2-W05	01D-E2-B05	BUS
BUS OUT BIT 2	01A-B2P2-W26	01D-E2-D06	BUS
BUS OUT BIT 3	01A-B2P2-W08	01D-E2-B08	BUS
BUS OUT BIT 4	01A-B2P2-W29	01D-E2-D09	BUS
BUS OUT BIT 5	01A-B2P2-W10	01D-E2-B10	BUS
BUS OUT BIT 6	01A-B2P2-W31	01D-E2-D11	BUS
BUS OUT BIT 7	01A-B2P2-W12	01D-E2-B12	BUS
BUS IN BIT P	01A-B2P2-X03	01D-E2-G03	BUS
BUS IN BIT 0	01A-B2P2-X24	01D-E2-J04	BUS
BUS IN BIT 1	01A-B2P2-X05	01D-E2-G05	BUS
BUS IN BIT 2	01A-B2P2-X26	01D-E2-J06	BUS
BUS IN BIT 3	01A-B2P2-X08	01D-E2-G08	BUS
BUS IN BIT 4	01A-B2P2-X29	01D-E2-J09	BUS
BUS IN BIT 5	01A-B2P2-X10	01D-E2-G10	BUS
BUS IN BIT 6	01A-B2P2-X31	01D-E2-J11	BUS
BUS IN BIT 7	01A-B2P2-X12	01D-E2-G12	BUS
MARK OUT	01A-B2P2-W33	01D-E2-D13	BUS
MARK IN	01A-B2P2-X33	01D-E2-J13	BUS
ADDRESS OUT	01A-B2P2-Y10	01D-F2-B10	TAG
COMMAND OUT	01A-B2P2-Y31	01D-F2-D11	TAG
SERVICE OUT	01A-B2P2-Y33	01D-F2-D13	TAG
DATA OUT	01A-B2P2-Z10	01D-F2-G10	TAG
SUPRESS OUT	01A-B2P2-Y12	01D-F2-G12	TAG
OPERATIONAL OUT	01A-B2P2-Z33	01D-F2-J13	TAG
HOLD/SELECT OUT	01A-B2P2-Y29	01D-F2-D09	TAG
COND SUPPR OUT	01A-B2P2-Y12	01D-F2-B12	TAG
METERING OUT	01A-B2P2-Z24	01D-E2-J04	TAG
ADDRESS IN	01A-B2P2-Y05	01D-F2-B05	TAG
STATUS IN	01A-B2P2-Y24	01D-F2-D04	TAG
SERVICE IN	01A-B2P2-Y26	01D-F2-D06	TAG
DATA IN	01A-B2P2-Z08	01D-F2-G08	TAG
DISCONNECT IN	01A-B2P2-Z31	01D-F2-J11	TAG
OPERATIONAL IN	01A-B2P2-Y03	01D-F2-B03	TAG
SELECT IN	01A-B2P2-Y08	01D-F2-B08	TAG
REQUEST IN	01A-B2P2-Z26	01D-F2-J06	TAG
METERING IN	01A-B2P2-Z05	01D-F2-G05	TAG

MPX Cable Routing

SIGNAL NAME	CARD TOP CON- NECTOR PIN	TAILGATE PIN	CABLE TYP
BUS OUT BIT P	01A-B2W2-W03	01D-D3-B03	BUS
BUS OUT BIT 0	01A-B2W2-W24	01D-D3-D04	BUS
BUS OUT BIT 1	01A-B2W2-W05	01D-D3-B05	BUS
BUS OUT BIT 2	01A-B2W2-W26	01D-D3-D06	BUS
BUS OUT BIT 3	01A-B2W2-W08	01D-D3-B08	BUS
BUS OUT BIT 4	01A-B2W2-W29	01D-D3-D09	BUS
BUS OUT BIT 5	01A-B2W2-W10	01D-D3-B10	BUS
BUS OUT BIT 6	01A-B2W2-W31	01D-D3-D11	BUS
BUS OUT BIT 7	01A-B2W2-W12	01D-D3-B12	BUS
BUS IN BIT P	01A-B2W2-X03	01D-D3-G03	BUS
BUS IN BIT 0	01A-B2W2-X24	01D-D3-J04	BUS
BUS IN BIT 1	01A-B2W2-X05	01D-D3-G05	BUS
BUS IN BIT 2	01A-B2W2-X26	01D-D3-J06	BUS
BUS IN BIT 3	01A-B2W2-X08	01D-D3-G08	BUS
BUS IN BIT 4	01A-B2W2-X29	01D-D3-J09	BUS
BUS IN BIT 5	01A-B2W2-X10	01D-D3-G10	BUS
BUS IN BIT 6	01A-B2W2-X31	01D-D3-J11	BUS
BUS IN BIT 7	01A-B2W2-X12	01D-D3-G12	BUS
MARK OUT	01A-B2W2-W33	01D-D3-D13	BUS
MARK IN	01A-B2W2-X33	01D-D3-J13	BUS
ADDRESS OUT	01A-B2W2-Y10	01D-E3-B10	TAG
COMMAND OUT	01A-B2W2-Y31	01D-E3-D11	TAG
SERVICE OUT	01A-B2W2-Y33	01D-E3-D13	TAG
DATA OUT	01A-B2W2-Z10	01D-E3-G10	TAG
SUPRESS OUT	01A-B2W2-Y12	01D-E3-G12	TAG
OPERATIONAL OUT	01A-B2W2-Z33	01D-E3-J13	TAG
HOLD/SELECT OUT	01A-B2W2-Y29	01D-E3-D09	TAG
COND SUPPR OUT	01A-B2W2-Y12	01D-E3-B12	TAG
METERING OUT	01A-B2W2-Z24	01D-E3-J04	TAG
ADDRESS IN	01A-B2W2-Y05	01D-E3-B05	TAG
STATUS IN	01A-B2W2-Y24	01D-E3-D04	TAG
SERVICE IN	01A-B2W2-Y26	01D-E3-D06	TAG
DATA IN	01A-B2W2-Z08	01D-E3-G08	TAG
DISCONNECT IN	01A-B2W2-Z31	01D-E3-J11	TAG
OPERATIONAL IN	01A-B2W2-Y03	01D-E3-B03	TAG
SELECT IN	01A-B2W2-Y08	01D-E3-B08	TAG
REQUEST IN	01A-B2W2-Z26	01D-E3-J06	TAG
METERING IN	01A-B2W2-Z05	01D-E3-G05	TAG

BMPX 1 Cable Routing

SIGNAL NAME	CARD TOP CON- NECTOR PIN	TAILGATE PIN	CABLE TYP
BUS OUT BIT P	01A-B2B2-W03	01D-F3-B03	BUS
BUS OUT BIT 0	01A-B2B2-W24	01D-F3-D04	BUS
BUS OUT BIT 1	01A-B2B2-W05	01D-F3-B05	BUS
BUS OUT BIT 2	01A-B2B2-W26	01D-F3-D06	BUS
BUS OUT BIT 3	01A-B2B2-W08	01D-F3-B08	BUS
BUS OUT BIT 4	01A-B2B2-W29	01D-F3-D09	BUS
BUS OUT BIT 5	01A-B2B2-W10	01D-F3-B10	BUS
BUS OUT BIT 6	01A-B2B2-W31	01D-F3-D11	BUS
BUS OUT BIT 7	01A-B2B2-W12	01D-F3-B12	BUS
BUS IN BIT P	01A-B2B2-X03	01D-F3-G03	BUS
BUS IN BIT 0	01A-B2B2-X24	01D-F3-J04	BUS
BUS IN BIT 1	01A-B2B2-X05	01D-F3-G05	BUS
BUS IN BIT 2	01A-B2B2-X26	01D-F3-J06	BUS
BUS IN BIT 3	01A-B2B2-X08	01D-F3-G08	BUS
BUS IN BIT 4	01A-B2B2-X29	01D-F3-J09	BUS
BUS IN BIT 5	01A-B2B2-X10	01D-F3-G10	BUS
BUS IN BIT 6	01A-B2B2-X31	01D-F3-J11	BUS
BUS IN BIT 7	01A-B2B2-X12	01D-F3-G12	BUS
MARK OUT	01A-B2B2-W33	01D-F3-D13	BUS
MARK IN	01A-B2B2-X33	01D-F3-J13	BUS
ADDRESS OUT	01A-B2B2-Y10	01D-G3-B10	TAG
COMMAND OUT	01A-B2B2-Y31	01D-G3-D11	TAG
SERVICE OUT	01A-B2B2-Y33	01D-G3-D13	TAG
DATA OUT	01A-B2B2-Z10	01D-G3-G10	TAG
SUPRESS OUT	01A-B2B2-Y12	01D-G3-G12	TAG
OPERATIONAL OUT	01A-B2B2-Z33	01D-G3-J13	TAG
HOLD/SELECT OUT	01A-B2B2-Y29	01D-G3-D09	TAG
COND SUPPR OUT	01A-B2B2-Y12	01D-G3-B12	TAG
METERING OUT	01A-B2B2-Z24	01D-G3-J04	TAG
ADDRESS IN	01A-B2B2-Y05	01D-G3-B05	TAG
STATUS IN	01A-B2B2-Y24	01D-G3-D04	TAG
SERVICE IN	01A-B2B2-Y26	01D-G3-D06	TAG
DATA IN	01A-B2B2-Z08	01D-G3-G08	TAG
DISCONNECT IN	01A-B2B2-Z31	01D-G3-J11	TAG
OPERATIONAL IN	01A-B2B2-Y03	01D-G3-B03	TAG
SELECT IN	01A-B2B2-Y08	01D-G3-B08	TAG
REQUEST IN	01A-B2B2-Z26	01D-G3-J06	TAG
METERING IN	01A-B2B2-Z05	01D-G3-G05	TAG

BMPX 2 Cable Routing

SIGNAL NAME	CARD TOP CON- NECTOR PIN	TAILGATE PIN	CABLE TYP
BUS OUT BIT P	01A-B2L2-W03	01D-C2-B03	BUS
BUS OUT BIT 0	01A-B2L2-W24	01D-C2-D04	BUS
BUS OUT BIT 1	01A-B2L2-W05	01D-C2-B05	BUS
BUS OUT BIT 2	01A-B2L2-W26	01D-C2-D06	BUS
BUS OUT BIT 3	01A-B2L2-W08	01D-C2-B08	BUS
BUS OUT BIT 4	01A-B2L2-W29	01D-C2-D09	BUS
BUS OUT BIT 5	01A-B2L2-W10	01D-C2-B10	BUS
BUS OUT BIT 6	01A-B2L2-W31	01D-C2-D11	BUS
BUS OUT BIT 7	01A-B2L2-W12	01D-C2-B12	BUS
BUS IN BIT P	01A-B2L2-X03	01D-C2-G03	BUS
BUS IN BIT 0	01A-B2L2-X24	01D-C2-J04	BUS
BUS IN BIT 1	01A-B2L2-X05	01D-C2-G05	BUS
BUS IN BIT 2	01A-B2L2-X26	01D-C2-J06	BUS
BUS IN BIT 3	01A-B2L2-X08	01D-C2-G08	BUS
BUS IN BIT 4	01A-B2L2-X29	01D-C2-J09	BUS
BUS IN BIT 5	01A-B2L2-X10	01D-C2-G10	BUS
BUS IN BIT 6	01A-B2L2-X31	01D-C2-J11	BUS
BUS IN BIT 7	01A-B2L2-X12	01D-C2-G12	BUS
MARK OUT	01A-B2L2-W33	01D-C2-D13	BUS
MARK IN	01A-B2L2-X33	01D-C2-J13	BUS
ADDRESS OUT	01A-B2L2-Y10	01D-D2-B10	TAG
COMMAND OUT	01A-B2L2-Y31	01D-D2-D11	TAG
SERVICE OUT	01A-B2L2-Y33	01D-D2-D13	TAG
DATA OUT	01A-B2L2-Z10	01D-D2-G10	TAG
SUPRESS OUT	01A-B2L2-Y12	01D-D2-G12	TAG
OPERATIONAL OUT	01A-B2L2-Z33	01D-D2-J13	TAG
HOLD/SELECT OUT	01A-B2L2-Y29	01D-D2-D09	TAG
COND SUPPR OUT	01A-B2L2-Y12	01D-D2-B12	TAG
METERING OUT	01A-B2L2-Z24	01D-D2-J04	TAG
ADDRESS IN	01A-B2L2-Y05	01D-D2-B05	TAG
STATUS IN	01A-B2L2-Y24	01D-D2-D04	TAG
SERVICE IN	01A-B2L2-Y26	01D-D2-D06	TAG
DATA IN	01A-B2L2-Z08	01D-D2-G08	TAG
DISCONNECT IN	01A-B2L2-Z31	01D-D2-J11	TAG
OPERATIONAL IN	01A-B2L2-Y03	01D-D2-B03	TAG
SELECT IN	01A-B2L2-Y08	01D-D2-B08	TAG
REQUEST IN	01A-B2L2-Z26	01D-D2-J06	TAG
METERING IN	01A-B2L2-Z05	01D-D2-G05	TAG

IC-Bus 0 and 1


General Information

The integrated channel bus is the link between the processing unit and the adapters of the system. The bus is two bytes wide (data/address path) and also contains the request/response control lines. The IC-bus consists of three different types of lines


- Ring lines 1
- Star lines 2
- Stub lines 3

which are routed to the adapter in three different ways as shown below.


① Ring Lines



② Star Lines



③ Stub Lines




The 4331/2 system has two independently working IC-buses each servicing three adapters. The two buses are named IC-bus 0 and IC-bus 1.

Five different adapters (MPX/CA, SCA2, FTA2, FTA3, HSC) can be attached to the IC-bus 0, but only three can be attached at one time. This results in three base configurations (version 1, 2 and 3). Only three different adapters (FTA1, SCA1, BBA 0/1) can be attached to the IC-bus 1. This results in only one base configuration. The base configuration equals the maximum configuration of the bus. Depending on the configuration of the system only one or two adapters may be attached to IC-bus.

IC-Bus Adapter Addressing

The system uses a logical and physical address scheme to address the IC-bus adapters. The table below shows the relationship of the address schemes.

IC-Bus Number	Adapter	Logical Address	Physical Address
0	HSC	0	1
	FTA 3	1	2
	FTA 2 or BMPX 2	2	4
	MPX/CA	3	6
1	FTA 1	4	9
	BMPX 1	5	A
	BBA 0/1	7	E



EC 366269
03 Aug 79

EC 366284
27 Mar 80




EC 366388
23 Jan 81

P/N 5683391
Page 1 of 12



1 110 F

IC Bus 0 and 1 (continued)

IC Bus Configuration






Cable Layout of IC Bus 0 and 1



For details on IC bus 1 refer to page 1134

1) Version 1, 2 D4C → YG
Version 3 D4B → YG

Cable Layout of IC Bus 0—Detail A



IC-Bus 0

Signal Names of IC Bus 0 Cables

Cable Number 8

From 01A-B1	To 01A-B2*	Signal Name
D4A02	V1D08	- IC Bus 0 Bit P,0-7
D4A03	V1D06	- IC Bus 0 Bit 0
D4A04	V1E06	- IC Bus 0 Bit 1
D4A06	W1A08	- IC Bus 0 Bit 2
D4A07	W1B06	- IC Bus 0 Bit 3
D4A08	W1B08	- IC Bus 0 Bit 4
D4A10	W1C06	- IC Bus 0 Bit 5
D4A11	W1C08	- IC Bus 0 Bit 6
D4A12	W1D06	- IC Bus 0 Bit 7
D4A14	W1E08	+ IC 0 Control 1
D4A15	X1A06	+ IC 0 Control 2
D4A16	X1A08	- IC 0 Control Parity
D4A18	X1B06	- IC CS Request Adapter 3
D4A19	X1B08	- IC CS Grant Adapter 3
D4A20	X1C06	- IC Trap 1 Request Adapter 3
D4A22	X1E08	- IC Trap 2 Request Adapter 3
D4A23	X1D08	+ IC Any Inbound Bit Adapter 3
D4A24	X1E06	- IC Check Adapter 3

* Connector YH

Cable Number 9 Version 1, 2

From 01A-B1	To 01A-B2*	Signal Name
D4C02	S1E08	- IC Bus 0 Bit P,8-15
D4C03	S1E06	- IC Bus 0 Bit 8
D4C04	T1A06	- IC Bus 0 Bit 9
D4C06	T1B08	- IC Bus 0 Bit 10
D4C07	T1C06	- IC Bus 0 Bit 11
D4C08	T1C08	- IC Bus 0 Bit 12
D4C10	T1D06	- IC Bus 0 Bit 13
D4C11	T1D08	- IC Bus 0 Bit 14
D4C12	T1E06	- IC Bus 0 Bit 15
D4C14	U1A08	- IC Clock 5A
D4C15	U1B06	- IC Clock 10A
D4C18	U1C06	- IC CS Request Adapter 1
D4C19	U1C08	- IC CS Grant Adapter 1
D4C20	U1D06	- IC Trap 1 Request Adapter 1
D4C21	V1A08	- IC Trap 2 Request Adapter 1
D4C23	V1E08	+ IC Any Inbound Bit Adapter 1
D4C24	V1A06	- IC Check Adapter 0/1

* Connector YG

© Copyright International Business Machines Corporation 1979, 1980, 1981

Cable Number 9 Version 3

From 01A-B1	To 01A-B2*	Signal Name
D4B02	S1E08	- IC Bus 0 Bit P, 8-15
D4B03	S1E06	- IC Bus 0 Bit 8
D4B04	T1A06	- IC Bus 0 Bit 9
D4B06	T1B08	- IC Bus 0 Bit 10
D4B07	T1C06	- IC Bus 0 Bit 11
D4B08	T1C08	- IC Bus 0 Bit 12
D4B10	T1D06	- IC Bus 0 Bit 13
D4B11	T1D08	- IC Bus 0 Bit 14
D4B12	T1E06	- IC Bus 0 Bit 15
D4B14	U1A08	- IC Clock 5A
D4B15	U1B06	- IC Clock 10A
D4B16	U1B08	+ Status Mode Adapter 0
D4B18	U1C06	- IC CS Request Adapter 0
D4B19	U1C08	- IC CS Grant Adapter 0
D4B20	U1D06	- IC Trap 1 Request Adapter 0
D4B22	V1A08	- IC Trap 2 Request Adapter 0
D4B23	V1E08	+ IC Any Inbound Bit Adapter 0
D4B24	V1A06	- IC Check Adapter 0/1

* Connector YG

Cable Number 10

From 01A-B2*	To 01A-B1	Signal Name
Q1A08	D4D02	- IC Bus 0 Bit P, (0-7)
Q1A06	D4D03	- IC Bus 0 Bit 0
Q1B06	D4D04	- IC Bus 0 Bit 1
Q1C08	D4D06	- IC Bus 0 Bit 2
Q1D06	D4D07	- IC Bus 0 Bit 3
Q1D08	D4D08	- IC Bus 0 Bit 4
Q1E06	D4D10	- IC Bus 0 Bit 5
Q1E08	D4D11	- IC Bus 0 Bit 6
R1A06	D4D12	- IC Bus 0 Bit 7
R1B08	D4D14	+ IC 0 Control Bit 1
R1C06	D4D15	+ IC 0 Control Bit 2
R1C08	D4D16	- IC 0 Control P
R1D06	D4D18	- IC CS Request Adapter 2
R1D08	D4D19	- IC CS Grant Adapter 2
R1E06	D4D20	- IC Trap 1 Request 2
S1B08	D4D22	- IC Trap 2 Request 2
S1A08	D4D23	+ IC Any Inbound Bit Adapter 2
S1B06	D4D24	- IC Check Adapter 2

* Connector YF

Cable Number 11

From 01A-B2*	To 01A-B1	Signal Name
M1B08	D4E02	- IC Bus 0 Bit, P, 8-15
M1B06	D4E03	- IC Bus 0 Bit 8
M1C06	D4E04	- IC Bus 0 Bit 9
M1D08	D4E06	- IC Bus 0 Bit 10
M1E06	D4E07	- IC Bus 0 Bit 11
M1B08	D4E08	- IC Bus 0 Bit 12
N1A06	D4E10	- IC Bus 0 Bit 13
N1A08	D4E11	- IC Bus 0 Bit 14
N1B06	D4E12	- IC Bus 0 Bit 15
N1C08	D4E14	- IC Clock 5B
N1D06	D4E15	- IC Clock 10B
N1D08	D4E16	- IC Clock 5C
P1C08	D4E22	- IC Clock 10C

* Connector YE


Cable Number 12

From 01A-B1	To 01A-B2*	Signal Name
B4C14	K1D08	- IC 0 Data Strobe
B4C15	K1B06	- IC 0 Control Strobe
B4C16	K1E08	- IC 0 Sense Gate

* Connector YD

IC Bus 0 Ring Lines


This page shows the IC bus 0 'bus ring lines' for version 1.



IC BUS 0 (continued)


IC Bus 0 Ring Lines (continued)

This page shows the IC bus 0 'bus ring lines' for version 2



IC Bus 0 Ring Lines (continued)


This page shows the IC bus 0 'bus ring lines' for version 3



IC Bus 0 (continued)





IC Bus 0 Ring Lines (continued)

This page shows on the right side all three possible base configurations of the IC bus 0.



IC Bus 0 Star Lines





This page shows the star lines for version 1.



IC Bus 0 (continued)





IC Bus 0 Star Lines (continued)

This page shows the star lines for version 2.



IC Bus 0 Star Lines (continued)



This page shows the star lines for version 3.



IC Bus 0 (continued)

IC Bus 0 Stub Lines

This page shows on the right side all three possible base configurations (versions) of the IC bus 0.



IC Bus 1

Signal Names of IC Bus 1 Cables

Cable Number 4

From 01A-A2*	To 01A-B1	Signal Name
S1E13	B4D02	- IC Bus 1 Bit, P, 8-15
S1E11	B4D03	- IC Bus 1 Bit 8
T1A11	B4D04	- IC Bus 1 Bit 9
T1B13	B4D06	- IC Bus 1 Bit 10
T1C11	B4D07	- IC Bus 1 Bit 11
T1C13	B4D08	- IC Bus 1 Bit 12
T1D11	B4D10	- IC Bus 1 Bit 13
T1D13	B4D11	- IC Bus 1 Bit 14
T1E11	B4D12	- IC Bus 1 Bit 15
U1A13	B4D14	+ IC 1 Control 1
U1B11	B4D15	+ IC 1 Control 2
U1B13	B4D16	- IC 1 Control Parity
U1C11	B4D18	- IC CS Request Adapter 7
U1C13	B4D19	- IC CS Grant Adapter 7
U1D11	B4D20	- IC Trap 1 Request 7
V1A13	B4D22	- IC Trap 2 Request 7
U1E13	B4D23	+ IC Any Inbound Bit Adapter 7
V1A11	B4D24	- IC Check Adapter 7

* Connector YQ

Cable Number 5

From 01A-A2*	To 01A-B1	Signal Name
V1E11	B4E04	- IC 1 Data Strobe
W1A13	B4E06	- IC 1 Control Strobe
W1B11	B4E07	- IC 1 Sense Gate
W1B13	B4E08	- IC Adapter Degate
W1E13	B4E14	- IC Bus 1 Bit P 0 - 7
X1A11	B4E15	- IC Bus 1 Bit 0
X1A13	B4E16	- IC Bus 1 Bit 1
X1B11	B4E18	- IC Bus 1 Bit 2
X1B13	B4E19	- IC Bus 1 Bit 3
X1C11	B4E20	- IC Bus 1 Bit 4
X1E13	B4E22	- IC Bus 1 Bit 5
X1D13	B4E23	- IC Bus 1 Bit 6
X1E11	B4E24	- IC Bus 1 Bit 7

* Connector YR

Cable Number 6

From 01A-B2	To 01A-A2	Signal Name
A3D13	X3D13	- IC Bus Bit P, (8-15)
A3D03	X3D03	- IC Bus Bit 8
A3D05	X3D05	- IC Bus Bit 9
A3D06	X3D06	- IC Bus Bit 10
A3D07	X3D07	- IC Bus Bit 11
A3D09	X3D09	- IC Bus Bit 12
A3D10	X3D10	- IC Bus Bit 13
A3D11	X3D11	- IC Bus Bit 14
A3B10	X3B10	- IC Bus Bit 15
A3B12	X3B12	- IC Clock 5B
A3B13	X3B13	- IC Clock 10B
A3B06	X3B06	- IC Sense Gate
A3B05	X3B05	- IC Control Strobe
A3B09	X3B09	- IC Data Strobe
A3B08	X3B08	- IC Adapter Degate

Cable Number 7

From 01A-B2	To 01A-A2	Signal Name
A2B12	X2B12	- IC Bus Bit P, (0-7)
A2D02	X2D02	- IC Bus Bit 0
A2B04	X2B04	- IC Bus Bit 1
A2D05	X2D05	- IC Bus Bit 2
A2D06	X2D06	- IC Bus Bit 3
A2D07	X2D07	- IC Bus Bit 4
A2D09	X2D09	- IC Bus Bit 5
A2D10	X2D10	- IC Bus Bit 6
A2D11	X2D11	- IC Bus Bit 7
A2B08	X2B08	- IC Control Bit 1
A2D13	X2D13	- IC Control Bit 2
A2B13	X2B13	- IC Control P

Cable Number 11

From 01A-B1	To 01A-B2*	Signal Name
D4E14	N1C08	- IC Clock 5B
D4E15	N1D06	- IC Clock 10B

* Connector YE

Cable Number 12

From 01A-B1	To 01A-B2*	Signal Name
B4C02	J1C08	- IC Bus 1 Bit P, 0-7
B4C03	J1C06	- IC Bus 1 Bit 0
B4C04	J1D06	- IC Bus 1 Bit 1
B4C06	J1E08	- IC Bus 1 Bit 2
B4C07	K1A06	- IC Bus 1 Bit 3
B4C08	K1A08	- IC Bus 1 Bit 4
B4C10	K1B06	- IC Bus 1 Bit 5
B4C11	K1B08	- IC Bus 1 Bit 6
B4C12	K1C06	- IC Bus 1 Bit 7
B4C18	L1A06	- IC CS Request Adapter 4
B4C19	L1A08	- IC CS Grant Adapter 4
B4C20	L1B06	- IC Trap 1 Request Adapter 4
B4C22	L1D08	- IC Trap 2 Request Adapter 4
B4C23	L1C08	+ IC Any Inbound Bit Adapter 4
B4C24	L1D06	- IC Check Adapter 4

* Connector YD


Cable Number 13

From 01A-B1	To 01A-B2*	Signal Name
B4B02	F1D08	- IC Bus 1 Bit P, 8-15
B4B03	F1D06	- IC Bus 1 Bit 8
B4B04	F1E06	- IC Bus 1 Bit 9
B4B06	G1A08	- IC Bus 1 Bit 10
B4B07	G1B06	- IC Bus 1 Bit 11
B4B08	G1B08	- IC Bus 1 Bit 12
B4B10	G1C06	- IC Bus 1 Bit 13
B4B11	G1C08	- IC Bus 1 Bit 14
B4B12	G1D08	- IC Bus 1 Bit 15
B4B14	G1E08	+ IC 1 Control 1
B4B15	H1A06	+ IC 1 Control 2
B4B16	H1A08	- IC 1 Control Parity
B4B18	H1B06	- IC CS Request Adapter 5
B4B19	H1B08	- IC CS Grant Adapter 5
B4B20	H1C06	- IC Trap 1 Request Adapter 5
B4B22	H1E08	- IC Trap 2 Request Adapter 5
B4B23	H1D08	+ IC Any Inbound Bit Adapter 5
B4B24	H1E06	- IC Check Adapter 5


* Connector YC

IC Bus 1 (continued)

IC Bus 1 Ring Lines







IC Bus 1 Ring Lines (continued)



IC Bus 1 (continued)

IC Bus 1 Star Lines




IC Bus 1 Stub Lines

Board 01 A - B1

Board 01 A - A2

Board 01 A - B2



This page has been intentionally left blank.



This page has been
intentionally left blank

EC 366221 31 Jan 79	EC 366233 30 Apr 79	EC 366388 23 Jan 81	P/N 8488377 Page 1 of 6	1 185
------------------------	------------------------	------------------------	----------------------------	-------

Processor Bus for Support Subsystem

Bus Layout

The processor bus consists of 34 lines:
 Bus byte 0, Bus byte 1,
 and 16 control lines.




Pin Location Charts

Processor Bus (Bytes)	Location of Card	Processor C2 E2	SCL Card 3 C2 C2	Connector C2 YJ	Connector A2 YM	PCI A2 E2	DCA Card 3 A2 K2	SBA A2 Q2	CDF Card 1 A2N2 A2 R2	BBA 0 A2 T2	RSF A2 W2
Byte 0 Bit 0		M02	D13	A1 B13	J1 D13	B08	G02	J09	G04	S06	G02
Byte 0 Bit 1		P02	B12	A1 C13	J1 E13	D11	J02	B07	D13	S12	J02
Byte 0 Bit 2		M03	B13	A1 D13	K1 A13	D10	D10	B13	J02	U10	D10
Byte 0 Bit 3		P04	D10	B1 A13	K1 C13	B09	G08	B08	G02	U09	G08
Byte 0 Bit 4		M04	D09	B1 B13	K1 D13	D06	J04	B09	J06	S10	J04
Byte 0 Bit 5		M05	B10	B1 C13	K1 E13	B03	D09	G02	G07	S05	D09
Byte 0 Bit 6		P05	D06	B1 D13	L1 A13	B10	B09	B10	G08	S07	B09
Byte 0 Bit 7		P06	D07	C1 A13	L1 C13	D04	D06	G03	G03	U12	D06
Byte 0 Bit P		P07	B03	C1 B13	L1 D13	B06	B02	G04	B12	S08	B02
Byte 1 Bit 8		P09	U06	A1 C11	J1 E11	J13	G09	J10	D12	U05	G09
Byte 1 Bit 9		M09	U04	A1 D11	K1 A11	J10	B07	J02 / G06	J04	S09	J06
Byte 1 Bit 10		M10	S04	A1 E11	K1 B11	G09	G07	G07	G09	U02	B07
Byte 1 Bit 11		P10	S03	D1 A11	K1 C11	G08	J07	J04	J07	U07	J07
Byte 1 Bit 12		P11	P09	B1 C11	K1 E11	G10	G10	J05	D10	U04	G10
Byte 1 Bit 13		P12	M09	B1 D11	L1 A11	G06	J10 / S08	J06	J09 / M08	U13	J10
Byte 1 Bit 14		P13	M08	B1 E11	L1 B11	J07	J11	J07	G05	S11	J11
Byte 1 Bit 15		M12	M07	C1 A11	L1 C11	G05	J12	G08	J05	U11	J12
Byte 1 Bit P		M13	S10	C1 B11	L1 D11	J06	G12	G09	B10	M13	G12

Processor Cont. Lines	Location of Card	Processor C2F2	Processor C2E2	SCL 3 C2C2	SCL 4 C2B4	Connector C2YK	Connector A2YD	PCI A2 E2	DCA Card 3 A2K2	SBA A2Q2	CDF Card 1 A2N2 A2R2	BBA 0 A2T2	RSF A2W2
Adapter to SP	Valid Byte	D04		D11		F1A11	L1D06	B12			U02	G07	G03
	Valid Halfword	B09		B02/S12		E1C11	L1A06		J09	B05			
	IRR	B03		D12		E1D11	L1B06	B04	D02	J12	P10	G12	D02
	Parity Valid	B12		U12		E1E11	L1C06	J04	D07	G05	U11	M04	D07
	CSR	B04				C1E11	J1C06		S02		M05	B09	
	EOC	D09				D1C11	K1A06		M05		U13	P05	
	PIO Reset			G09	D10	E1A13	K1D08		J06	D09	S03	D04	J05
	Restart	S08			J11								
SP to Adapter	TA	D05		S13		E1C13	L1A08	G04	D05	D12	U06	G08	D05
	TC	B10		B04		E1E13	L1C08	G02			S05	G05	B08
	TD	D11		G08		F1A13	L1D08	D13	B05	D13	U05	M11	B05
	I/O Tag	G08	U09	U13		E1B13	K1E08	B13	B04	D04	S09	J09	B04
	Halt	B07		M13		D1E13	K1C08	J02	G04	P11	P02	P07	G04
	CSG	D10		D04	G04	D1B11	J1E06				U10		
	Byte Tag	B08				D1D11							
	CSG Pass DCA								B10		S10	J10	
	OSC Out	U02		S05		D1E11	K1C06			D11			

Note: Not all control lines of the Processor bus are used for each Adapter.



The following picture shows for example one bit of bus 0. All the other bits and control lines use the same way.



Processor Bus for I/O Subsystem

Bus Layout

The processor bus consists of 34 lines:
 Bus byte 0, Bus byte 1,
 and 16 control lines.





Pin Location Charts

Location of Card Processor Bus (Bytes)	BBA 1	Connector	Connector	MFCU	SCL Card 1	IOC Card 4	LOOP * HPCA card
	A2 U2	A2 YG	A1 ZG	A1 R2	A1 B2	A1 D2	J2,L2,N2,Q2
Byte 0 Bit 0	S06	T1 A08	T6 A04	P10	D13	M02	G02
Byte 0 Bit 1	S12	T1 B08	T6 B04	U05	B12	P02	J02
Byte 0 Bit 2	U10	T1 C08	T6 C04	M13	B13	M03	D10
Byte 0 Bit 3	U09	T1 E08	T6 E04	P12	D10	P04	G08
Byte 0 Bit 4	S10	U1 A08	U6 A04	P13	D09	M04	J04
Byte 0 Bit 5	S05	U1 B08	U6 B04	M08	B10	M05	D09
Byte 0 Bit 6	S07	U1 C08	U6 C04	M10	D06	P05	B09
Byte 0 Bit 7	U12	U1 E08	U6 E04	S03	D07	P06	D06
Byte 0 Bit P	S08	V1 A08	V6 A04	P11	B03	P07	B02
Byte 1 Bit 8	U05	T1 B06	T6 B02	M09	U06	P09	G09
Byte 1 Bit 9	S09	T1 C06	T6 C02	M12	U04	M09	J06
Byte 1 Bit 10	U02	T1 D06	T6 D02	M06	S04	M10	G07
Byte 1 Bit 11	U07	T1 E06	T6 E02	M11	S03	P10	J07
Byte 1 Bit 12	U04	U1 B06	U6 A02	P07	P09	P11	B07
Byte 1 Bit 13	U13	U1 C06	U6 B02	U04	M09	P12	J10
Byte 1 Bit 14	S11	U1 D06	U6 D02	U02	M08	P13	J11
Byte 1 Bit 15	U11	U1 E06	U6 E02	S04	M07	M12	J12
Byte 1 Bit P	M13	V1 A06	V6 A02	S02	S10	M13	G12


* Up to four HPCA may be installed

Location of Card Processor Control Lines	BBA 1	Connector	Connector	MFCU	SCL Card 1	IOC Card 3	LOOP * HPCA card
	A2 U2	A2 YH	A1 ZH	A1 R2	A1 B2	A1 E2	J2,L2,N2,Q2
Adapter to IOC	Valid Byte	G07	X1 E06	X6 E02	U07		G03
	Valid Halfword					B09	
	I/O Exception					D2 U11	
	IRR	G12	X1 C06	X6 C02	J12	D12	D02
	Parity Valid	M04	X1 D06	X6 D02	U12	B12	D07
	CSR	B09	V1 D06	W6 B04	S09		M13
	EOC	P05	W1 B06	W6 B02	S06	D09	P11
	Reset				G09	J02	J05
IOC to Adapter	Restart					S08	
	TA	G08	X1 B08	X6 B04	S10	S13	D05
	TC	G05	X1 D08	X6 D04	U09	B04	B10
	TD	M11	X1 E08	X6 E04	U13	G08	D11
	I/O Tag	J09	X1 A08	X6 A04	G10	U13	G08
	Halt	P07	W1 A08	W6 D04	S08	M13	B07
	CSG	J10	W1 D06		P02	D04	D10
	Byte Tag						B08

Note: Not all control lines of the I/O Subsystem are used for each adapters



Support Processor Restart Line




Supplement to MAPs, Section 2: REMOVALS and REPLACEMENTS

Table of Contents


Title	Page
Table of Contents - Section 2	2000
Check and Replacement Procedures	2010
Cable Check and Replacement Procedure	2010
B1 Board Replacement	2010
22 Position Board Replacement	2020
Handling ESD Sensitive Parts	2030

Check and Replacement Procedures


Cable Check and Replacement Procedure




Note: To replace a cable in position YA or YR, loosen the upper retainer and remove it.



To replace a cable in position ZA to ZH, loosen the lower retainer.







B1 Board Replacement





A

22-Position Board Replacement



5 Crossover connectors can easily be removed using the extraction tool P/N 454065(wire relay extraction tool).



6 To remove cards use extraction tool P/N2360375.

Handling of ESD Sensitive Parts

- 1. Keep the part in the original shipping container (ESD Bag) until actually ready to plug it into the machine.
- 2. When handling ESD sensitive parts, minimize body movements to prevent the build up of static electricity from clothing fibers, carpeting, and furniture.
- 3. Just prior to touching the sensitive part, discharge yourself to the frame of the machine by deliberate physical contact to the metal frame or cover. If possible, keep one hand on the frame when inserting or removing a card.
- 4. Avoid touching the pins on the components by handling the card by its edges or shroud. If removing a pluggable module, use the proper tool.
- 5. Do not place the part on the machine cover or on a metal table. These are electrical grounds, and increase the risk of damage by providing a discharge path from your body to ground through the components on the part. Parts should be immediately placed in the special ESD protective bag if it must be temporarily placed down. (Large metal objects can be discharge paths without being grounded.)
- 6. Do not leave parts exposed to accidental contact with other personnel (other CE's, customers, etc.) who may come into physical contact with an exposed ESD sensitive part. Replace machine covers when not actually working on the machine and do not lay ESD sensitive parts out on a table or bench unprotected.
- 7. If practical, store all ESD sensitive parts in a grounded metal cabinet.
- 8. Be extra cautious in handling during the winter heating season because low humidity contributes to static build up.

Supplement to MAPs, Section 3: ADJUSTMENTS

Table of Contents

<i>Title</i>	<i>Page</i>
Contents of Section 3	3000
Blank Page	3010

In this system there are only adjustments needed for POWER. They are described in the POWER MANUAL.

This page has been
intentionally left blank

Supplement to MAPs, Section 4: DIAGNOSTIC RUN PROCEDURES
Table of Contents

Title	Page	Title	Page	Title	Page
Table of Contents - Section 4	4000	How to Load OLTSEP	4254	(USSNAA) Card Code CE60	4506
M/S Program Selection - Overview	4010	How to Load OLTSEP (continued)	4255	(WTSNMA) Card Code CE62	4507
How to Select a M/S Program	4010	Central Complex Test Selection	4320	Line Plate Adjustment Procedure	4507
M/S Programs - Handling Overview	4012	Test Chaining Selection	4325	(WTLL) Card Code CE65	4508
Log Programs	4012	Blank Page	4328	RSF Line Error Statistics	4509
Test Programs	4014	IC-Bus Test	4329	RSF Diagnostics	4512
Test Programs (continued)	4016	PU-BSM Test	4330	Adapter Test	4512
Tool Programs	4020	Special Control Store Test (Handling)	4332	Sending a Test Pattern	4513
Log Mode Selection	4030	Special Control Store Test (continued)	4334	Receiving a Test Pattern	4514
Disable Channel Logs	4030	Special Control Store Test (continued)	4336	Use of the Acoustic Coupler	4514
Erase Selective Log	4032	Diagnostic MS Test	4338	Resetting the Modem to Talk Mode	4514
Erase All Logs	4034	IM-Test (Handling)	4339	Cable Wrap Test for EIA Interface	4515
Stop Before Log	4036	IM-Test (Handling continued)	4340	Reference Code Intermediate Storing and	
Reference Code Log		Blank Page	4341	Display Function	4516
(Log Distribution Statistics)	4040	FTA (X) Test	4350	How to Display the Stored Data Bank	
Example of Log Distribution	4042	Control Interface Wrap Test	4355	Information	4516
Detailed Log Display		How to Plug the Wrap Connectors	4355	FRIEND PRINT LOG Function	4516
Selection	4050	MPX/BMPX Adapter Test	4360	How to Install a MCTF or IRECA Update	
Explanation of the Common Area on Screen	4055	Standard Interface Test for MPX/BMPX and HSC	4365	Received via Remote Link	4517
SP Machine Check Log Display	4070	How to Plug the Wrap Connectors	4365	Manual MCTF Installation	4530
Last PU Stop Log Display	4080	SBA/Support Bus Test	4370	Manual MCTF Installation (continued)	4531
PU Program Log Display	4090	BBA O/1 Test	4375	Manual MCTF Installation (continued)	4532
BBA O/1 Log Display	4100	HSC Adapter Test	4380	MCTF Update via MCTF Diskette	4533
MPX/BMPX, HSC Log Display	4110	SCL IOSS/MSS Test	4385	Diskette Identification	4540
IOC Log Display	4120	Disk/Tape Inline Tests, General	4400	Diskette Directory (DDIR) Display	4541
IC-Bus Log Display	4130	Exceptions for: 3310	4400	Diskette Directory (DDIR) Display (continued)	4542
FTA Log Display	4140	Exceptions for: 3340/3344	4400	Blank Page	4543
FTA Log Display (continued)	4142	Exceptions for: 3344	4400	Tests for DCA and Attached Devices	4545
Format Zero Messages and Sense Bytes	4145	Exceptions for: 3370	4401	Test 0	4545
Blank Page	4146	Exceptions for: 8809	4402	Test 1	4550
SPiL Program Log Display	4160	Disk/Tape Inline Test (Handling)	4410	Test 3 and 4	4555
IML Log Display	4170	Disk/Tape Inline Test (continued)	4411	Test 6	4560
Last Detailed Log Display	4180	Disk/Tape Inline Test (continued)	4412	Test 6 (continued)	4565
Integrated Reference Code Analysis (IRECA)	4200	Disk/Tape Inline Test (continued)	4413	Test 6 (continued)	4570
Integrated Reference Code Analysis (continued)	4201	Status Display - Examples	4420	Test 6 (continued)	4575
IRECA Info Box Selection	4202	Run Options - Explanation	4525	Test 6 (continued)	4580
Update - Introduction	4203	Control Options - Explanation	4430	DCA Control Block Display	4585
Reference Code Update Selection	4203	Control Options (continued)	4435	Test 7	4590
Reference Code Update Selection (continued)	4204	Inline Test Handling (Flowchart)	4440	SP Trace	4650
FRU Update Selection	4205	Inline Test Handling (continued)	4450	Lamp Test for SP Display Indicators	4650
FRU Update Selection (continued)	4206	Inline Test Handling (continued)	4455	Support Processor Display	4660
Message Update Selection	4207	Inline Test Handling (continued)	4460	Messages that Appear on Screen	4700
Message Update Selection(continued)	4208	MLX Cross References	4465	Messages that Appear on Screen (continued)	4710
Blank Page	4209	Outgoing References	4465		
System Test 4300 (ST-4300) / OLTSEP	4250	Incoming References	4465		
Introduction to ST4300	4250	Utilities Program Selection	4500		
Enhancements of the ST-4300 via ST-370	4250	Remote Support Facility	4501		
How to Load the ST-4300	4250	Remote Support Facility (continued)	4502		
How to Load the ST-4300 (continued)	4251	RSF Adapter Interface Cards	4503		
How to Load the ST-4300 (continued)	4252	External Modem Interface	4504		
Devices Supported by the ST-4300 Diskette		Card EIA/CCITT V24	4504		
Version	4253	Signal Flow and Wrap Test	4505		
Introduction to OLTSEP	4254	Integrated Modem Interface	4506		

© Copyright International Business Machines Corporation 1979, 1980, 1981

Maintenance/Service Program Selection - Overview

M/S Program Selection - Actions

Prerequisites:

1. IML complete
2. Control or Diagnostic diskette inserted.

How to Select a M/S Program:

1. Call M/S Program Selection.

A

This selection is available on the control and diagnostic diskette.


If the control diskette is inserted you must hold down the ALT KEY and press the DIAG key for selection.

If the diagnostic diskette is inserted only the DIAG key must be pressed for selection.
2. Key in the selection for the LOG, TEST or TOOL program you want to select.

A

The digits in front of the program name must be typed in behind the word SELECTION to select the appropriate program. A dash (-) instead of a digit indicates that the program is not available. (False diskette or wrong configuration).

M/S Program Selection - Results



M/S Program-Handling Overview

The following tables show the available LOG, TEST, and TOOL programs with a summary of all handling prerequisites.

These tables are intended as a quick recall aid on how to set up a wanted program and how to terminate this program.

The handling prerequisites are indicated by an asterisk (*) in the respective columns.

Log Programs

This table shows the available log programs and the summary of their handling prerequisites.

A log is recorded on the diagnostic diskette only for SP machine check, SPIL program, Power, and IML.

Note 1: This log is only documented in the Field Support Center documentation.

Note 2: For power logs and ambient recording logs refer to the Power Manual in Volume 16.

Note 3: For CA unit check log refer to the CA Section in Volume 14.

Note 4: For loop adapter log refer to the Loop Section in Volume 15.

LOG PROGRAMS		SETUP								TERMINATION					
Selectable from M/S PRO-GRAM SELECTION menu Selection offered in the selected menu V V		Control diskette								Manual stop required					
		Diagnostic diskette								Re-IML required					
		PWR complete light								Copy config progr					
		IML complete								Cancel key					
Page reference V		CE mode switch on								Vary on line					
		Vary off line								Jumper/plug					
		Jumper/plug								Previous test run					
		Previous test run								Runtime (min)					
		V	V	V	V	V	V	V	V	V	V	V	V	V	V
Log mode	4030	*	*												
Erase selective log	4032	*	*												
Erase all logs	4034	*	*												
Stop before log	4036	*	*	*	*										
Disable channel logs	4030	*	*	*	*										
Enable channel logs	4030	*	*	*	*										
Reference code log	4040	*	*												
Detailed log display	4050	*	*												
PU trace log	Note 1	*	*												
Power log	Note 2	*	*												
SP machine check log	4070	*	*												
PU stop log	4080	*	*												
PU program log	4090	*	*												
BBA 0/1 log	4100	*	*												
MPX/BMPX/HSC log	4110	*	*												
Ambient recording log	Note 2	*	*												
IOC log	4120	*	*												
IC bus log	4130	*	*												
FTA log	4140	*	*												
Loop adapter log	Note 4	*	*												
CA unit check log	Note 3	*	*												
SPIL program log	4160	*	*												
IML log	4170	*	*												
Last detailed log	4180	*	*												
Refcode analysis	4200	*	*	*	*										

M/S Programs Handling - Overview (continued)

Test Programs

This table shows the available diagnostic test programs and the summary of their handling prerequisites.

TEST PROGRAMS		SETUP								TERMINATION					
Selectable from M/S PRO-GRAM SELECTION menu Selection offered in the selected menu V V Page reference V		Control diskette	Diagnostic diskette	PWR complete light	IML complete	CE mode switch on	Vary off line	Jumper/plug	Previous test run	Manual stop required	Re-IML required	Copy config progr	Cancel key	Vary on line	Runtime (min)
Power		*	*								*				
Power controller status	Note 1	*	*								*				
Voltage measurement		*	*								*				
Central complex	4320	*	*								*				
PU-BSM test Note 9	4330		*	*	*						*				2/10
IC-bus test	4329		*	*							*				<1
BBA O/I test	4375		*	*						Note 5	*				<1
HSC adapter test	4380		*	*						Note 5	*				<1
HSC interface test	4365		*	*				*		Note 5	*				<1
FTA test	4350		*	*	*			*		Note 5	*				3
CTLI wrap test FTA (X)	4355		*	*	*			*		Note 5	*				1
MPX/BMPX adapter test	4360		*	*	*			*		Note 5	*				<1
MPX/BMPX interface test	4365		*	*	*			*		Note 6	*				<1
CA-BA adapter test	Note 2		*	*	*					Note 5					1
53FD diagnostic	5100		*	*	*										<1
SBA/service bus test	4370		*	*	*										<1
SCL IOSS/MSSS test	4385		*	*	*										<1
Loop adapter offline test	Note 3		*	*	*										<1
5424/Loop inline		*		*	*										
Ripple read punch test		*		*	*		*						*	*	2
Read punch any card test		*		*	*		*			*			*	*	2
Print feature test		*		*	*		*						*	*	2
Read adjustment test		*		*	*		*						*	*	5
Loop adapter inline	Note 3	*		*	*		*						*	*	
Adapter test		*		*	*		*						*	*	2
TAPs		*		*	*		*						*	*	5
Sense display		*		*	*		*				*		*	*	<1
Stacker select		*		*	*		*						*	*	2

This table continues on the following page.

Test Programs (continued)

Note 1: For power test description refer to the Power Manual in Volume 16.

Note 2: These tests are described in the CA Section of Volume 14.

Note 3: These tests are described in the MFCU Section of Volume 14 for 5424 in Volume 15 for the loop.

Note 4: If the functional code occupies two diskettes, the inline tests reside on the second diskette. You are prompted to change diskettes after selection of inlines.

Note 5: Run IC-bus test.

Note 6: Run IC-bus test, then the ACC/SCA (MPX/BMPX) test.

Note 7: Do not run other tests concurrent to the 'disk/tape inline' tests.

Note 8: Running time depends on environmental conditions.

Note 9: Perform IML with DIAG diskette inserted before selected this test.

TEST PROGRAMS		SETUP								TERMINATION						
Selectable from M/S PROGRAM SELECTION menu Selection offered in the selected menu V V		Control diskette Diagnostic diskette PWR complete light IML complete CE mode switch on Vary off line Jumper/plug Previous test run V V V V V V V V								Manual stop required Re-IML required Copy config progr Cancel key Vary on line Runtime (min) V V V V V V						
Disk/tape inline 3310 3370 3340 3344 8809	4400	N o t e 4		*	*		*		Note 7	*				*	N o t e 8	
CA inline Inline tests Trace/dynamic display Line exerciser	Note 2	*	*		*											
Test chaining	4325		*	*							*					

M/S Programs Handling-Overview (continued)

Tool Programs

This table shows the available tools and the summary of their handling prerequisites.

Note 1: These tools are documented in the Field Support Center Documentation.

Note 2: Refer to MAP FE90.

Note 3: These tools are described in the CA Section of Volume 14.

Note 4: Refer to the FRIEND Documentation in Volume 17.

Note 5: Not applicable for PT-CE.

TOOL PROGRAMS		SETUP								TERMINATION					
Selectable from M/S PRO-GRAM SELECTION menu		Control diskette Diagnostic diskette PWR complete light IML complete CE mode switch on Vary off line Jumper/plug Previous test run								Manual stop required Re-IML required Copy config progr Cancel key Vary on Runtime (min)					
Selection offered in the selected menu		Page reference													
V V		V V V V V V V V								V V V V V V					
Manual operations	Note 1	*	*												
PU manual operations	Note 1	*	*	*							*				
PU tool (Matrix)	Note 1		*	*											
IOC manual operations	Note 1	*	*	*											
IC-bus matrix	Note 1	*	*	*											
FTA manual operations	Note 1	*		*	*										
FTA trace loader	Note 1	*		*	*										
Utilities/remote	4500	*	*												
MES update	6190	*	*												
Remote support	4501	*	*								*				
Manual MCTF installation	4530	*	*	*	*							*			
Alter channel number	6112	*	*									*	*		
FTA configurator	6130	*	*									*	*		
BMPX configurator	6145	*	*									*	*		
HSC configurator	6143	*	*									*	*		
MCTF diskette loader	4533	*	*												
Record display	Note 1	*	*								*				
Diskette identification	4540	*	*												
Copy configurator	Note 2	*	*												
Diagnostic communication	Note 5	*	*	*	*										
TOD correction	6110	*	*												
Displays and Printers	6124	*	*	*											
Communication adapter		*	*												
Update configure table	Note 3	*	*	*	*										
UCW display		*	*	*	*										
Display trace data		*	*	*	*										
FRIEND	Note 4		*	*	*										
ST4300/OLTS	4250	*		*	*										
Others	Note 5	*	*												
Miniselect		*	*												

Log Mode Selection

Log Handling - Actions

The picture **A** appears on the screen when you select 'LOG MODE' from the 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'. This menu offers five selections which are described briefly below. For handling refer to the following pages.

- A Erase Selective Log**
Erases the reference code log of a selected unit and, if available, the detailed log of this unit. See table in right column.
- B Erase all Logs**
Erases all detailed log areas and the reference code log area.
- C Stop before Log**
This mode immediately stops the processing unit as soon as an error is detected in a selected unit. The units for which this can be applied are listed on screen.
- D Disable Channel Logs**
If this selection is entered, any logs from MPX/BMPX are suppressed to allow scoping on the standard interface or control unit. A message is displayed on line 23 as long as this mode is active.
- E Enable Channel Logs**
This selection resets selection **D**, thus allowing all logs to be recorded. This is the normal status.

Log Handling - Results

A

4331 LOG MODE SELECTION

UNIT = TYPE **K**

A 1 = ERASE SELECTIVE LOG
B 2 = ERASE ALL LOGS
C 3 = STOP BEFORE LOG
D 4 = DISABLE CHANNEL LOGS
E 5 = ENABLE CHANNEL LOGS

SELECT UNIT
SELECT UNIT

CONFIGURATION INDEX: <-- **F**

SELECTION: **H**

ACTION DONE **J**

RESTART=PF4 **G**

ANSWER

- F** This information is used as instructed by the MAP E680.
- G** After selection of **A** to **E** you may return to this picture by pressing PF 4.
- H** Enter field for selection code.
- J** This message is displayed after selection **D** or **E** is executed.

K

Unit	Mod1	Type Mod2	Mod 11	Meaning
TRAC	= 01	01	01	Pu Trace Log
IC	= 2X	3X	3X	IC-Bus
PU	= 49	4B	4B	Processing Unit
BMPX	= 80	80	80	Block Multiplexer Channel 1
BPX2	= 81	81	-	Block Multiplexer Channel 2
HSC	= 82	82	-	High Speed Channel
MPX	= 84	84	84	Multiplexer Channel
R CA-C	= 88	88	88	CA Channel Check
CA-U	= 89	89	89	CA Unit Check
IOC	= A0	A0	-	I/O Controller
BBA1	= A2	A2	-	Bus to Bus Adapter 1
Loop	= A8	A8	-	Loop Adapter
FTA 1	= C4	C4	C4	File/Tape Adapter 1
FTA 2	= C5	C5	C5	File/Tape Adapter 2
FTA 3	= C6	C6	-	File/Tape Adapter 3
IML	= E0	E0	E0	Initial Microprogram Load
R TIMR	= E1	E1	E1	Timer Check
R PUPS	= E4	E4	E4	PU Program Check Stop Log
AMBI	= E8	E8	E8	Ambient Recording
PUPR	= EA	EA	EA	PU Program Check Log
SPMC	= F0	F0	F0	SP Machine Check
BBA0	= F2	F2	F2	Bus to Bus Adapter 0
SPIL	= F5	F5	F5	SP Interpreter Log
POWR	= F7	F7	F7	Power
3278	= F9	F9	F9	Device Cluster Adapter
R LOG	= FC	FC	FC	Error during log-in

Type of log or unit which caused a log.

First two digits shown in the reference code.

Abbreviation used in the screen display.

R = Only a reference code is stored (no detailed log available).

Erase Selective Log

Log Handling - Actions

Prerequisites:

- IML
- Control diskette inserted

How to Select the Log Mode

1. Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
2. Key in selection for 'LOG MODE', press ENTER. **B**
3. Key in selection for 'ERASE SELECTIVE LOG',
press ENTER. **C**

Caution:

Whenever a non empty log area is erased the log distribution is also cleared.


How to Terminate the Log Mode

Hold down ALT key and press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

- A** 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- B** 'LOG MODE SELECTION'



- A** This area lists all units by unit name and unit type (see **K** on 4030) for which the mode ERASE SELECTIVE LOG is applicable. The unit type corresponds to the first two digits of the reference code.
An 'R' in front of the unit name indicates when there is only a reference code logged for a unit and no detailed log area is available.
- B** Enter the two-digit unit type of the log you want to erase.
- C** Enter date and time if asked to do so by message. **E**
- D** If 'LOG PENDING' is indicated in this field press 'CANCEL' key to allow the log to be recorded.
- E** If a valid TOD (time of day) cannot be fetched from the PU this message is displayed. Enter the correct value in **C**.
- F** To return to the LOG MODE SELECTION menu press PF4.

Erase All Logs

Log Handling - Actions

Prerequisites:

- IML
- Control diskette inserted

How to Select the Log Mode

1. Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **[A]**
2. Key in selection for 'LOG MODE', press ENTER. **[B]**
3. Key in selection for 'ERASE ALL LOGS', press ENTER. **[C]**
You are prompted to press PF5 **[A]** to reset all logs.
When the logs are erased the message LOG ERASE COMPLETE is displayed.

Caution:

Whenever a non empty log area is erased the log distribution is also cleared.

How to Terminate the Log Mode

Hold down ALT key and press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on screen.

Log Handling-Results

Screen displays:

- A** 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- B** 'LOG MODE SELECTION'

- C**

4331 LOG MODE SELECTION

UNIT = TYPE

1 = ERASE SELECTIVE LOG SELECT UNIT
 2 = ERASE ALL LOGS
 3 = STOP BEFORE LOG SELECT UNIT
 4 = DISABLE CHANNEL LOGS
 5 = ENABLE CHANNEL LOGS

CONFIGURATION INDEX:

TOD INVALID, ENTER DATE: MM DD HH MM
 SELECTION: 2 DATE: ../..

TO ERASE PRESS PF5 ← (A)

RESTART=PF4
 (B)

ANSWER

- (A) Pressing PF5 initiates a reset of all log areas.
- (B) To return to the LOG MODE SELECTION menu press PF4.

Stop Before Log

Log Handling - Actions

Prerequisites

- Power complete
- IML
- Control diskette installed

How to Select the Log Mode

1. Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
2. Key in the selection for 'LOG MODE', press ENTER. **B**
3. Key in the selection for 'STOP BEFORE LOG', press ENTER. **C**

Caution:

Reference code FE 630781 may appear on line 23 together with a warning message if the PU is not IMLed or if stopped.

IML for the PU is not performed if IML is executed with the diagnostic diskette inserted or if partial power down is active.

How to Set/Reset the Stop Mode

To set the mode enter the two digit unit type in **B** and press ENTER.

As result the message 'ACTION DONE' is displayed **C** and an asterisk (*) is set in front of the unit name in field **A**.

To reset the mode proceed as for setting the mode. As result the message 'ACTION DONE' is displayed and the asterisk in field **A** disappears.

Operation

Whenever a log condition occurs for a unit where the stop mode is set the system enters check stop state. In addition a message for example PU STOP LOG is displayed on line 23.

How to Terminate the Log Mode

Hold down ALT key and press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

B 'LOG MODE SELECTION'

C

4331 LOG MODE SELECTION

UNIT = TYPE

1 = ERASE SELECTIVE LOG SELECT UNIT

2 = ERASE ALL LOGS

3 = STOP BEFORE LOG SELECT UNIT

4 = DISABLE CHANNEL LOGS

5 = ENABLE CHANNEL LOGS

A

CONFIGURATION INDEX:

SELECTION: 3

ACTION DONE

C

SELECT UNIT TYPE: RESTART=PF4

B

D

ANSWER

A In this field all unit names and their unit types are shown for which the mode 'stop before log' is applicable.

Unit	Type	Unit	Type
CAC	= 88	Loop	= A8
MPX	= 84	BBA	= F2 (BBA0 and BBA1)
BMPX	= 80	PU	= 49/4B
BMPX 2	= 81	FTA1	= C4
HSC	= 82	FTA2	= C5
FTA3	= C6	IOC	= A0

- Stop before log is already active for these units.
Stop before log is only possible for the units listed.

D Press PF4 to return to the Log Mode menu selection picture.

© Copyright International Business Machines Corporation 1979, 1980, 1981, 1982
AAB4036

Reference Code Log

Log Handling - Actions

Prerequisites:

- None

How to Select the Log

1. Call M/S PROGRAM SELECTION.

Hold down ALT key and press DIAG key. **A**

2. Key in selection for 'REFERENCE CODE LOG', press ENTER. **B**

This selection causes the display LOG DISTRIBUTION STATISTIC to be displayed first. With PF5 the REFERENCE CODE LOG DISPLAY can then be called.

Caution:

Whenever a non empty log area is erased, the log distribution is also cleared.

Communication adapter unit check logs and ambient recording logs are not stored in the 'reference code log' and the 'log distribution statistic'. They can only be displayed with 'Detailed Log Display' selection.

How to Terminate the Log Display

Press ALT key and press DIAG key.
The 'IBM M/S Program Selection' is displayed on the screen.


For the following log types there is no detailed log available. Only a reference code log is stored.

CA channel check log
PU program stop log
Time log
Error during log-in


Log Handling - Results

Screen displays:

A IBM MAINTENANCE AND SERVICE PROGRAM SELECTION



- A** See picture **A** in example on next side
- B**
- C** Selection of any row in **A**
- D** Indication what row in **A** is selected.
- E** To display all logged reference codes, press PF5. You get the picture 'REFERENCE CODE LOG DISPLAY' **C**.



- F** Address of the reference code(s) logged.
- G** Name of the unit.
- H** Reference code.
- J** Additional information (Reference code extension).
- K** The count shows how often this log had occurred.
- L** Time and date of recorded log.
- M** The arrow points to the last log.

Reference Code Log


The reference code log consists of two parts:

- Log distribuion statistics (A)
- Reference code log display (B)

Log Distribution Statistics

Purpose:
Keeps track of the log history. A reference code pre-analysis is performed to offer the correct reference code for entering the MAP.

Example of Log Distribution



Detailed Log Display

Selection

The picture shown on the right appears on screen when you select 'DETAILED LOG DISPLAY' from the 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' picture. For selection and interpretation of the logs which are listed in (A), (B) and (C) of this picture, refer to the following pages.

- (A) (B) (C) Selection codes and log name
- (D) The digit in front of the log name must be typed in behind the word SELECTION to select the appropriate log. A dash (-) instead of digit indicates that the log is not available. (False diskette or wrong configuration).

DETAILED LOG DISPLAY SELECTION

(D) = LOG NAME
(A)

(D) = LOG NAME
(B)

(D) = LOG NAME
(C)

SELECTION:MAN

-- = NOT AVAILABLE

DATA : 0000

ADDR : 000000

ANSWER

Detailed Log Display (continued)

Explanation of the Common Area on Screen

Log Handling - Actions

Prerequisites:

- Control diskette inserted

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. **B**
- Key in the desired selection, press ENTER. **C**
A detailed log display falls into two parts, the common area and the area which contains information specific to the selected log.

The common area is explained here for all the following detailed log displays.

How to Terminate the Log Display

Hold down ALT key and press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

- A** IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
B DETAILED LOG DISPLAY SELECTION

C

LOG DISPLAYPAGE:

LAST ERASE DATE: **D** FIRST LOG: **C** LAST LOG: **B**

LOG COUNT: **E** LAST REF.CODE: **A**

SELECTION:

Common Area

Specific area, wick is different for the various units

Shown on the following pages

Explanation of the common area:

The information given in the common area relates only to this log type, for example: PU log, BBA log etc.

- A** The last reference code that was generated for this log type is shown on every page of the log display. Up to four bytes of additional information can be displayed together with the reference code.
- B** The time when the last reference code was logged is shown here.
- C** The time when the first reference code was logged after the last erase date is shown here.
- D** Last erase date for this log type.
- E** This shows how many logs occurred since the last erase date independent from the kind of error, i. e. different reference codes might have come up for this unit.

SP Machine Check Log Display

Log Handling - Actions

Prerequisites:

- Control or diagnostic diskette inserted.

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. **B**
- Key in selection for SP Machine Check log display,
press ENTER. **C**

How to Terminate the Log Display


Hold down ALT key and press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

B 'DETAILED LOG DISPLAY SELECTION'



- A** This reference code corresponds to the data in field. **B**
- B** Hardware data to be used in case of support.
- C** No time of occurrence is recorded for this log.

Last PU Stop Log Display

Log Handling - Actions

Prerequisites

- Control diskette inserted

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. **B**
- Key in the selection for 'Processing Unit Stop
Log', press ENTER. **C**

How to Terminate the Log Display

Hold down ALT key and press DIAG key. The 'IBM
MAINTENANCE AND SERVICE PROGRAM SELECTION'; is
displayed on screen.

Log Handling - Results

Screen displays:

A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

B 'DETAILED LOG DISPLAY SELECTION'

C

PU STOP DISPLAY

LAST ERASE DATE: _____ FIRST LOG: _____ LAST LOG: _____

LOG COUNT: _____ LAST REF.CODE: _____

ADDITIONAL REF. CODE (S)

00000000 00000000 00000000

A

NSAT CONTENT. (LAST ENTRY REPRESENTS SAT)

011D011D 011D011D 011D011D 011D011D

SELECT: S= REF. CODE SUMMARY B= BSM-ADDR-STATISTIC

P= PREVIOUS LOG(S)

D

D

PU LOG SUMMARY

REF.CODE REASON

LAST-00 4B601001 23

LAST-01 4B804001 13

4B104001 79

4B218001 87 88 **H**

LAST-11 4B930101 49 5C

LAST-12 4B104001 79

LAST-13 4B104001 79

SELECT: **E** **G** **F** ADDR.:

The recorded logs are listed in the sequence of
their occurrence. LAST-00 is the most recent one.
The highest number is the oldest log.

- E** Note that within one log more than one
reference code can be generated. **H**
- F** These are check numbers. They are the
interpretation of the four digits **G** of the
reference code for ease of maintenance.

E

BSM-ADDR-STATISTIC

+-----+ +-----+ +-----+ +-----+ +-----+

| | | | |

+-----+ +-----+ +-----+ +-----+ +-----+

J

- J** This display shows a maximum of 8 fields each 3
bytes wide. These fields indicate addresses at
which a uncorrectable error had occurred. Enter
this information in the UNCADR field of DM test
to check for defective storage cards.

- A** Hardware data for use in case of support.
- B** This field displays the 'Non-sequential PU
Instruction Address Trace' (NSAT).
- C** These are symptom codes. The first one from
left to right is included in the last reference
code in the common area.
- D** Subselection S causes a PU-LOG SUMMARY to be
displayed **D**. Subselection B causes a BSM.
ADDR-STATISTIC to be displayed **E**.
Subselection P causes a display of the previous
log (s). A maximum of 6 previous logs can be
displayed, one at a time.

PU Program Log Display

Log Handling - Actions

Prerequisites:

- Control diskette inserted

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
- Key in selection for DETAILED LOG DISPLAY,
press ENTER. **B**
- Key in the selection for 'Processing Unit Program
LOG', press ENTER. **C**

How to Terminate the Log Display

Hold down ALT key and press DIAG key. The 'IBM
MAINTENANCE AND SERVICE PROGRAM
SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

- A** 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
B 'DETAILED LOG DISPLAY SELECTION'

C

PU PROGRAM LOG DISPLAYPAGE: 0001

LAST ERASE DATE: FIRST LOG: LAST LOG:

LOG COUNT: LAST REF.CODE:

REFERENCE CODE: **A**

SEQ.NUMBER: **B** LOG COUNT: **C**

DATE: **D**

PRESS ENTER FOR NEXT LOG

SELECTION:

Common Area

Specific Area

- A** This reference code correponds to the data in field. **E**
- B** This is the sequence number of this specific ref-
erence code. **A**
- C** If one and the same reference code came up
more than once, only the count is updated. This
shows how often the same error occurred.
- D** The date when the reference code **A** occurred.

- E** Hardware data for use in case of support.

Byte	Explanation
0	Opcode
1	Length of Data - 1
2- 7	Time of Day
8-15	ID in hex of failing program module
16-17	Not used
18-19	Offset where error was detected in module
20-23	Designer dependent information

BBA 0/1 Log Display

Log Handling - Actions

Prerequisites:

- Control diskette inserted

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. [B]
- Key in the selection for 'BBA0/1 LOG', press EN-
TER. [C]
- Key in 0 or 1 according to the BBA Log you want
to see [H] (only if both, BBA0 and BBA1 are in-
stalled).

How to Terminate the Log Display

Hold down ALT key and press DIAG key. The 'IBM
MAINTENANCE AND SERVICE PROGRAM
SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

[A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

[B] 'DETAILED LOG DISPLAY SELECTION'

[C]

BBA LOG DISPLAY		PAGE:
LAST ERASE DATE:	FIRST LOG:	LAST LOG:
LOG COUNT: [K]		LAST REF CODE: XXXXXXXX [L]
REFERENCE CODE: [A]		
SEQ NUMBER: [B]	LOG COUNT: [C]	
DATE: [D]	ADAPTER: STOPPED [E]	
DEVICE ADDRESS: [F]		
LAST X ERRORS OF 000X REPORTED BY SP: XXXXXXXX XXXXXXXX XXXXXXXX XXXXXXXX [J]		
SELECTION:	SELECT BBA 00R 1: [H]	

Common Area

Specific Area

- [A] This reference code corresponds to the data displayed in field [G].
- [B] This is the sequence number of this specific reference code. [A]
- [C] If one and the same reference code came up more than once, only the count is updated. This shows how often the same error occurred. This count relates to the log dump displayed in. [G]
- [D] The date when the reference code [A] occurred.
- [E] Displays the status of the adapter e.g. STOPPED.

- [F] This shows the device address of the device with which the PU had communicated when the error occurred.
- [G] Hardware data to be used in case of support.
- [J] Up to 8 last SP detected reference codes are stored here if the SP was not able to complete a communication via BBA 0 to the PU. The left-most reference code is the most recent one.
- [K] Sum of all logged errors detected by PU and SP.
- [L] The last reference code is caused by an SP or PU detected log. If this code matches with the last recent one in [J] it is an SP detected log.

MPX/BMPX, HSC Log Display

Log Handling - Actions

Prerequisites:

- Control diskette installed

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. [B]
- Key in selection for 'MPX/BMPX LOG', press EN-
TER.
This picture offers in its lower part the appropriate
selection for MPX,BMPX, and HSC.
- Key in selection for the log to be displayed, for ex-
ample: BMPX1 [C]

How to Terminate the Log Display

Hold down ALT key and press DIAG key. The 'IBM
MAINTENANCE AND SERVICE PROGRAM
SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

[A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

[B] 'DETAILED LOG DISPLAY SELECTION'

[C]

BMPX1 LOG DISPLAY		PAGE:
LAST ERASE DATE: _____ FIRST LOG: _____ LAST LOG: _____		
LOG COUNT: _____ LAST REF.CODE: _____		
REFERENCE CODE: (A)	LOG COUNT: (C)	(H)
SEQ.NUMBER: (B)	ADAPTER: (E)	
DATE: (D)	DEVICE ADDRESS: (F)	
(K) → TIMEOUT ON DEVICE: XXX		
MAP COLUMN 2:	1 2 3 4 5 6 7	(L)
	X ↑ X	
(J) → ADD DEV. STAT.		
SELECTION: (G)		

- (A) This reference code corresponds to the data displayed in field (H) .
- (B) This is the log sequence number of the specific reference code (A) . The logs are numbered per adapter in the sequence of their occurrence.
- (C) If one and the same log came up more than once, only the count is updated. This shows how often the same error occurred.
- (D) The date when the reference code (A) occurred.
- (E) Displays the status of the adapter e.g. STOPPED.
- (F) This shows the device address of the erroneous control unit connected to the standard interface.

- (G) These seven digits are used additionally within the MAPs for further decision which FRU(s) to replace.
- (H) Hardware data to be used in case of support.
- (J) The last 32 device addresses are displayed here, four at a time.
With PF5 the next four addresses are displayed. The device address with the highest count is displayed first. The count can be from 01 to 15.
- (K) This message appears when an adapter timeout was detected. This may happen when a read is attempted on a blank tape on device XXX.
- (L) The standard interface is displayed here.

IC-Bus Log Display

Log Handling - Actions

Prerequisites:

- Control diskette inserted

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. [B]
- Key in the selection for 'IC-BUS (DM) LOG', press
ENTER. [C]

How to Terminate the Log Display

Press ALT key and hold and press 'DIAG key. The
'IBM MAINTENANCE AND SERVICE PROGRAM
SELECTION' is displayed on screen.


Log Handling - Results

Screen displays:

[A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

[B] 'DETAILED LOG DISPLAY SELECTION'

[C]



Explanation of the Specific Area:

(A) Hardware data to be used in case of support.

FTA Log Display

Log Handling - Action

Prerequisites:

- Control diskette inserted

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. A
- Key in selection for 'DETAILED LOG
DISPLAY', press ENTER. B
- Key in the selection for 'FTA LOG
DISPLAY', press ENTER. C
- Key in the IC-address of the FTA log
display wanted. D

How to Terminate the Log Display

- Press ALT key and hold and press DIAG key.
The 'IBM MAINTENANCE AND SERVICE PROGRAM
SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

- A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- B 'DETAILED LOG DISPLAY SELECTION'
- C

FTA LOG DISPLAY

LAST ERASE DATE: FIRST LOG: LAST LOG:

LOG COUNT: LAST REF.CODE

LAST DETAILED LOG

PLS SELECT FTA PHYSICAL ADDR

FTA ADDRESS.: 2 4 9 X

FTA ATTACHED.: Y Y Y N

9 = FTA-1 4 = FTA-2 2 = FTA-3

SELECTION: D

Common Area

----- FTA address

See picture D on next page.

FTA Log Display (continued)

Log Handling - Results

LV: 80267133
LAST ERASE DATE: 10/02 12:54
LOG COUNT: 000003

FTA-1 LOG DISPLAY
FIRST LOG: 10/02 13:03
LAST LOG: 10/02 13:40
LAST REF.CODE: C430F001 00000000

PAGE: 0001

REFERENCE CODE: CA 30F0 01 <-- (A)

ADPT: TRAP STOP CTL: 0004

SEQ. NO. -- S Y M P T O M S --
003 = 30F0
002 = 30F0
001 = 30F0
..... 30F0

(C) (B)

SELECTION:

2108

0...: 23020200 450E8A66 77787777 900068A0
16..: 08C20308 08C866FF 000E8A21 30000091
32..: 18DCF4A0 3002C4D2 E5E6FFFF 0001FFE5

48..: D50F90DB 1826008D 48420204 00008001
64..: 23030000 00000000 00000000 00000000

CHK.: PS0 CRG ALU PPC SPC PXC SXC SYN FCO
CNT.: 000 000 000 000 000 000 000 000 000

(D) (E)

PRESS ENTER COMP/3340 DA LOG <-- (E)

4MB VSE TIMER: ON
TOD: SEC
DATA: ADDR:

Common Log Area

Specific Log Area

- (A) This reference code corresponds to the data in the specific area.
- (B) This area shows all the symptoms which were collected for the error. The first symptom from left in the top row is included in the reference code.
- (C) This field shows the log sequence number.
- (D) This field shows 80 bytes of data. Byte 62, bit 0 = address valid bit. Byte 63 contains the address of the last used device. All other data has to be used in case of support only.
- (E) Pressing ENTER causes a second page to be displayed. This page, if not empty, displays either compatibility log or functional adapter log (3340) information. (E)

LV: 80011034
LAST ERASE DATE: 02/15 11:11
LOG COUNT: 000005

COMP FEAT/3340 DIR ATTACHM LOG DISPLAY, FTA-1
FIRST LOG: 02/15 11:13
LAST LOG: 02/15 11:15
LAST REF.CODE: C4307001 00000000

PAGE: 0002

LAST REF.CODE: C400DA01 01009180

ADDR: 0/32--- 4/36--- 8/40--- 12/44--- 16/48--- 20/52--- 24/56--- 28/60---
00-31: D6258FB9 CA932F34 FF4202FF 42010000 10000100 40010010 880961ED 00010783
32-63: 1E010000 80009180 00000000 00000000 00000000 00000000 00000000 00000000
LAST-1 REF.CODE: C400DA01 01009180
00-31: D6258FB9 CA34EEEE FF4202FF 42010000 10000100 40010010 880961ED 00010783
32-63: 1E010000 80009180 00000000 00000000 00000000 00000000 00000000 00000000
LAST-2 REF.CODE:
00-31:
32-63:
LAST-3 REF.CODE:
00-31:
32-63:

SELECTION:

2108

PRESS ENTER FOR FTA LOG

370 TIMER: ON
TOD: SEC
DATA: ADDR:

These two bytes have the same contents as byte 38, 39. They show the FSI code.

Byte 12 = DASD adapter number and channel address
13 = Device address

This display shows log data of the last four logs which have occurred. 64 data bytes are displayed for each log.

Byte	Meaning
0-11, 15	All these bytes are only used for support cases.
14	Bit 0 = 0 indicates a functional adapter log. = 1 indicates a compatibility feature log.
12, 13	See highlight in picture (E) .
16-39	Contain the sense bytes for the functional adapter log or the compatibility log. The meaning of these bytes is explained in the appropriate I/O manual (3340, 3310, 3370).
40-63	For explanation refer to the FSC documentation.

Format Zero Messages and Sense Bytes

Only format 0 is used in the 4331 processors.
The following tables show the meaning of the sense bytes 8-23 and the messages of format zero.

From page 4465

MLX
9

Format 0

Sense bytes 8-23		Messages	
Sense Byte	Meaning	Message	Meaning
0-7	Same meaning as for sense bytes in formats 1, 4, 5 and 6. See respective I/O MLM.	X'0'	No message available
		X'1'	Invalid command
		X'2'	Invalid command sequence
		X'3'	CCW count less than required
8-21	These bytes are not used. Contents is X'00'.	X'4'	Invalid argument used for command
		X'5'	
		thru	Not used
		X'C'	
22, 23	These two bytes contain the skip displacement value of a track. This applies only if a sense command is chained from a successful Read Home Address command. Bytes 22, 23 have no meaning for other operations.	X'D'	Operation attempted on defective track (see Note)
		X'E'	Multi track or overflow operation switched from alternate track
		X'F'	Not used

This page has been
intentionally left blank

EC 366345 15 Feb 80	EC 366388 23 Jan 81	EC 366493 26 Oct 81	P/N 8488380 Page 5 of 8	4 146
------------------------	------------------------	------------------------	----------------------------	-------

SPIL Program Log Display

Log Handling - Actions

Prerequisites:

- Control diskette or diagnostic diskette inserted.

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. [B]
- Key in selection for 'SPIL Program Log' display,
press ENTER. [C]

How to Terminate the Log Display

Press ALT key and hold and press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

[A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

[B] 'DETAILED LOG DISPLAY SELECTION'

[C]

SPIL CHECK LOG DISPLAY

PAGE: 0001

LAST ERASE DATE: _____ FIRST LOG: _____ LAST LOG: _____
LOG COUNT: _____ LAST REF. CODE: _____

REFERENCE CODE: (A)

SEQ. NUMBER: (B) LOG COUNT: (C)

DATE: (D)

(E)

PRESS ENTER FOR NEXT LOG

SELECTION:

Common Area

Specific Area

- (A) This reference code corresponds to the data displayed in the specific area.
- (B) This is the sequence number of this specific reference code (A).
- (C) If one and the same reference code came up more than once, only the count is updated. This shows how often the same error occurred.
- (D) The date when the reference code (A) occurred.
- (E) Hardware data to be used in case of support.

IML Log Display

Log Handling - Actions

Prerequisites:

- Control diskette or diagnostic diskette inserted.

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
- Key in selection for 'DETAILED LOG DISPLAY',
press ENTER. [B]
- Key in the selection for 'IML LOG', press ENTER.
[C]


How to Terminate the Log Display

- Press ALT key and hold and press DIAG key. The
'IBM MAINTENANCE AND SERVICE PROGRAM
SELECTION' is displayed on screen.

Log Handling - Results

Screen displays:

- [A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
[B] 'DETAILED LOG DISPLAY SELECTION'
[C]



Explanation of the specific area:

- (A) By entering 'L' the hardware data in the specific area (D) belong to the last log.
- (B) By entering 'P' the hardware data in the specific area (D) belong to the log before the last one.
- (C) By entering 'M' the hardware data in the specific area (D) belong to the most frequent log.
- (D) Hardware data for use in case of support.

Last Detailed Log Display

Log Handling - Actions

Prerequisites:

- Control diskette or Diagnostic diskette inserted (see Note).

How to Select the Log

- Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
- Key in selection for 'LAST LOG DISPLAY', press ENTER. [B]

How to Terminate the Log Display

- Press ALT key and hold press DIAG key. The 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is displayed on the screen.

Note: On the diagnostic diskette alog is recorded only for Power, SP machine check, SPIL program, and IML.

Log Handling - Results

Screen displays:

- [A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- [B] The picture now displayed on screen is showing the last detailed log that occurred.

ATTENTION!
When you select the LAST LOG DISPLAY and you get '2**' displayed, it indicates that the last log that had occurred has been erased before.

If the last log was a reference code log with no detailed log area, the LOG DISTRIBUTION STATISTICS are displayed.

Communication adapter (CA) unit check logs and ambient recording logs cannot be displayed with last log selection.

Integrated Reference Code Analysis (IRECA)

Purpose

The Integrated Reference Code Analysis program will assist the 4331 CE on his way through the MAPs. It will minimize the time required to determine the failing FRU. It also allows immediate and simple update of the decision tables.

Restrictions

The IRECA program analyses only reference codes which lead to the analysis result without the need for manual intervention, for example: it is not possible to respond to questions. It also requires a functional 4331 Support Processor for execution. Reference Codes other than the Last Log reference code must be typed in manually.

- Warning:
- Results may be wrong if the reference code or symptom code is entered incompletely, or if the refcode entered was not generated by this machine.
 - In case of multiple SYMPTOM Codes enter only one at a time together with the refcode.

Screen Layout

The 20 basic lines of the screen display are arranged as follows:

T I T L E		
(A)	INPUT AREA	MAP TYPE
(B)	PREREQUISITE INSTRUCTIONS	FRU (C) DISPLAY AREA
(D)	VERIFICATION INSTRUCTIONS	
(E)	HANDLING MESSAGES	
(F)	SELECTION MENU	

- (A) This field shows the title of the selection, the MAP number and FIX number, and two input fields for the reference code and symptom code if available.

- (B) This field informs you about the necessary prerequisites. For example: logs which should be inspected first or tests which should run first. Instructions in this field must be executed before any FRU is replaced.
- (C) This field lists all suspected FRUs in their sequence of priority. Only 10 FRUs can be displayed in one frame. Press ENTER to display the next frame. All input fields are locked in this case until all FRUs have been displayed. Only the FRUs which are physically installed in this machine are displayed.
- (D) This field tells you how to proceed after FRU replacement. If not otherwise instructed go to the Exit MAP 0001.
- (E) This field may display additional messages.
- (F) This field lists the PF-selections available for this screen.

Example of an IRECA Display

INTEGRATED REFERENCE CODE ANALYSIS	
REFERENCE CODE: F2028001	(SYMPTOM CODE):
*** PREREQUISITE INSTRUCTIONS: ***	MAP: F200 FIX: 1004
CHECK TOP CONNECTORS OF SUPECTED FRUS. BEFORE FRU REPLACEMENT GO TO ENTRY POINT B of MAP F200.	SUSPECT:...
*** VERIFICATION INSTRUCTIONS ***	1. CARD 01A-A2T2 2. CARD 01A-C2D2 3. CARD 01A-C2E2 4. CARD 01A-C2F2 5. CARD 01A-C2G2 6. CARD 01A-C2H2 7. CARD 01A-C2J2 8. CARD 01A-C2C2 9. CARD 01A-C2B4 10. CARD 01A-A2R2
(A) -->MORE... (PRESS ENTER)	====> CHECK THE INFO-BOX <====
PF1 = IRECA PF2 = INFOBOX PF3 = REF-UPDATE PF4 = FRU-UPDATE PF5 = MSG-UPDATE	
MAN 4MB VSE TIMER: ON DATA: 0000 ADDR: 000000	
A00C	

- (A) MORE... = Indicates that not all suspected FRU's are displayed. Press Enter to display next screen with the remaining FRU's.

Integrated Reference Code Analysis (continued)

Prerequisites

1. IML must be completed, if not, perform IML with the control diskette (FU1) or diagnostic diskette 1 (DD1) inserted.
2. Insert the diagnostic diskette which contains the IRECA program. This is diskette DD1 for Model 1 and DD2 for Model 2.

How to Select IRECA

1. Call the 4331 MAINTENANCE/SERVICE PROGRAM SELECTION. Select REFCODE ANALYSIS.
Read the handling instruction displayed, then press ENTER to get the basic IRECA display. This display shows in the bottom line the selection menu for the IRECA program. The selections are assigned to PF-keys as follows:

PF1 = IRECA PF2 = INFOBOX
PF3 = REF UPDATE PF4 = FRU UPDATE
PF5 = MSG UPDATE
2. If the message:
CHECK THE INFO-BOX
appears press PF2 and read the information in the info-box. It might be important for this repair action. Return to IRECA via PF1.
3. Type in the reference code and - if required - the symptom code as received from log, test, or MAP. If there is more than one SYMPTOM Code, enter only one at a time together with the reference code.
4. Press ENTER.
Note: If a last log was stored since the last IML steps 3 and 4 are executed automatically after step 1.
5. Follow the instructions displayed under PREREQUISITE INSTRUCTIONS.
6. Replace the FRUs in the listed sequence (1..n). If more than 10 FRUs are in the SUSPECT list the message MORE ... is displayed. Press ENTER to continue the FRU display. In this case all input fields are locked until all FRUs are displayed.
7. Follow the VERIFICATION INSTRUCTIONS or return to the EXIT MAP 0001 if not told otherwise.
8. Note down your activities in the INFO-BOX.

Selection Menu

The PF-keys listed in the bottom line allow you to select another IRECA function. No further selections are available for this display.

Messages

Message	Reason
THIS REFERENCE CODE IS UNKNOWN. PLEASE CHECK YOUR INPUT!	This reference code is unknown to the IRECA program. Check for typing errors. If input was correct invoke your support structure.
THIS SYMPTOM CODE IS UNKNOWN. PLEASE CHECK YOUR INPUT!	This symptom code is unknown to the IRECA program. Check for typing errors or missing input. If input was correct invoke your support structure.
===> CHECK THE INFO-BOX <===	There is at least one letter in the INFO-BOX. Press PF2 to display the letters.
MORE... (PRESS ENTER)	There are more FRUs to be displayed. Press ENTER to scroll.
*** FEATURE NOT INSTALLED ***	This reference code is known but the hardware is not installed in this machine. Check for correct diskette, the diskette used for IML is not correctly configured. Refer to MAP FE90.
*** DISKETTE ERROR ***	An unrecoverable diskette error was detected. Try again with another diskette. If error persists use the 53FD diagnostics for problem analysis.

IRECA - Info Box Selection

Screen Layout

Example of an Info Box Letter

```

                INTEGRATED REFERENCE CODE ANALYSIS
                *** INFO-BOX ***

        THIS IS NUMBER 01 OF 04 LETTERS IN THE INFO-BOX.

        IT IS FROM C.BROWN..... DATED 11/07/80 FOR REFERENCE CODE F2028001.

        <==> THE ERROR IS HIGHLY INTERMITTENT! TODAY I REPLACED FRUS 1
              THROUGH 5. IF ERROR PERSISTS CHANGE NEXT 5.

                                   <===

PF1 = IRECA  PF2 = INFOBOX      PF6 = WRITE A LETTER  PF7 = ERASE THIS LETTER
```

Purpose

The INFO-BOX is intended to serve the CE as a reminder stored on the diskette. Its main usage will be on intermittent errors or deferred maintenance when it is necessary to leave information for the same or another CE on a particular problem. The info box can hold up to ten letters.

How to Call the Info-Box

- 1. Select REFCODE ANALYSIS from the MAINTENANCE AND SERVICE PROGRAM selection menu.
- 2. Press PF2 key to select INFO BOX
- 3. After selection the first (oldest) letter is automatically displayed. Pressing the ENTER key will scroll the display to the next letter. When no more letters are stored the display will wrap back to the first letter.

Selection Menu

The selection menu is displayed in the bottom line. Two additional subselections and a scroll function are available for this selection.

- PF6 = Write a letter
- PF7 = Erase this letter
- ENTER = scroll to next letter

How to Write a Letter

Press PF6 to write a letter. The program will unprotect the input area (224 characters) between the symbols <==> and <===. Any text may now be written. The letter will be stored by pressing the ENTER key. Then the program switches back immediately to display mode.

How to Erase a Letter

Display the letter to be erased. Press PF7 to erase this letter. The remaining letters will automatically close the gap and the freed space is now available for a new letter. Then the program switches back to display mode.

Messages

Message	Reason
** THE INFO-BOX IS FULL, ERASE A LETTER BEFORE YOU WRITE A NEW ONE **	Press ENTER until the letter is displayed you want to erase. Press PF7 to erase the letter.
THE LETTER IS STORED	Prompting message
THE LETTER IS ERASED	Prompting message

IRECA Update - Introduction

Three selections are available to call the update program for the Reference Code-, the FRU-, and the Message-Table of the IRECA program.

Each selection has its own subselection menu. This menu can be selected by entering a question sign (?).

When an update program is selected the first screen displayed shows subselection D = Display as default in the SELECT MODE field.

An update would require the entering of A as select mode followed by ENTER, see also the individual descriptions.

The erase selections allow only to erase manually entered updates. It is not possible to erase basic entries of the IRECA program. To erase an update the respective reference code, the FRU - number or the message number must be entered followed by pressing ENTER.

IRECA - Reference Code Update Selection

Screen Layout

Example of a Refcode Update Input

REFERENCE CODE UPDATE FUNCTION

REFERENCE CODE: F2028001(SYMPTOM CODE):

MAP BLOCK NUMBER: F200FIX: 1005

FIX MESSAGES: P017 PNEXT P019 OMAP V018 M0001

FRU NUMBERS: 014 015 016 017 038 042 182 183 210 211 ...

.....

.....

SELECT MODE: D? = MENUKEY:

PF1 = IRECA PF2 = INFOBOX PF3 = REF-UPDATE PF4 = FRU-UPDATE PF5 = MSG-UPDATE

Purpose

The REFERENCE CODE UPDATE function allows to delete, alter, or add reference code and/or symptom code definitions together with their message and FRU assignment. All updates are developed by Engineering and distributed via the support structure. They are protected against accidental misuse and typing errors by a key given in the update instruction.

The update information in the data bank may be accessible from the 4331 and stored onto the DD1 or DD2 diskette by using the REMOTE SUPPORT FACILITY (RSF). Once it has been stored on the diagnostic diskette it can be retrieved and used to update the reference code and/or symptom code tables by using the REF-CODE FIX DISPLAY program.

How to Call the Refcode Update Program

1. Call the MAINTENANCE AND SERVICE PROGRAM SELECTION and select REFCODE ANALYSIS, press ENTER.
2. Press PF3 Key to select REF-UPDATE.
After selection the REFERENCE CODE UPDATE FUNCTION screen appears with the default selection D for DISPLAY REFCODE UPDATE in the selection field.

Selection Menu

There are four subselections available. The selection menu can be displayed by entering a '?' behind SELECT MODE. The available selections are:

- A = ALTER A REFERENCE CODE
- D = DISPLAY REFERENCE CODE UPDATES
- E = ERASE ONE SELECTED UPDATE
- F = ERASE ALL UPDATES

The REFCODE UPDATE menu is displayed whenever an invalid selection was done.

How to Enter a Refcode Update

- 1. Enter subselection 'A' for ALTER and press ENTER.
- 2. Type in the variables as received from the support function.
IMPORTANT: Type in the 4-digit key. This key will not be displayed.
- 3. Press ENTER to store the variables. The update is available now.

How to Update via RSF

Refer to page 4516 'Temporary Storage and Display of Data Bank Information', and page 4517 'How to Install a IRECA Update or MCTF Received from the Data Bank'.

Messages

Message	Reason
ENTER REF.CODE (AND SYMPTOM CODE)..	Subselection D entered for DISPLAY. Enter info to display the wanted update. Default: displays all updates.
	Subselection E entered for ERASE. Enter info for the update to be erased. No default available.
ALTER NOW...	Subselection A entered for ALTER. Key in the complete update received from the support function.

** INCORRECT KEY **	There is a typing error.
** PARAMETER MISSING OR INVALID **	- MAP, or FIX missing. - FIX not numeric. - Wrong message parameter. (Cursor points to the beginning of the incorrect field.)
** INVALID NUMBER (NOT 0..254) **	Wrong FRU number. (Cursor points to the beginning of the incorrect field.)
** INVALID REFERENCE/SYMPTOM CODE **	- Refcode missing. - Refcode/symptom not hex or characters other than . X or blank.
** UPDATE AREA OVERFLOW **	Get diskette with higher level.
** DISKETTE ERROR **	An unrecoverable diskette error was detected. Try again with another diskette. If the error persists use the 53FD diagnostics for problem analysis.
** UPDATE NOT FOUND **	May occur during DISPLAY or ERASE.
** UPDATE COMPLETED **	The update was correctly stored.
UPDATE IN PROCESS...	Wait for completion.
** SORRY, NO UPDATE STORED **	In response to selection DISPLAY.
** ALL UPDATES DISPLAYED **	End of the updates was reached.
** UPDATE ERASE COMPLETED **	After ERASE or ERASE all.
==> TO ERASE PRESS PF9 <==	Prompting stop.

IRECA - FRU Update Selection

Screen Layout

Example of a FRU Update Input

FRU UPDATE FUNCTION

(handling instructions)

FRU NUMBER: 093

FEATURE 1: 2C8080 TYPE: CARD. LOCATION: A C2M2.. (FROM) (TO)

===== ONLY IF EXCLUSIVE FEATURES: =====

FEATURE 1: 2C4040 TYPE: CARD. LOCATION: A C2M2..

FEATURE 1: 2C2020 TYPE: CARD. LOCATION: A C2M2..

SELECT MODE: D ? = MENU KEY:

PF1 = IRECA PF2 = INFOBOX PF3 = REF-UPDATE PF4 = FRU-UPDATE PF5 = MSG-UPDATE

Purpose

The FRU UPDATE FUNCTION provides facilities to add, delete, and alter any FRU definition. All updates are developed by Engineering and distributed via the support structure. They are protected against accidental misuse and typing errors by a key given in the update instruction.

The update information in the data bank may be accessible from the 4331 and stored onto the DD1 or DD2 diskette by using the REMOTE SUPPORT FACILITY (RSF). Once it has been stored on a diagnostic diskette of your system, it can be retrieved and used to update the FRU tables by using the REF-CODE FIX DISPLAY program.

How to Call the FRU Update Program

1. Select REFCODE ANALYSIS from the MAINTENANCE AND SERVICE PROGRAM selection menu.
2. Press PF4 key to select FRU-UPDATE.
After selection the FRU UPDATE FUNCTION screen appears with the default selection D for DISPLAY FRU-UPDATE in the selection field.

Selection Menu

There are five subselections available. The selection menu can be displayed by entering a '?' behind SELECT MODE.
The available selections are:

- A = ALTER A FRU
- C = DISPLAY ALL FRU ENTRIES
- D = DISPLAY FRU UPDATES
- E = ERASE ONE SELECTED UPDATE
- F = ERASE ALL UPDATES

The FRU UPDATE menu is displayed whenever an invalid selection was done.

How to Enter a FRU Update

1. Enter subselection 'A' for ALTER and press ENTER.
2. Type in the variables as received from the support function.
IMPORTANT: Type in the 4-digit key. This key will not be displayed.
3. Press ENTER to store the variables. The update is available now.

How to Update via RSF

Refer to page 4516 'Temporary Storage and Display of Data Bank Information' and page 4517 'How to Install a MCTF or IRECA Update Received from the Data Bank'.

Messages

Messages	Reason
** ENTER THE WANTED FRU NUMBER **	Subselection D entered for DISPLAY. Enter FRU number to display the correct update. Default: Display all updates. Subselection E entered for ERASE. Enter FRU number for the update to be deleted. No default.
ALTER NOW...	Subselection A entered for ALTER. Key in the complete update received from the support function.
** INCORRECT KEY **	There is a typing error.
** PARAMETER MISSING OR INVALID **	- Update incomplete - Non hex in feature field - Invalid type - Invalid location (Cursor points to beginning of the incorrect field.)
** INVALID NUMBER (NOT 0..254) **	Wrong FRU number. (Cursor points to beginning of the incorrect field.)
** UPDATE AREA OVERFLOW **	Get diskette with higher level.
** DISKETTE ERROR **	An unrecoverable diskette error was detected. Try again with another diskette. If the error persists use the 53FD diagnostics for problem analysis.
** SELECTED UPDATE NOT FOUND **	May occur in response to selection DISPLAY or ERASE.
** UPDATE COMPLETED **	The update was correctly stored.
UPDATE IN PROCESS...	Wait for completion.
** SORRY, NO UPDATE STORED **	In response to selection DISPLAY.
** ALL UPDATES DISPLAYED **	End of the updates was reached.
** UPDATE ERASE COMPLETED **	After ERASE or ERASE ALL.
==> TO ERASE PRESS PF9 <==	Prompting stop.

© Copyright International Business Machines Corporation 1981

STM

EC 366390 10 Apr 81	EC 366493 26 Oct 81	P/N 5683365 Page 7 of 10	4 206 F
------------------------	------------------------	-----------------------------	---------

IRECA - Message Update Selection

Screen Layout

Example for a Message Update Input

```

MESSAGE UPDATE FUNCTION

MESSAGE NUMBER: 047      TEXT: CHECK: READ OPERATION ATTEMPTED
                           ON A BLANK TAPE. ....
                           .....

                           ALTER NOW ...

SELECT MODE: A          ? = MENU                                KEY:

PF1 = IRECA  PF2 = INFOBOX  PF3 = REF-UPDATE  PF4 = FRU-UPDATE  PF5 = MSG-UPDATE

```

Purpose

The MESSAGE UPDATE FUNCTION will add, delete, or alter any message(s) to be displayed, either in the PREREQUISITE INSTRUCTIONS or the VERIFICATION INSTRUCTIONS areas. All updates are developed by Engineering and distributed via the support structure. They are protected against accidental misuse and typing errors by a key given in the update instruction.

The update information in the data bank may be accessible from the 4331 and stored onto the DD1 or DD2 diskette by using the REMOTE SUPPORT FACILITY (RSF). Once it has been stored on a diagnostic diskette of your system, it can be retrieved and used to update the message tables by using the REF-CODE FIX DISPLAY program.

How to Call the Message Update Program

1. Select REFCODE ANALYSIS from the MAINTENANCE AND SERVICE PROGRAM selection menu.
2. Press PF5 key to select MSG-UPDATE.
After selection the MESSAGE UPDATE FUNCTION screen appears with the default selection D for DISPLAY MESSAGE UPDATES in the selection field.

Selection Menu

There are four subselections available. The available selections are:

- A = ALTER A MESSAGE
D = DISPLAY MSG UPDATES
E = ERASE ONE SELECTED UPDATE
F = ERASE ALL UPDATES

The FRU UPDATE menu is displayed whenever a invalid selection was done.

How to Enter a Message Update

1. Enter subselection 'A' for ALTER, press ENTER.
2. Type in the update data as received from the support function.
IMPORTANT: Type in the 4-digit key. This key will not be displayed.
3. Press ENTER to store the update. The update is available now.

How to Update via RSF

Refer to page 4516 'Temporary Storage and Display of Data Bank Information' and page 4517 'How to Install a MCTF or IRECA Update Received from the Data Bank'.

IRECA - Message Update Selection (continued)

Messages

Message	Reason
** ENTER THE WANTED MESSAGE NUMBER **	Subselection D entered for DISPLAY. Enter the number of the message you want to display. If no num- ber is entered all updates are displayed starting with the first one entered. Subselection E entered for ERASE. Enter the number to be erased.
ALTER NOW...	ALTER mode selected. Input fields are now unprotec- ted to accept update data.
** INCORRECT KEY **	Typing error.
** PARAMETER MISSING OR INVALID **	Message missing.
** INVALID NUMBER (NOT 0..127) **	Wrong message number (Cursor points to begin of field).
** UPDATE AREA OVERFLOW **	Get diskette with higher level.
** DISKETTE ERROR **	An unrecoverable diskette error was detected. Try again with another diskette. If the error persists use the 53FD diagnostics for problem analysis.
** SELECTED UPDATE NOT FOUND **	May occur in response to selection DISPLAY or ERASE.
** UPDATE COMPLETED **	The update was correctly stored.
UPDATE IN PROCESS...	Wait for completion..
** SORRY, NO UPDATE STORED **	In response to selection DISPLAY.
** ALL UPDATES DISPLAYED **	End of the updates was reached.
** UPDATE ERASE COMPLETED **	After ERASE or ERASE ALL.
=> TO ERASE PRESS PF9 <==	Prompting stop.

This page has been
intentionally left blank

System Test 4300 (ST4300) and OLTSEP

Introduction for ST4300

The ST4300 is a stand-alone test to be used as system test on 4300 Processors. The ST4300 is basically an ST-370 with enhancements to cover especially the 4300 Processor with 0.5 MB. The main purpose is to test the interface and the interaction of the attached devices.

For US only the ST4300 has to be ordered through the DOC (Diagnostic Order Calculator) and is supplied by the PID (Program Information Department). For WT follow local ordering procedure. It is written either on tape or disk along with other diagnostic programs (OLTs). Starting with EC 366453 (Mod-1/2) the ST4300 is also available on a separate diskette - the System Test Diskette (labelled 'Diag 5'). The ST370 User's Guide (D99-0370A) supplied with the ST4300 is still valid but the deviations described here for handling and supported devices, must be obeyed.

Enhancements of the ST4300 via ST-370

- 3278 and 3287 will configure and be tested as a 3270.
- 3310, 3340 natively attached, 3370, and 8809 will configure and be tested.
- The 4331 customer diskette will configure and be tested as 3540.
- The 4331 CA lines will only be configured by the ST4300.
- The loop attached devices will only be configured (if powered up). Neither the adapter nor the devices are tested by the ST4300.
- The ST4300 is also capable to test 3310/3370 disks in 23XX or 33XX emulation mode, but it requires that the disks are initialized by the customer as 'count-key-data' devices. The test can also be applied if the disk device is used in mixed mode. For example: One 2314 volume on a 3310 disk and the remaining part in FBA mode. Obey the limitations for the ST4300 diskette version described at the end of this subject.
- Any emulated CKD-disk (minidisk) can not be tested. The corresponding device address should be dropped.

How to Load the ST4300

Loading from Diskette

1. Make all devices to be tested 'ready'.
2. If the system is not running, perform IML from the control diskette 1 (FU 1). After IML complete the PROGRAM LOAD picture appears on the screen, proceed with step 4.

3. If the system is running, check that you are in the correct mode to run ST4300:
Call MODE SELECT picture, enter L, press ENTER. This selection displays the PROGRAM LOAD picture with the input from the previous load operation.

4. Check and if necessary correct the following specifications:

- PROGRAM RESET = CLEAR (C)
- MACHINE MODE = 370 (3)
- STORAGE SIZE = REAL (R)
- 1052 MODE = specify one of the following:

PRINT (P) - Printer Keyboard Mode (see Note below).
Verify that the hardcopy device is 'ready'. If no hardcopy device is available or if it is used for other than console message printing specify:

NO PRINT (N) - Printer Keyboard Mode (see Note below).
The 1052 mode will then use the screen as the only means for message output.

OFF (F) - 3270 Operation Mode

Note: If you are in 1052 mode (Printer Keyboard Mode) the keyboard is normally locked. It is freed by an read inquiry command which is invoked by pressing the REQ key. Any message can now be entered followed by pressing ENTER.

- NUMBER OF 3340 BUFFERS = 1
Only necessary if 3340/44 is directly attached at the FTA, otherwise leave field empty.
- NUMBER OF EMU BUFFERS = 1
Only necessary if the compatibility feature is installed, otherwise leave field empty.

Note on Number of Buffers: If necessary only one buffer should be specified to save MS-space. If MS-size available is too small (especially on 0.5 MB machines) ST4300 cannot be loaded. This results in the following message: INSERT CONTROL DISKETTE, PRESS MODE SELECT, DO CLEAR RESET AND TRY AGAIN, INVALID MSD ENTRY. To follow this message would force you in a permanent loop.

- Leave all other specifications unchanged. Verify that the load device specified by CHANNEL - CONTROL UNIT - DEVICE is ready, press ENTER.

System Test 4300 (ST4300) and OLTSEP (continued)

Loading from Diskette (continued)

- Call MODE SELECTION picture, select CLEAR RESET (C), press ENTER. Wait until RESET COMPLETE appears on screen.
- Call M/S PROGRAM SELECTION.
- Select ST4300 (E), press ENTER. The display LOADER FOR SYSTEM AND I/O TESTS appears on screen.
- Execute steps indicated on screen:
 - Insert diskette with system and I/O tests (diskette is labelled DIAG5)
 - Type in 'S', press ENTER.

The load process is indicated by the message:

- LOAD IN PROCESS
 - VERIFY IN PROCESS
 - LOAD DONE
- Execute steps 4 to 7 indicated on the screen:
 - Insert functional diskette (FU 1).
 - Select customer manual operations, press MODE SEL.
 - Do PROGRAM RESET, wait until RESET COMPLETE appears on screen.
 - Do RESTART.
 - After the restart is executed the processor enters wait state X'FF01'. This and the following wait states can be displayed on the screen in the data field of line 21 if you press the STOP key. To proceed press the START key.
 - Continue with step 10 of the 'Loading from Tape' description.

Loading from Tape

- Make all devices to be tested 'ready'.
- Mount the ST4300/OLTSEP tape (file protected) and make loader device 'ready'.
- Perform steps 3 and 4 of the 'Loading from Diskette' description. Then proceed here.
- When the PROGRAM LOAD picture disappears from screen, press STOP key at the console keyboard.
- Rewind the ST4300/OLTSEP tape to the load point and make the device 'ready' again.
- Call MODE SELECTION picture, type in DM84, press ENTER. Alter MS-locations 84 and 85 to X'4300', press ENTER.

- Call MODE SELECTION picture again, select PROGRAM LOAD (L).
- Alter reset field to PROGRAM (P). Leave all other specifications unchanged, press ENTER.
- After IPL is executed the processor enters wait state X'FF01'. For how to display wait state, see step 10 of ' Loading from Diskette'.
- Force an interrupt on the message output device (press STOP/START on the printer). A 3287 console printer cannot be used as message output device. The operator console (3278-2A or 3279-2C) can only be used as message output device, if in 1052 mode. If a 3278-02 is the message output device, the instruction printout stops when the screen is full. To continue press ENTER on the output device keyboard. This interrupt forces an instruction printout on the just assigned output device. Read these instructions carefully before you continue testing. Read all references to the ST370 as ST4300. To stop or bypass the instruction printout read the messages in the instruction printout. Note: If the output device specified is a line printer wrong characters are printed if the UCS buffer has not been loaded with the correct chain image. reload the UCS buffer. This however is only possible at or after wait state 'FF04'. Load the UCS buffer by entering:

UCS CUU TT

where CUU = printer address, for example 02E
 TT = chain image code (depending on printer type), see table.

Printer	TT Value
1403	AN, RN, PN, HN, YN, SN, TN, QN, XN, PH (PCS-HN), PA (PCS-AN), QC (QNC), OD (ODA), ON (ONA)
3203	PCSAN, PCSHN, AN2, HN2, PN2, QN2, RN2, SN2, TN2, QNC, XN2, ODA, YN2
3211	AE (A11), GE (G11), HE (H11), PE (P11), TE (T11)
3262	48C, 52C, 63C, 64C, 96C, 116C, 128C
3289	48C, 64C, 96C, 116C, 128C

Loading from Tape (continued)

Printout Example

ST4300 . RELEASE 12.0
ASM DATE=01/13/81, TIME=09.59
MODEL 4331,SER 20367,856K

EXTD FL PT,MVM INST,DECML
FETCH AND STORE PRT,TMR,370 INST,TOD
MONITOR CALL,CPU TIMER,EC,DAT

TO BYPASS INSTRUCTION PRINTOUT ENTER -BYPASS- NOW

TO STOP INSTRUCTION PRINTOUT PRESS EXTERNAL INTERRUPT
NOTE ENTERING ONLY 1ST LETTER OF MESSAGES IS NO LONGER VALID

11. When the printout is finished the processor enters wait state X'FF02'. This is indicated at the end of the instruction printout together with the message INTERRUPT FROM INPUT DEVICE, WAIT FOR READY MSG. TO PROCEED ENTER GO. The interrupt has to be given by pressing ENTER if in 3270 Mode or the REQ key if in 1052 Mode. In response READY is displayed on the screen. Respond with typing in GO and press ENTER.
12. The message PRECONFIGURATION STARTED is printed and after a short delay all available I/O addresses are printed out, and the processor enters wait state X'FF03'.

Preconfiguration Printout

TABLE OF I/O ADDRESSES TO BE CONFIGURED ON THIS SYSTEM						
011	015	017	01E	02D	02E	200
220	221	230	231	232	233	240
241	243	300				

ENTER DROP CUU OR CNFG MESSAGE NOW.
WAIT CODE FF03.

CNFG
CONFIGURATION STARTED

ENTERED

13. Any unit can be left unconfigured by the DROP CUU message (or DROP CUU CUU or DROP CUU-CUU or multiple combinations). After READY the DROP message prints another table of I/O addresses for a further check. When configuration is proper, type in the message CNFG (all four letters, not just C). The unit availability table (UAT) is then printed and the next wait state is entered (FF04).

Configured Devices

UNIT AVAILABILITY TABLE				
UNIT TYPE	UNIT CLASS	ADDRESS CUU	TEST LEVEL	FEATURES
3270	GD	000011	0	
3270	GD	000015	0	
3270	GD	000017	0	
3270	GD	00001F	*	INPUT DEV.
2540	PU	00002D	0	COL BIN
1403	PR	00002E	0	132 POS
3340	DS	000200	0	VOL ID CEPACK MOD 35
3370	DS	000220	0	MODEL 00
3370	DS	000221	0	MODEL 00
3370	DS	000230	0	MODEL 00
3370	DS	000231	0	MODEL 00
3370	DS	000232	0	MODEL 00
3370	DS	000233	0	MODEL 00
3310	DS	000240	0	MODEL 00
3310	DS	000241	0	MODEL 00
3310	DS	000243	0	MODEL 00
8809	TP	000300	0	MOD 0,9 TRK

CONFIGURATION COMPLETE
TEST LEVEL * INDICATES DEVICE NOT TESTED
WAIT CODE FF04

TO PROCEED ENTER GO

14. If the configuration is correct, the operator responds to message 'TO PROCEED PRESS INTERRUPT OR TYPE GO'. Relevant I/O tests are loaded followed by the ST4300 Test Control Program. ST4300 is now ready to perform its main function, as printed in a three-line message. Wait state (FF05) is entered, and the following messages or options (also indicated on the machine instruction printout) should be considered:
- Various assign messages (input, output, retain, and set clock).
 - Vary test level (see ST4300 Test Levels).
 - Enter run options.
 - Other messages (write CUU, print, and tapemark CUU).

System Test 4300 (ST4300) and OLTSEP (continued)

15. When no further action is required on the preceding messages the operator must press the console INTERRUPT or type GO. System test responds with RUN STARTED, and runs the various tests. Display screens will show ST4300 running via a timer (elapsed time).

Note: For a more detailed explanation of ST4300, see ST370 User's Guide, D99-0370A.

Log Report

This is an example of a possible printout at test end.

REPORT 04 0002 MIN, 55 SEC									
CLOCK 68/144/03/46/05									
BLOCKS OPERATED FAILED									
CPU									
FIXED PT	000999	000000							
FLOAT PT	000998	000000							
DECIMAL	000998	000000							
SP TEST	000998	000000							
MVM TEST	000998	000000							
I/O 001055 000028									
I/O UNITS BLOCKS ACUM NOT TEST									
ADDRESS	CLAS	OPER	FAIL	STAT	RDY	RDY	LEVEL		
000011	GD	0038	0028	0E00			0	CE, DE, UCK	
000015	GD	0040	0000				0		
000017	GD	0039	0000				0		
00001F	GD	0000	0000				*		
00002D	PU	0053	0000				0		
00002E	PR	0431	0000				0		
000200	DS	0272	0000				0		
000220	DS	0018	0000				0		
000221	DS	0018	0000				0		
000230	DS	0018	0000				0		
000231	DS	0018	0000				0		
000232	DS	0018	0000				0		
000233	DS	0018	0000				0		
000240	DS	0018	0000				0		
000241	DS	0018	0000				0		
000243	DS	0018	0000				0		
000300	TP	0020	0000				1		
TEST LEVEL * INDICATES DEVICE NOT TESTED									

Devices Supported by the ST4300 Diskette Version

The diskette version of ST4300 does not support all devices that the tape version does. Following is a list of all devices supported by the diskette version.

Direct Access Storage Unit

2311, 2314, 2321, 3310, 3330, 3340, 3344, 3350, 3370, 3375, 3380, 3540.

Display

3270, 3274

Banking Machine

1419, 3890

Printer

1403, 1443, 3203, 3211, 3262, 3289, 3800.

Reader/Punch

1442, 2520, 2540

Reader

2501, 3505

Punch

3525

Communication Controller

3705

Magnetic Tape Unit

2400, 2415, 2420, 3410, 3420, 8809

Keyboard

3200

Encoder

3848

Introduction to OLTSEP/OLTs

OLTSEP/OLTs

An OLT is a test written for a specific type of I/O device. Most OLTs are able to run in concurrent mode (OLTEP), but some must be executed under a stand-alone control program (OLTSEP). These are called Central Mode OLTs. Each device is usually supported by a series of OLTs, which contain a complete test for the device. Some devices mainly older OCR and MICR devices require time-dependent testing for complete testing. Others such as two-channel switches may require precise control of the channels for certain tests. Devices with such requirements usually include some central mode OLTs in the devices OLTs package. These tests should be run under ST4300 and require the customer to give you the system.

OLTEP

OLTEP is a series of programs, one version for each Operating System with OLTEP support. Each OLTEP program supplies a link between the device tool (or OLT) and the Operating System chosen by the customer.

How to Load the OLTSEP/OLT s

Loading from Tape

Proceed according to OLTSEP User's Guide Form No. D99-SEPEC-03.

Loading from Diskette

- 1. Make all devices to be tested 'ready'.
- 2. If the system is not running, perform IML from Control diskette 1 (FU 1). After IML complete the Program Load picture appears on screen.
- 3. Call MODE SELECTION picture, select CLEAR RESET (C), press ENTER. Wait until RESET COMPLETE appears on screen.
- 4. Call M/S PROGRAM SELECTION.
- 5. Select ST4300 (E), press ENTER. The display LOADER FOR SYSTEM AND I/O TESTS appears on screen.
- 6. Execute steps indicated on screen:

Insert diskette with system and I/O tests (diskette is labelled DIAG5).
Type in 'TXXXX' (XXXX = device type), press ENTER.
The load process is indicated by the message:
LOAD IN PROCESS
VERIFY IN PROCESS
LOAD DONE

- 7. Execute steps 4 to 7 indicated on the screen:
Insert functional diskette (FU 1)
Select customer MANOPS, press MOD SEL.
Do PROGRAM RESET, wait until RESET COMPLETE appears on screen.
Do RESTART
- 8. Press ENTER.
- 9. OLTSEP is now functional. If your printer has the address 00E the following message is displayed:
04 SEP188D ENTER DATE (AND TIME) - 'MM/DD/YY, HH/MM/SS'.

Note: Enter the date and time without the single quote ('), otherwise the message SYNTAX ERROR appears on screen.
If wait code FF9002 occurs the console CDS (configuration data set) is incorrect. To continue, press ENTER on the desired input device. OLTSEP then autoconfigures that device. If OLTSEP cannot autoconfigure the device wait code FF990A occurs. For further operational information refer to the OLTSEP User's Guide.

- If the printer CDS is incorrect, you are prompted to enter the address and device type of the output printer as follows:

Enter output device address and device type as follows:
CUU-DDDD, where CUU = device address and DDDD = device type.

Sample entry: 00E-1403

After you enter the device address and device type OLTSEP continues as described in the OLTSEP User's Guide. If a problem occurs, enter blanks in response to the above request (results in wait code FF9906), and then refer to the OLTSEP User's Guide. Valid device types are:

1403 3203 3262 3800
1443 3211 3289

System Test 4300 (ST4300) and OLTSEP (continued)

How to Load the OLTSEP/OLT s (continued)

- One CDS is available for each of the following types of tape drives:

2400 3410 3420

When you test a tape drive that has standard features, OLTSEP automatically creates a temporary (until the next IPL) CDS for that tape drive (you do not have to create a CDS via the CDSGEN function).

Standard Features CDS:

2400 - x'0000 8001 00 000000'
3410 - x'0000 8005 00 000000'
3420 - x'0000 8004 00 000000'

If the tape drive you want to test has no standard features you must use the CDSGEN function. The CDSGEN function gives you the choice of entering CDS information from the operator's console or from a reader. You are prompted to enter Y if you want to use the operator's console to create a temporary CDS. Enter the CDS information as shown below.

ddd mmmm cccc ffff oooo/

ddd = device address
mmmm = model and feature code
cccc = class and type codes
ffff = flags
oooo = optional data (up to 37 bytes)

Example: 181 0000 8001 4400

For additional information see the CDSCEN function in the OLTSEP User's Guide.

- On Machines with less than 470K available main storage, the 3410 OLTS will not all fit. Also the 3420 OLTS will not fit.

On those machines a subset of OLTS is loaded. If the operator attempts to run an OLT that is not in that subset he will be instructed to go to the diskette load screen and enter one of the following:

For 3410's
T3410 --> Loads T3410A - 0
T3412 --> Loads T3410P

For 3420s
T3420 --> Loads T3420A - CE
T3422 --> Loads T3420CD - P
T3424 --> Loads T3420 -
T3426 --> Loads T3420ZA - ZB

Central Complex Test Selection

The following picture appears on screen when you select 'CENTRAL COMPLEX' from the 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' picture.

The selection menu occupies two frames. The last selection (F) of the first frame calls the second frame.

To run one of the tests which are listed in this picture go to the respective test handling procedure on the following pages.

CENTRAL COMPLEX TEST SELECTION

D = Test Name A	D = Test Name B	D = Test Name C
---------------------------------------	---------------------------------------	---------------------------------------

SELECTION: 6

LOG-WAITING

-- = NOT AVAILABLE

DATA:

ADDR:

- A

B

C
- Test names and selection codes
- D

The digits in front of the test name must be typed in behind the word SELECTION to select the appropriate test. A dash (-) instead of a digit indicates that the test is not available. (False diskette or wrong configuration).

Test Chaining Selection

Test Handling - Actions

Prerequisites:

- Power complete
- Diagnostic diskette inserted

How to Select the Test

1. Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
2. Select TEST CHAINING, press ENTER. [B]

How to Use the Test

After selection of 'test chaining' field (E) of the display shows all tests which run in default selection at this system.

Default selection causes all listed tests to be executed in the sequence indicated.

By varying the sequence number (F) tests can be excluded from execution or the sequence of execution can be changed, however, the tests with sequence number 0 and 1 cannot be changed or excluded.

For default run just press ENTER.

If you want to change the execution, alter the sequence number(s) and press ENTER. The next display will now list the tests in the requested sequence in field (E). At this point you can verify your selection. Press ENTER to start test chain or use PF 4 to return to picture [B]. A new selection is now possible.


How to Stop the Chaining Selection

The test chain is stopped automatically when all selected tests were executed error free, or the first error was detected in a test.

The test presenting the error can now be handled as described in the appropriate test description.

When a test chain was not completed and test chaining is selected again, the last chaining selection is repeated as default.

Test Handling - Results



Examples:

ENTER	(A) The test sequence was changed.	(B) By deleting 4, all following tests are deleted.	(C) Some tests are deleted. For the remaining tests the sequence number has been changed.
	First Display 0 = SBA/SUPPORT BUS TEST 1 = PU-BSM TEST 2 = IC-BUS TEST 7 = BBA 0 TEST 4 = CA BA TEST 6 = FTA 1 TEST 3 = MPX ADAPTER TEST 5 = BMPX-1 ADAPTER TEST Second Display 0 = SBA/SUPPORT BUS TEST 1 = PU-BSM TEST 2 = IC-BUS TEST 3 = MPX ADAPTER TEST 4 = CA BA TEST 5 = BMPX-1 ADAPTER TEST 6 = FTA 1 TEST 7 = BBA 0 TEST	First Display 0 = SBA/SUPPORT BUS TEST 1 = PU-BSM TEST 2 = IC-BUS TEST 3 = BBA 0 TEST = CA BA TEST 5 = FTA 1 TEST 6 = MPX ADAPTER TEST 7 = BMPX-1 ADAPTER TEST Second Display 0 = SBA/SUPPORT BUS TEST 1 = PU-BSM TEST 2 = IC-BUS TEST 3 = BBA 0 TEST	First Display 0 = SBA/SUPPORT BUS TEST 1 = PU-BSM TEST 2 = IC-BUS TEST = BBA 0 TEST 4 = CA BA TEST = FTA 1 TEST 3 = MPX ADAPTER TEST = BMPX-1 ADAPTER TEST Second Display 0 = SBA/SUPPORT BUS TEST 1 = PU-BSM TEST 2 = IC-BUS TEST 3 = MPX ADAPTER TEST 4 = CA BA TEST

This page has been
intentionally left blank

IC Bus Test

Test Handling - Actions

Prerequisites:

- Power complete
- Diagnostic diskette inserted
- PU-BSM test run

How to Select the Test

1. Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. **A**
 2. Select 'CENTRAL COMPLEX', press ENTER. **B**
 3. Select IC-BUS TEST, press ENTER. **C**
This selection automatically tests IC bus 0 and 1, if installed.
 4. Press ENTER to start test.
During test run, the message LOG PENDING can appear on line 23.
- Run time about 40 seconds if both buses are tested.
 - Test stops at test end displaying STOPPED in **B**
 - If an error is detected the test also completes and in addition to the message STOPPED a reference code and at least 1 symptom code is shown **A** and **C**
By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following parameters **D** can be specified

LOOP (Y/N)

N=default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO:..

- a) 01 TO.. = default if no TO-routine is specified.
Test runs from routine 01 to last routine.

- b) To run or loop a complete test, not starting with RTN01: Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO: 07

- c) To run or loop a specific routine: Enter the routine number in both fields:
RTN: 05 TO: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):

Y=Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in **C** and **A** in case of error.
Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: 0 (Physical address)

The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.
If a valid adapter number would be entered, the test starts but generates false reference codes. If an invalid number is entered, the message INV. INPUT is shown in **B**.

What to Do in Case of Error

If the test stops with a reference code displayed in **A** go to MAP 2370.

How to Terminate the Test

If you want to run another test return to M/S PROGRAM SELECTION. Select new test, otherwise perform the following steps:


1. Press ENTER, to stop the test
2. Insert control diskette
3. Perform re-IML
4. Return machine

Test Handling - Results

Screen displays:

A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

B 'CENTRAL COMPLEX TEST SELECTION'



A Reference code

C Symptom code display field

B Status of test

D Run mode selection field

PU-BSM Test

Test Handling - Actions

Prerequisites

- 'Power Complete' Light on

How to Select the Test

- Insert the diagnostic diskette.
- Press IML to reload the service processor.
(This ensures correct execution of the test.)
- Call M/S PROGRAM SELECTION. **1**
- Key in selection for 'CENTRAL COMPLEX', press ENTER. **2**
- Select PU-BSM test, press ENTER. **3**
- Press ENTER to start test.
 - Test runs in mode 4, (diagnostic mode), default mode.
 - Run time about five minutes.
 - Pressing ENTER stops test at overlay end.
 - Pressing ENTER a second time the test continues to execute.
 - Test stops at test end displaying STOPPED in **G**.
 - A reference code is displayed in **G** in case of error. Use this reference code to enter the appropriate MAP.

How to Terminate the Test

- Press ENTER, to stop the test.
 - Insert control diskette.
 - Perform re-IML.
 - Return machine.
- If you want to run another test return to M/S PROGRAM SELECTION. Select new test.

Test Handling - Results

Screen displays:

- 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- 'CENTRAL COMPLEX TEST SELECTION'
- PU Test Frame Picture

A
M: 4

B
ID:

C
C:

D
S:

E

SELECT: **F**

H

G

- A** Display of Test Mode. Mode 4 is the default value, no entry has to be made.
- B** Identifier of test section just running. After the test has been started, the display identifier changes whenever a new routine is executed, thus also indicating that the test is running.
- C** Displays the identifier of the test step.

- D** The card location(s) of the suspected FRU(s) are displayed in this field.
- E** Displays PU hardware data, if test runs in mode 3 and stops with error. The displayed data is to be used in case of support.
- F** Enter field for test options.
- G** Displays RUNNING, STOPPED, or a reference code, if an error is detected.
- H** If one or more additional reference codes are displayed in this field, use these codes first for error analysis.

PU-BSM Test (continued)

Control Store (CS) Test

There are two different control store cards available.

Type 0 ---> Card QA5
Type 1 ---> Card QS2

Each type has its own test described on the following pages.

CS Test for Type 0 (QA5)


Description of Test

The test consists of seven passes. (LOOP..) specifies how often the test should be repeated.

During the first pass the storage area, specified by parameter BEG and END, is loaded with consecutive blocks of pattern. In the first pass block load starts at BEG +0 (displacement). After load is completed the test patterns of the blocks are executed. After the last block is executed the next pass will be executed if no repetition of pass is specified (PASS..).

In pass two to seven the load address BEG is modified by +1 (BEG+1, BEG+2, until BEG+6), but the execution remains the same as in pass one.

At the end of pass seven the test is stopped if no LOOP count is specified.



Note: A pass consists of two phases, the load phase and the execute phase. In the load phase the storage area is loaded with consecutive blocks of test patterns. Thereafter, one block of test pattern after the other is executed.

If in 'BLOCK XX' a value is entered, every block is looped until count is zero. Then the next block is executed.

CS-Test for Type 0 (continued)

Test Handling - Actions

Prerequisites

- Selection of 'PU-BSM test'

How to Use the Control Store Test

- Enter 'CT' in the SELECT field, press ENTER. After a delay the CT selection picture is displayed with all default run parameters for the CT test.
- If you want to run the CT-test in the default selection, press ENTER to start the test, otherwise type in the new run parameters first.

Test runs about one minute if the default selection is used and the CS-size is 16 K. For 32 K CS-size run time is approx. 2.5 minutes.

Result of Test Run

Up to ten errors can be displayed. If an error is detected looping of this block is stopped. Test continues with next block.

The test stops if the ten error display lines are used up or after all loops are completed.

Test Handling - Results

4

PU-BSM-TEST M:CT ID: C: SYMP:

CS-TEST

C.	IS.....	XOR.....	ADR.	DI	BL	PA	LP
01	019FCFB7	00000020	7D6C	00	01	02	01
10	7031187D	00001000	7D4B	01	01	03	01

TEST PAT:

0 60960897

1 6D693068

2 019FCF97

3 703108..

4 019FFC00

5 603103..

6 024E0000

SEL: CT

BEG: 0040

END: 8000

BLOCK: F0

PASS: 03

LOOP: 01

STOP

TIMER:OFF

DATA:

ADDR:

ERROR XXXXXXXX SYMP YY

A Error **Δ** Indicates the occurrence of an error.

XXXXXXXX **Δ** Reference Code
SYMP YY **Δ** Symptom (card position)
YY = 02 ---> C2
YY = 03 ---> D2

B Selection Field

D Test Parameter Enter Fields

After selecting the CT-test the default values are displayed.

BEG: Begin address of test area must not be < X'0040'.

END: End address of area to be tested (< or = CS size).

BLOCK: Number of repetitions for each block.

PASS: Number of repetitions for each pass.

LOOP: Number of repetitions for whole test.

E Test pattern which is loaded into all blocks.

F See next page

PU-BSM Test (continued)

CS Test Type 0 (continued)


Test Handling - Results

F Error Display Field

Depending on the error (bit failure, or address error) some fields have a different meaning.

Meaning of fields if bit failure:

- C. 10 = OP register check 0,2
01 = OP register check 1, 3
- IS..... Failing test pattern in the OP register.
- XOR..... Indicates the failing bit.



- ADDR. Failing control store address.

Meaning of fields if address error:

- C. Displays AE for address error.
- IS..... Displays the wrong address which was generated. Address is shown right adjusted.
- XOR..... Shows correct address left aligned.

The fields DI, BL, PA, and LP have for bit failure and address error the same meaning.

- DI Displacement of pass in which the error occurred.
- BL Count shows how often block was repeated when error occurred.
BL = 1 Error was detected in first run of block.
- PA Count shows how often pass was repeated when error occurred.
- LP Count shows how often the whole test was looped when error occurred.

CS Test for Type 1 (QS2)

Test Handling - Actions

Prerequisites

- Selection of 'PU-BSM test'

How to Use the Control Store Test

1. Enter 'CT' in the SELECT field, press ENTER. After a delay the CT selection picture is displayed with all default run parameters for the CT test. This delay is caused by execution of buster 4777. 1
2. Run the CS-test in the default mode. F Press ENTER to start the test.

Note that when started this test cannot be stopped. It stops automatically either

- after completion or
- with X'400' inversions or
- on the occurrence of not correctable errors.

Result of Test Run

If an error is detected the test is stopped.

Note: With this storage type, errors may be corrected by storing the respective bit pattern 'inverted'. Inversions are time consuming and therefore limited. IML, and all tests which use the control storage, require an increased execution time (depending upon the number of inversion). Successful inversions and their count (hex) are displayed (I: XXXX) on the screen. After hex 400 inversions, a warning reference code is displayed. (The same reference code will appear during IML.)

Test Handling - Results

A

PU-BSM-TEST M:CT ID: C: SYMP:

CS-TEST

B

INVCNT: 0400

DATA: 00000020

PTY: 0

IBIT: 0

ADR:

PAX:

C

A

ERRCNT: 0400

G

Ignore these fields

D

THERE ARE > 1024 INV ERR IN. TEST WILL RUN > 30 MIN.

F

BEG: 0048 END: 8000 PASS: 03 RUN: 00 ALL: 0

TIMER: ON

DATA: ADDR:

TOD: SEC

E

RUNNING E0861A01

8110

A ERRCNT: Count of not correctable errors.

B Invert Count.

C 0400 = Number (hex count) of single bit errors (inverted bits), which are corrected by inversions.

DATA, PTY, IBIT = These fields show those bits as (1) which failed and caused an inversion.
(Data = 32 data bits;
PTY = 1 parity bit)
(per storage word);
IBIT = 1 invert bit
(per storage word)

D Note, which indicates, that the number of acceptable inversions ('400') is exceeded. Large increase of testing time is to be expected. (See explanation for IML screen on next page.)

E Reference Code (Warning)
The indication 'Running' means that the execution of the CS-Test is currently interrupted (not stopped) by the occurrence of an error. The test may be continued by pressing 'ENTER' but this is not recommended because of the long execution time (see also D).

G Upper field ^ Number (count) of inverted bits.
Lower field ^ Number (count) of actual inversions.

Diagnostic MS Test

Program Handling - Actions

Prerequisites

- Selection of PU-BSM test

How to Select the DM-Test

Enter DM in the SELECT field of the PU-BSM test, press ENTER. After a delay this causes the DM selection picture **5** to be displayed.

How to Use the Test

There are different cases where the DM test can be used. In any case press ENTER after you have entered your parameters. This causes the test to be executed once. If the parameter RUN: is changed to greater '00' the test loops until it is stopped by pressing ENTER.

Case 1:

A given address (from log display) is available. An uncorrectable error is assumed at this address. Enter this address in the UNCADR field, press ENTER.

Case 2:

No address available. The test is selected for diagnostic purposes. Do not change value in the UNCADR field, press ENTER.

For both cases refer to 'Result of DM Test Run' for test result interpretation. If you suspect a failing card(s) but the DM test result does not show an asterisk (*) or a count greater X'400', select the IM test under the

Test Handling - Results

Result of DM Test Run

If the test runs error-free, the test stops with the message

STOPPED in **E**

and NO ERROR displayed in **B**. In case of an error the location of the failing card and an error count is displayed in field **B** together with the message STOPPED.

For case 1 replace the card if an asterisk is displayed. For case 2 replace any card (s) which show an count greater X'400'.

5

PU-BSM-TEST M:DM ID:	C:	SYMP:
DM-TEST ALLERR: 00000040	<---	A
P2:X0040 <---	B	
SEL: DM UNCADR: FFFFF8	RUN: 00	STOPPED
C	D	E

A In case of error(s) ALLERR: XXXXXXXX is displayed. In the X-field the total (ALL) errors of the tested array card (s) are given.

B This field gives the total errors of each array card.

T2: * FFFF
| | | | |
| | | | |--- Error count
| | | | | (FFFF indicates counter overflow)
| | | | |----- X = errors per card
| | | | |----- * = errors per card including
| | | | | uncorrectable error at
| | | | | address entered in UNCADR.
| | | | |
| | | | |--- Card location

C Enter field for the uncorrectable error address, found in the LOG. Default is FFFFF8 (=invalid address). Avoids erroneous indication of uncorrectable errors

D If a value other than 00 is entered the test loops until stopped by pressing ENTER.

IM-Test

Program Handling - Actions

Prerequisites

- DM test has been executed but did not show an error however a failing card is assumed. In this case run sub- selection IM of the PU-Tool.
- Insert diagnostic diskette

How to Select the IM-Test

- Call M/S PROGRAM SELECTION 1
- Key in selection for MANUAL OPERATIONS 2
- Key in selection for PU TOOL 3

How to Run the IM-Test

- Enter IM in the select field B, press ENTER. This causes individual test routines (busters) to be executed. Thereafter the test stops displaying picture 4. This is the IM-test screen display.
- Do not alter the displayed values in the control fields C. Press ENTER to start the actual IM-Test.
- Run time approx. 2 minutes per 1MB storage.

In case the test runs error-free the screen will display the message D below the topline.
In case the test encounters an error(s) the screen display 5 shows the message ERROR E and at least one line of error information F and a reference code G. Up to ten error lines per screen can be displayed. Only if the two XX-digits in the reference code equal X'0A' you can continue, otherwise call for support. In case of card replacement restart with PU-BSM test.

Program Handling - Results

Screen displays:

- 1 IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
- 2 MANUAL OPERATIONS

3

```
PU-TOOL  18JUL80      RAO  CS:32K  MS:1M
00....03 04....07 08....11 12....15 16....19 20....23 24....27
A: 00000000 00000000 FF0003F9 0000101F 1000400B C56084D9 C560E000
B: 00000000 00000000 00000000 00000000 10220010 C03B0009 0EFFA300

H: 21DB0000 FF830000 00000000 00000000 000000F8 00F800F8 00F80
I: 00000000 00000000 00000000 00000000 00000000 00000000 00000

IS:
BE:
EXECUTE:
SELECT : IM<-- B      AM: 00      TIMER:ON      DATA:
                        TOD:SEC

803D
```

4

```
PU-TOOL  18JUL80      RAO  CS:32K  MS:1M
IM-TEST
TYPE M ERRADR .ACTUAL> XOR.RSLT FRU

C----->SEL: IM  BEG: 000000  END: 100000  LOOP CNT: 00  ECC(Y/N): Y
                        TIMER:ON      DATA:
                        TOD:SEC      STOPPED

803A
```

D----->

```
PU-TOOL  18JUL80      RAO
IM-TEST  O.K.  EOT
TYPE M ERADR .ACTUAL. XOR.RSLT FRU
```


How to Run the IM-Test (continued)

If the reference code displays X'0A'
replace the FRU(s) **H** indicated. Use the FRU-table **6** for
card location. Only if EOT is displayed behind **J**, the test has
completed and all errors have been shown.

If the word LIMER is displayed behind ERROR **K** more than ten lines of
error information are available.
Replace the FRUs indicated in this display. Restart the IM-test and
continue to replace FRUs if the test still shows errors. All errors
have been displayed if EOT is shown.

5

PU-TOOL 18JUL80 RAO

IM-TEST ERROR <---**E**

TYPE M	ERRADR	.ACTUAL.	XOR.RSLT	FRU
DATA R	0DDC18	BD72E5CA	00000001	T
DATA V	0DD018	BD72E5CA	00000001	T
DATA V	0DD018	BD72E5CA	00000001	T

REF CODE : 4BB3XX81

SEL: IM

BEG: 000000

END: 100000

LOOP CNT: 00

ECC(Y/N): Y

TIMER:ON

TOD:SEC

DATA:

STOPPED

803A

F

G

H

PU-TOOL 18JUL80 RAO

IM-TEST ERROR EOT <---**J**

PU-TOOL 18JUL80 RAO

IM-TEST ERROR LIMER <---**K**

6

FRU TABLE

FRU	NAME	FRU LOCATION
U	BSM CARD 9	01A-B1U2
T	BSM CARD 8	01A-B1T2
R	BSM CARD 7	01A-B1R2
Q	BSM CARD 6	01A-B1Q2
P	BSM CARD 5	01A-B1P2
N	BSM CARD 4	01A-B1N2
M	BSM CARD 3	01A-B1M2
L	BSM CARD 2	01A-B1L2

This page has been
intentionally left blank

FTA (X) Test

Test Handling - Results

Prerequisites:

- IML
- Diagnostic diskette inserted
- PU/BSM test and IC-bus test run
- If the CTLI test has been executed before, verify that the wrap connectors have been removed and the CTLI cables are properly seated.

How to Select the Test

1. Call M/S PROGRAM SELECTION.
Hold down ALT key and press DIAG key. [A]
2. Key in selection for 'CENTRAL COMPLEX', press ENTER. [B]
3. Select FTA test 1, 2 or 3, press ENTER. [C]
4. The status field displays SELECTION. Enter new run mode if you want to change the default. Press ENTER to start test.
 - Run time about two minutes.
 - Test stops at test end displaying STOPPED in [B].
 - If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least one symptom code is shown in [A] and [C].By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following parameters [D] can be specified

LOOP (Y/N)
N=default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO:..

- a. 01 TO:.. = default if no TO-routine is specified. Test runs from routine 01 to last routine.
- b. To run or loop a complete test, not starting with RTN01:
Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO: 07
- c. To run or loop a specific routine: Enter the routine number in both fields:
RTN: 05 TO: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):
Y=Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in [C] and [A] in case of error.
Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means: the analysis phase does not always interrupt the test execution.

ADAPT: 9 = FTA 1, 4 = FTA 2, 2 = FTA 3 (Physical address)
The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.
If a valid adapter number would be entered, the test starts but generates false reference codes.
If an invalid number is entered, the message INV. INPUT is shown in [B].

What to Do in Case of Error

If an error is indicated rerun the test with power off on all attached control units. If the error is still indicated use the reference code in [A] to enter the correct MAP. If no error is indicated suspect the control interface. Run CTLI Wrap test.


How to Terminate the Test

- If you want to run another test return to M/S PROGRAM SELECTION. Select new test, otherwise perform the following steps:
1. Press ENTER, to stop the test
 2. Insert control diskette
 3. Perform re-IML
 4. Return machine

Test Handling - Results

Screen displays:

- [A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
[B] 'CENTRAL COMPLEX TEST SELECTION'



- [A] Reference code
[B] Status of test
[C] Symptom code display field
[D] Run mode selection field

Control Interface Wrap Test

Test Handling - Actions

Prerequisites:

- Power complete
- IML
- Diagnostic diskette inserted
- PU/BSM test, IC-bus test, FTA test run
- Wrap connectors cable assembly P/N 8483860 must be available.
- All attached controllers must have power off.

How to Plug the Wrap Connectors

Drop power on all connected control units. Plug the wrap connectors for bus and tag lines on the terminals of the first control unit seen from the 4331.

If an 8809 is attached the CTLI cables must be disconnected at the control unit and the wrap connectors must be plugged at the end of the CTLI cable.

Run the test. An error indication at this point shows that the error is inside the system, possibly a bad connection at gate 01D. No error means that the connectors have to be moved to the next control unit and so on until the whole control interface is tested.

If no IBM controller is attached, plug the wrap connectors on the terminals at the processor in gate 01D according to the following list:

	FTA1	FTA2	FTA3
Bus lines	01D-A2	01D-C2	01D-E2
Tag lines	01D-B2	01D-D2	01D-F2

How to Select the Test

1. Call M/S PROGRAM SELECTION. Hold down ALT key and press DIAG key. **A**
2. Key in selection for 'CENTRAL COMPLEX', press ENTER. **B**
3. Select appropriate test, press ENTER. **C**
4. Press ENTER to start test.

- Run time about thirty seconds.
- Test stops at test end displaying STOPPED in **B**.
- If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least one symptom code is shown. **A** and **C**
By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following run mode parameters **D** can be specified.

LOOP (Y/N)
N = default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO:..
a) 01 TO.. = default if no TO-routine is specified. Test runs from routine 01 to last routine.

b) To run or loop a complete test, not starting with RTN01:
Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO: 07

c) To run or loop a specific routine:
Enter the routine number in both fields:
RTN: 05 TO: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):
Y = Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in **C** and **A** in case of error.
Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: 9 = FTA 1, 4 = FTA 2, 2 = FTA 3 (Physical address)
The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.
If a valid adapter number would be entered, the test starts but generates false reference codes. If an invalid number is entered, the message INV. INPUT is shown in **B**.

What to Do in Case of Error

Go to MAP C180 for CTLI 1 or C280 for CTLI 2 or C380 for CTLI 3 } If 3370 I/Os attached to the Control Interface use also 3370 MIM pages Ctrl. 10 & 20.



To 3370 MIM
MLX page

How to Terminate the Test

If you want to run another test return to M/S PROGRAM SELECTION. Select new test.

If you had disconnected any cables or connectors check for proper reconnection.

If you don't want to select a new test do the following steps:


1. Press ENTER, to stop the test
2. Insert control diskette
3. Perform re-IML
4. Return machine

Test Handling - Results

Screen displays:

A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

B 'CENTRAL COMPLEX TEST SELECTION'



A Reference code

C Symptom code display field

B Status of test

D Run mode selection field

MPX/BMPX Adapter Test

Test Handling / Actions

Prerequisites:

- Power complete
- Diagnostic diskette inserted
- PU/BSM test run, IC bus test run.

How to Select the Test

1. Call M/S PROGRAM SELECTION. Hold down ALT key and press DIAG key. **[A]**
2. Key in selection for 'CENTRAL COMPLEX', press ENTER. **[B]**
3. Enter appropriate selection for:
MPX ADAPTER TEST or
BMPX 1 or 2 ADAPTER TEST.
to test the ACC/SCA cards of the MPX or BMPX adapter Press Enter **[C]**
4. Press ENTER to start test.
 - Run time about 2.5 minutes
 - Test stops at test end displaying STOPPED in **(B)**.
 - If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least one symptom code is shown. **(A)** and **(C)**By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following parameters (D) can be specified:

LOOP (Y/N)

N=default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO:...

- a) 01 TO.. = default if no TO-routine is specified
Test runs from routine 01 to last routine.

- b) To run or loop a complete test, not starting with RTN01:
Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO: 07

- c) To run or loop a specific routine:
Enter the routine number in both fields:
RTN: 05 TO: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):

Y=Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in (C) and (A) in case of error.

Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: 6 = MPX, A = BMPX 1, 4 = BMPX 2 (Physical address)

The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.

If a valid adapter number would be entered, the test starts but generates false reference codes. If an invalid number is entered, the message INV. INPUT is shown in (D).

What to Do in Case of Error

If the test stops with a reference code displayed in (A) go to the referenced MAP.

How to Terminate the Test


If you want to run another test return to M/S PROGRAM SELECTION. Select new test, otherwise perform the following steps:

1. Press ENTER, to stop the test
2. Insert control diskette
3. Perform re-IML
4. Return machine

Test Handling - Results

Screen displays:

- A** 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- B** 'CENTRAL COMPLEX TEST SELECTION'



- (A) Reference code
- (B) Status of test
- (C) Symptom code display field
- (D) Run mode selection field

Standard Interface Test for MPX/BMPX and HSC

Test Handling - Actions

Prerequisites:

- Power complete
- Diagnostic diskette inserted
- PU/BSM test, IC-bus test, ACC/SCA test run errorfree
- Wrap Connector Plug (Bus) P/N 8483772 and Wrap Connector Plug (Tag) P/N 8483773 must be available.

How to Plug the Wrap Connectors

Drop Power on all connected control units. Plug the wrap connectors for bus and tag lines on the terminals of the IBM control unit next to the processor, and run test. An error indication at this point shows that the error is inside the system, possibly a bad connection at gate 01D. No error means that the connectors have to be moved to the next control unit and so on until the control interface is tested. If no IBM control unit is attached, plug the wrap connectors on the terminals at the processor in gate 01D according to the following list:

	MPX	BMPX1	BMPX2	HSC
Bus lines	01D-D3	01D-F3	01D-C2	01D-E2
Tag lines	01D-E3	01D-G3	01D-D2	01D-F2

How to Select the Test

1. Call M/S PROGRAM SELECTION. Hold down ALT key and press DIAG key. **A**
2. Key in selection for 'CENTRAL COMPLEX', press ENTER. **B**
3. Select appropriate test, press ENTER. **C**
4. Press ENTER to start test.
 - Run time about 1 minute
 - Test stops at test end displaying STOPPED in **B**.

- If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least 1 symptom code is shown **A** and **C**. By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following run mode parameters **D** can be specified.

LOOP (Y/N)
N = default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO:..

- a) 01 TO.. = default if no TO-routine is specified. Test runs from routine 01 to last routine.
- b) To run or loop a complete test, not starting with RTN01:
Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO:07
- c) To run or loop a specific routine:
Enter the routine number in both fields:
RTN: 05 TO:05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):
Y=Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in **C** and **A** in case of error. Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: 6 = MPX, A = BMPX 1, 4 = BMPX 2, 1 = HSC
(Physical address)
The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu. If a valid adapter number would be entered, the test starts but generates false reference codes. If an invalid number is entered, the message INV. INPUT is shown in **B**.

What to Do in Case of Error

Go to MAP 8080 for BMPX1 or 8180 for BMPX2, 8480 for MPX or 8280 for HSC

How to Terminate the Test


If you want to run another test return to M/S PROGRAM SELECTION. Select new test. If you had disconnected any cables or connectors check for proper reconnection. If you don't want to select a new test do the following steps:

1. Press ENTER, to stop the test
2. Insert control diskette
3. Perform re-IML
4. Return machine

Test Handling - Results

Screen displays:

- A** 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- B** 'CENTRAL COMPLEX TEST SELECTION'



- A** Reference code
- B** Status of test
- C** Symptom code display field
- D** Run mode selection field

SBA/Support Bus Test

Test Handling - Action

Prerequisites

- IML
- SP must be powered up for part executed during IML.
- CEC must be powered up if test is selected manually.

How to Select the Test

1. Insert diagnostic diskette
2. Call M/S PROGRAM SELECTION
3. Select CENTRAL COMPLEX
4. Select SBA Test

Note: The SBA test is also included in the test chaining selection.

Test Handling

1. Press 'ENTER'
Test starts to run in the default selection, this is no looping. If you specify looping, test routine string is repeated until stopped.
2. To stop test press 'ENTER' again.
3. Pressing 'ENTER' a third time returns you to the SBA selection picture. Selection of looping can now be changed.
4. Pressing 'ENTER' the fourth time starts test again in the desired mode (loop or no loop).

Test Description

The SBA test consists of ten routines. The routines cannot be selected separately, however, under certain conditions only some of the routines are executed.

Use of Test During IML

During the IML phase routines 1, 2, and 7 of the selectable SBA test are executed immediately after 'IML TEST OF SP CS ABOVE 32K'. If an error is detected at this time a reference code with the format shown is generated.

E03 . . . 01
| | |
Step number 1 to 6
| |
- Routine number 1, 2, or 7
|
-- MCPC indicator
0 = No MCPC error
4 = MCPC timeout error
8 = MCPC inbound parity error

In case of an MCPC error the address, command and data of the failing I/O instruction are displayed and the instruction is looped.

With no MCPC error the test ends in a hang loop.

In either error case IML cannot be continued.

Use of Test During Manual Selection

If the SBA test is selected from the test selection menu CEC must be powered up in order to run the test.

Error Indication

If the test was selected manually, and an error is detected, the reference code has the following format:

F3F . . . 81
| | |
Step number 1 to 6
| |
- Routine number 1 to A
|
-- MCPC indicator
0 = No MCPC error
4 = MCPC timeout error
8 = MCPC inbound parity error

If looping was not specified test stops after displaying the reference code, otherwise test loops between the beginning of the test and the occurrence of the error.

Looping of Failing I/O Instruction

If the test is selected from the test menu failing I/O instructions will not be looped.

BBA 0/1 Test

Test Handling / Actions

Prerequisites:

- Power complete
- Diagnostic diskette inserted
- PU/BSM test run

How to Select the Test

1. Call M/S PROGRAM SELECTION. Hold down ALT key and press DIAG key. **A**
2. Key in selection for 'CENTRAL COMPLEX', press ENTER. **B**
3. Select ACC/BBA 0 TEST or ACC/BBA1 TEST, press ENTER. **C**
4. Press ENTER to start test.
 - Run time about 1 minute
 - Test stops at test end displaying STOPPED in **B**
 - If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least 1 symptom code is shown **A** and **C**
By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following parameters **D** can be specified:

LOOP (Y/N)

N=default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO:..

- a) 01 TO.. = default if no TO-routine is specified.
Test runs from routine 01 to last routine.

- b) To run or loop a complete test, not starting with RTN01:
Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO: 07

- c) To run or loop a specific routine:
Enter the routine number in both fields:
RTN: 05 TO: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):

Y=Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in **C** and **A** in case of error.
Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: E = BBA 0 and BBA 1 (Physical address)

The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.
If a valid adapter number would be entered, the test starts but generates false reference codes.
If an invalid number is entered, the message INV. INPUT is shown in **B**.

What to Do in Case of Error

Go to MAP A280 (if BBA 1) or MAP F280 (if BBA 0)

How to Terminate the Test

If you want to run another test return to M/S PROGRAM SELECTION. Select new test, otherwise perform the following steps:


1. Press ENTER, to stop the test
2. Insert control diskette
3. Perform re-IML
4. Return machine

Test Handling - Results

Screen displays:

A 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

B 'CENTRAL COMPLEX TEST SELECTION'



A Reference code

B Status of test

C Symptom code display field

D Run mode selection field

HSC ADAPTER TEST

Test Handling - Actions

Prerequisites:

- Power complete
- Diagnostic diskette inserted
- Processing Unit/BSM test, IC-bus test run

How to Select the Test

1. Call M/S PROGRAM SELECTION. Hold down ALT key and press DIAG key. **A**
2. Key in selection for 'CENTRAL COMPLEX'; press ENTER. **B**
3. Select appropriate test, press ENTER. **C**
Tests the ACC/SCA cards of the HSC adapter.
4. Press ENTER to start test.
 - Run time about 2.5 minutes
If routine 1F is excluded, runtime is only 0.5 minutes.
 - Test stops at test end displaying STOPPED in **B**. If any routine from 0 to 1E shows an error stop test and exclude routine 1F which would take two minutes run time. Run time reduces to 0.5 minutes.
 - If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least one symptom code is shown. **A** and **C**
By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Run Modes

The following parameters **D** can be specified

LOOP (Y/N)
N=default. If Y is selected the test or routine will loop until stopped.

RTN: 01 TO...
a. 01 TO.. = default if no TO-routine is specified. Test runs from routine 01 to last routine.

- b. To run or loop a complete test, not starting with RTN01:
Enter start routine number in the RTN-field, and start routine number minus 1 in the TO-field:
RTN: 08 TO: 07
- c. To run or loop a specific routine:
Enter the routine number in both fields:
RTN: 05 TO: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):
Y=Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in **C** and **A** in case of error.
Enter 'N' to suppress error analysis. This can be useful if 'loop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: 1 (Physical address)
The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.
If a valid adapter number would be entered, the test starts but generates false reference codes.
If an invalid number is entered, the message INV. INPUT is shown in **B**.

What to Do in Case of Error

If the test stops with a reference code displayed in **A** go to the referenced MAP.


How to Terminate the Test

- If you want to run another test return to M/S PROGRAM SELECTION. Select new test, otherwise perform the following steps:
1. Press ENTER, to stop the test
 2. Insert control diskette
 3. Perform re-IML
 4. Return machine

Test Handling - Results

Screen displays:

- A** 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
B 'CENTRAL COMPLEX TEST SELECTION'
C



- A** Reference code
B Status of test
C Symptom code display field
D Run mode selection field

SCL IOSS/MSSS Test

Test Handling - Actions

Prerequisites

- Power complete
- Diagnostic diskette inserted
- PU/BSM test run

How to Select the Test

1. Call M/S PROGRAM SELECTION. **A**
 2. Select CENTRAL COMPLEX, press ENTER. **B**
 3. Select the appropriate test, press ENTER. **C**
 4. Press ENTER to start test.
 - Run time is about 1 minute. The test stops at test end displaying STOPPED in **B**.
 - If an error is detected the test also runs to the end and in addition to the message STOPPED a reference code and at least one symptom code is shown in **A** and **C**.
- By pressing ENTER a running test or routine can be stopped. Stop occurs always at routine end.

Exception for SCL MSSS Test

If the SCL MSSS test is selected the test stops at test end with the status RUNNING and the display for the CE panel lamp test **D**. Set the CE panel DISPLAY MODE switch to ON and execute the lamp test according to the information in display **D**. To stop the test either before or after lamp test execution press ENTER.

Run Modes

The following parameters **D** can be specified:

LOOP (Y/N)

N = default. If Y is selected the test or routine will loop until stopped.
If Y is specified for the SCL MSSS test ENTER has to be pressed twice in arapid succession to stop the test.

RTN: 01 T0:..

- a) 01 T0.. = default if no T0-routine is specified. Test runs from routine 01 to last routine.

- b) To run or loop a complete test, no: starting with RTN01: Enter start routine number in the RTN-field, and start routine number minus 1 in the T0-field:

RTN: 08 T0: 07

© Copyright International Business Machines Corporation 1979, 1980, 1981

- c) To run or loop a specific routine: Enter the routine number in both fields:
RTN: 05 T0: 05

Note: Routine 00 must not be entered. This is an auxiliary routine for special purposes.

ANALYSIS (Y/N):

Y = Default. If analysis is enabled (Y) symptom codes and a reference code are displayed in **C** and **A** in case of error.
Enter 'N' to suppress error analysis. This can be useful if 'lcoop a routine' is specified. In this case the routine loops under real-time conditions, that means, the analysis phase does not always interrupt the test execution.

ADAPT: X

The adapter number is displayed automatically. Do not change the adapter number. To test another adapter select the appropriate test from the CENTRAL COMPLEX menu.

What to Do in Case of Error

Go to MAP A280 (if BBA1) or MAP F280 (if BBA0)

Terminate the Test


If you want to run another test return to M/S PROGRAM SELECTION, select new test. Otherwise perform the following steps:

1. Press ENTER, to stop the test
2. Insert control diskette
3. Perform re-IML
4. Return machine


Test Handling - Results

Screen displays:

- A** IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
- B** CENTRAL COMPLEX TEST SELECTION
- C**



- A** Reference code
- C** Symptom code display field
- B** Status of test
- D** Run mode selection field



Disk/Tape Inline Test - General

Before running the lLTs, read the following:

- Do not run other tests concurrent to the 'disk/tape inline' tests.
- Only one device and its controller can be tested at a time.

1. On devices with a CE panel (for example, 3340), set the CE switch to CE mode.

2. For 3340: Bring inset on the handle of the data module in 'write enable' position.

For 3370: Set the Read/Write enable switch to the 'write enable' position.

- The device to be tested cannot be used by the customer and must be taken out of the operating system by respective control statements.

If the customer program tries to access this device, the command will be terminated and 'Intervention Required' is indicated.

- ILT routines may consist of several tests, which run sequentially or can be executed separately, as required by the MAPs.
- Various run and control modes for execution can be selected, when told by the MAPs.
- Status messages will be updated in parallel at the screen and at the CE panel.
- By pressing MOD SEL or DIAG key, running lLTs are discontinued, for example, for man Ops. 3370 lLTs controlled by the MD cannot be discontinued, see 'Exceptions for 3370'.
Note that the lLTs are not automatically restarted unless the lLT program is recalled by pressing the CHG DPLY or the CNCL key.
- Remote operator console support and remote lLT execution are mutually exclusive.

Exceptions for 3310

- Do not select an individual test of routine 71.
- Do not run routine 74 stand-alone.

Exceptions for 3340/3344

Inline Test Handling with String Switch Feature Installed

The 4331 processor supports the string switch feature only in static mode. This means that via the toggle switches A and B on the 3340 controller one interface has to be enabled while the other interface must be disabled.

The enabled string switch interface is then seized by the FTA of the 4331 processor with the first addressing of a 3340/3344 and remains in this state until power at the control unit is turned off.

Therefore the inline tests must be executed on the presently seized interface except for the Dynamic String Switch Routine B6.

Dynamic String Switch Routine


To test the string switch feature dynamically use routine B6.

- No concurrent maintenance possible. All customer applications must be terminated which use the interfaces to be tested.
- Press STOP key at the operator console keyboard.
- Enable also the second interface (both switches A and B must now be set to 'enable'). Remember that the interface just enabled must be disabled again under item 5.
- Run routine B6 as described in the 3340 MLM. Display of control information '8DFF' and '3FFF' is shown only on the 3340 CE panel.
- After completion of routine B6 turn power off and set the interface switch which was enabled under item 3 to disable. Turn power on again. The enabled interface will be seized again with the first addressing of a 3340/3344 device.

Exceptions for 3344

Each 3344 device represents four logical 3340 devices. Each 3344 has therefore four logical 3340 addresses of which the lowest one is identical to the physical address of the 3344. To run lLTs on 3344 devices enter the lowest 3340 logical device address.

Example:



Disk/Tape Inline Test - General (continued)

Exceptions for 3370

The primary CE maintenance tool for the 3370 disk device is the Maintenance Device (MD). Only with the MD attached the complete 3370 diagnostics can be executed and errors or other information provided by the diagnostics can be analyzed. Therefore the MD should always be used if available. However the 3370 diagnostics can be run without an MD attached. In this case the diagnostics run in a limited version on a GO - NO GO basis, as a quick checkout if the device is working or not.

Caution: As long as the 3370 ILTs are controlled from the system console:

- Do not select any other routine than E0, EF, or FC.
- Use default run option only.
- Do not select control options 10, 20, 2X, and 37.

A violation of these rules may cause irregular results and can destroy customer data.

How to Select 3370 Inlines

After the device type and address have been entered as directed by item 3 on page 4410, the 3370 INLINE ROUTINE SELECTION menu is displayed. If an MD is available go to selection 'EF'. Without an MD available proceed with selection 'E0'. Notice the WARNING displayed on the lower part of the screen.

Selection of Routine-ID EF

1. If a MD is available, enter selection 'EF', press ENTER. Wait for CA ANSWER on line 23.
2. Now the system is ready to communicate with the MD. For MD setup see 3370 MIM MLX2 page Entry 3.
For all further actions follow the instructions shown on the MD-display.
3. If no System - MD communication is possible (MD will timeout), the system console displays
3370 C0 INVALID D0C00080
on line 23.
To recover proceed as follows:



To page 4465

- Press the PF-key on the MD keyboard. Re-enter routine-ID 'EF' at the system console and run routine 'EF'.
4. Do not enter any input via the system console when the diagnostics are controlled by the MD. This would cause loss of synchronization and require a complete ILT restart.
 5. Instruct the customer not to use 'customer man-ops' during run of 3370 ILTs. This would also cause a timeout of the MD and requires a complete ILT restart.
 6. The message CA ANSWER on line 23 may be permanently displayed but should be ignored as long as the ILTs are controlled from the MD. The device tested must be in CE mode. Set/reset of the CE mode is controlled by the MD, see 'Selection of Routine-ID 'FC'.

Selection of Routine-ID E0

1. If no MD is available enter routine selection 'E0', press ENTER. Wait for CE ANSWER on line 23.
 2. Press the CHG DPLY key to get the TAPE/DISK INLINE RUN/CONTROL OPTIONS displayed, see D on page 4415.
 3. Press ENTER. The selected routine is started with the default run and control option.
 4. Press CHG DPLY key again to release the screen to the customer. Routine selection E0 causes the routines E0, E1, E3, E5, E7 and EB to run in a chained mode on a GO - NO GO basis.
Normal completion of this routine string causes
3370 CF STOPPED D0EB0080
to be displayed on line 23. This means the diagnostics run error-free.
- At this point another device to be tested can be selected or the ILTs can be terminated. In both cases the CE mode must first be reset, see 'Reset CE mode'.
 - If during the routine execution an error is encountered the line 23 shows the message
3370 E1 ERROR DEXXX81
Reset the CE mode, see 'Reset CE Mode', and terminate the ILTs. Call for an MD and run the diagnostics from the MD.

Selection of Routine-ID FC

Purpose
The routine string executed under selection 'E0' requires that the device to be tested is set to CE mode. Only one 3370 drive (address) per controller can be set to CE mode at a time.

Set CE Mode
For selection 'EF' CE mode is automatically set by the MD. For selection 'E0' CE mode is automatically set in routine E1 test 2.

Reset CE Mode
1. Enter routine selection FC, press ENTER. Wait for CA ANSWER on line 23.
2. Press CHG DPLY key to get the TAPE/DISK INLINE RUN/CONTROL OPTIONS displayed, see D on page 4415.
3. Press ENTER. The selected routine is started with the default run and control option.
Normal completion of the routine 'FC' causes the display
CF STOPPED D0FC0080
on line 23 and a rezero operation to the tested device. This causes a device end interrupt to inform the system that the device is available again for the customer. Continue with step 4. If routine FC encounters an error, terminate the ILTs and call for an MD to run diagnostics from MD.
4. Terminate ILTs or select next device to be tested.

Disk/Tape Inline Test - General

Exceptions for 8809

- Before starting the tape inline tests insure that:
 1. A good scratch tape is loaded.
 2. The tape has been rewound to the load point.
 3. The tape drive is READY.
- Unless otherwise instructed by the MAPs, always run the Diagnostic Linked Series (DLS) starting with routine 40.
- In the reference code D8RRRR81 (line 23 on the screen) RRRR is the two-byte Isolation Code, where the left byte of RRRR indicates the routine identifier and the right byte indicates the stop code.
- Before terminating tape inline tests (Control Option 30) start test routine 6A, '8809 Termination'.

Disk Tape Inline Test

Test Handling - Actions



From page 4465

Prerequisites

- Before starting any Disk/Tape Inline Test you should be familiar with the Inline Test General Description (see pages 4400 through 4402).
- IML must have been completed successfully with the control diskette (FU1) installed.
Caution: Do not Re-IML when the customer is using the system at the same time.
- If the inline tests should run concurrently to the customer's application the device to be tested cannot be used by the customer. Ask the system operator to unassign the device.
- The disk/tape device must have been set up for testing as described in the maintenance documentation of the appropriate device.
- Initiation of the ILTs is only possible from the operator console; further operation may be controlled from the operator console, from the CE panel (for example, 3340), or from the maintenance device (MD) of 3370.

How to Select and Run Inline Tests

A detailed flowchart for 'Inline Test Handling' is shown on pages 4440 through 4460.

Note: In this procedure the word 'enter' always means that some data has to be typed in from the keyboard and then the ENTER key must be pressed.

1. Call M/S PROGRAM SELECTION by holding down the ALT key and pressing the DIAG key. Screen **1** is displayed.
2. Enter the selection code for 'DISK/TAPE INLINE'. Screen **2** is displayed.

Note: If the microcode is located on a set of two diskettes you will be prompted to insert now the second diskette (FU2). After termination of the inline tests reinsert the first control diskette (FU1).

Test Handling - Results

Screen displays:

1 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

2

DISK AND TAPE INLINE TEST SELECTION

A

X=UNIT
A

ENTER TYPE AND DEVICE ADDRESS (CUU)

SELECTION: 8 B

DATA: ADDR:
ANSWER

A Shows all possible machine types for which the inlines apply.

B Field to enter machine type (take from **A**) and device address (CUU).

Example: Type 3340 = 2
CUU, for example = 200
SELECTION: 82200 _____

Disk/Tape Inline Test (continued)

Test Handling - Actions

3. Select the device type code from field **A**. Enter the device type code and the physical device address in the selection field **B**. Screen **3** is displayed.

For 3344 device address see 'Exceptions for 3344' on page 4400.

4. For 3370 devices further test handling is done from the maintenance device (MD), if available. (See 'How to Select 3370 Inlines', page 4401.)

For devices other than 3370 continue here. Select the routine identifier from field **C** and enter it in the selection field **D**. (See 'Exceptions for...', page 4400 through 4402.)

On the screen, lines 1-20 will change from DISK/TAPE INLINE RUN/CONTROL OPTIONS to the system message buffer (customer screen display).

5. Observe the status field **I**, and wait for message 'XXXX CA ANSWER XXXXXXXX'. (A layout of the status field is shown on page 4420.)
6. For a 3340/44 device further test handling can be done from the 3340 CE panel. For other device types continue with step 7.
7. Press CHG DPLY (change display) key. Screen **4** is displayed. You must always have this screen when you want to change run/control options.

Note: The CHG DPLY key causes the screen display to change from the system message buffer to the DISK/TAPE INLINE RUN/CONTROL OPTIONS picture, and vice versa.

3

XXXX ROUTINE SELECTION

C

SELECTION: 8 **D**

J-----XXXX CA ANSWER XXXXXXXX

4

DISK/TAPE INLINE RUN/CONTROL OPTIONS

E **F**

DEFAULT RUN OPTION = 08 **K**

*DISPLAY OF RUN INFO
PREVENT / ALLOW PRESS PF4

SELECTION: 00..... **L**

H TEST **G**

DATA: ADDR: **J**

SEL RUN OPT:08 CUU =XXX
RTN ID = XX QVY NR = ..
TST NR = .. QVY ID = ..

- C** Menu of available inline routines for selected I/O.
- D** Enter field for the routine ID offered in **C**.
- J** Status and reference code

UUUU	IS	STATUS	UU RR RR XX	B1 B2 B3 B4
Unit Type	S	Status Message	Reference Code	4 Bytes Additional Information
----	T			
3310	T			
3340	U			
3344	S			
3370				
8809				
	C O D E			

For details refer to page 4420.


- E** Table of all run options.
- F** Table of all control options.
- G** This part of the run parameters may be stopped to be displayed.
- See message **L**.
- H** Enter field for run and control options. Normally the selected control option (for example, 00) is displayed here.
- J** Status and reference code (see above table).
- K** Run parameter field. The shaded parts are parameters from the program. The other parameters had to be entered before and also can be altered during inline selection.
- L** Additional error bytes or run information.

Disk/Tape Inline Test (continued)

Test Handling - Results

8. At this point you can enter run/control options in the selection field **H** . If no option is entered, the default options will be used.
Default options are:
Run option = 08 (No loop, link, stop on error)
Control option = 00 (start/stop diagn execution)
For a description of run/control options, see pages 4425 through 4435.
9. Start test execution by pressing the ENTER key.
Caution: Never press the START key at the 4331 operator console when inline tests are running stand alone (no operating system loaded). This will result in a hangup condition.
10. If the inline tests should run at the same time as customers programs, press CHG DPLY to display the system message buffer. The operator console is now available for the system operator.
The status of the inline tests can be observed continuously in line 23 **J** . (A description of the status field is shown on page 4420.)
11. For any intervention to the inline operation (for example, stop inline test execution) you need the DISK/TAPE INLINE RUN/CONTROL OPTIONS picture displayed. Press CHG DSPY key, if necessary, to return to screen **4** .
12. Depending on the run option selected, the inline tests will run until:
- The first error is detected or
 - The end of the routine(s) is reached or
 - The execution is stopped manually.
- If an error has been detected during test execution, a reference code is displayed in the status field **J** . Up to 15 additional error bytes (numbered 1 through 9 and A through F) may be displayed in field **L** . (Refer to the flow chart on page 4450, Entry E, for more detailed information about the display of the error bytes.)
- If you want to restart inline tests, enter control option 00 in the selection field **H** .
If you want to stop or terminate inline tests, refer to 'How to Stop or Terminate Inlines' (see next page).

Test Handling - Results



Example: Error Display for 3340

LU: 80009222

DISK / TAPE I N L I N E R U N / C O N T R O L O P T I O N S

RUN OPTIONS										CONTROL OPTIONS									
*01 = NO LOOP, LINK, BYP ERR STOP										00 = START/STOP DIAGN. EXEC.									
*02 = LOOP + RTN, STOP ON ERR										*10 = START DIAGN. PARAM. ENTRY									
*03 = LOOP + LINK RTN, BYP ERR STOP										*20 = ADV ERROR/PARAM. DISPL.									
*04 = NO LOOP, NO LINK, STOP ON ERR.										*2X = SELBYTE X OFF ERROR/PARAM.DISPL.									
*05 = NO LOOP, NO LINK, BYP ERR STOP										*30 = TERMINATE INLINE MODE									
*06 = NO LOOP, LINK, BYP ERR STOP										*31 = I/O ADDRESS ENTRY (OC UU)									
*07 = LOOP SINGLE RTN, byp ERR STOP										*33 = CONCURRENT RUN RATE SEL									
08 = NO LOOP, LINK, STOP ON ERR										*33 = RESET ERROR LOG MODE									
08 = DEFAULT RUN OPTION										*36 = SET ERRDR LOG MODE									
*XX = INVALID FOR 3370										*37 = START DIAGN. PARAM. DISPL.									
										*3C = DISPL. ILT MNTR. REL LVL.									
										*40.. FF = RTN. ID SELECTION									

L

DIAGN 1 2 3 4 5 6 7 8 9 A B C D E F

ERROR 42 00

SELECTION: 00

TEST 370 TIMER: ON DISK DATA: ADDR:

 TOD: SEC

 3340 E1 ERROR DAA2428100

- E** Table of all run options.
- F** Table of all control options.
- G** This part of the run parameters may be stopped to be displayed.

See message **L** .
- H** Enter field for run and control options. Normally the selected control option (for example, 00) is displayed here.
- J** Status and reference code (see page 4420).
- K** Run parameter field. The shaded parts are parameters from the program. The other parameters had to be entered before and also can be altered during inline selection.
- L** Additional error bytes or run information.
- J** Status and reference code.

Disk/Tape Inline Test (continued)

Test Handling - Actions

How to Change the Run Option

If you are asked to change the run option type in the ID **E** of the option you want, behind SELECTION: Overwriting 00, press ENTER. The selected run option is then displayed in run parameter field **K** . 00 will again be displayed behind SELECTION.

For details refer to 'Run Options - Explanation' (page 4425).

How to Change the Control Option

If you are asked to change the control option, do the following:

- 1. Stop running inline if not yet stopped by pressing ENTER.
- 2. Enter control options and parameters as stated in the device - MLM, press ENTER.

For details refer to 'Control Options - Explanation'.

How to Stop or Terminate Inlines

1. Stopping of Inline Tests

Enter run option 00 in the selection field **H** . This stops a running test, but does not terminate inline mode.

2. Termination of Inline Mode

- Exception for 3370 Disk Inlines

Before terminating 3370 Disk Inlines (control option 30) refer to 'Reset CE Mode', page 4401.

- Exception for 8809 Tape Inlines

Before terminating tape inline tests (control option 30), start test routine 6A '8809 Termination'.

- To terminate inline mode any running test must be stopped first (see step 1). Then enter control option 30 in the selection field **H** . This terminates inline mode, resets the TEST indicator (line 21), and displays the system message buffer (customer screen).

Note: If control option 30 fails to terminate inline mode, a 4331 hardware malfunction is suspected. In this case, the customer must terminate his programs and perform a system reset. Follow the reference code displayed.

- If control diskette FU2 has been installed, insert control diskette FU1. Caution: Do not press the IML key.

Any error log that occurred while diskette FU2 was installed is stored on this diskette. Check diskette FU2 for new log entries.

- Reset of CE mode for 3340/44

Turn off the CE mode switch at the CE panel and press ATTENTION.

Disk/Tape Inline Test (continued)

Status Display Examples and Description

DISK / TAPE

INLINE

RUN / CONTROL

OPTIONS

RUN OPTIONS

* 01 = NO LOOP, LINK, BYP ERR STOP

CONTROL OPTIONS

00 = START / STOP DIAGNOSTIC EXECUTION

08 = DEFAULT RUN OPTION

* 37 = START DIAGN PARAMETER DISPLAY

* 3C = DISPL ILT MNTR REL LVL

* 40.. FF = ROUTINE ID SELECTION

* XX = INVALID FOR 3370

DIAGN 1 2 3 4 5 6 7 8 9 A B C D E F SEL RUN OPT : 08 CUU = 210

ERROR 20 00 26 83 64 RTN ID = A1 OVY NR = 11

TST NR = 01 OVY ID = 01

SELECTION : 00.....

TEST

Line 23

3340 E1 ERROR DAA1208100268364

- Note 1:
- 'ANSWER' indicates that some CE action is required.
 - 'ERROR' indicates that the disk/tape inline tests have detected a failure condition.
 - 'INVALID' indicates that invalid data has been entered in the SELECTION-field.
 - 'LOADING' indicates that the inline test routines are being loaded.
 - 'RUNNING' indicates that an inline test is in progress.
 - 'STOPPED' indicates that the test has successfully completed.

Note 2:
An unexpected failure condition was detected and has stopped test execution. This can be caused by a missing TAG VALID signal, for example.

Device	Inline Status	Status Message (Note 1)	Status or Reference Code	Additional Information Bytes				Meaning	Action
				B0	B1	B2	B3		
D D D D	I S	M M M M M M	U U R R R R X X						
X X X X	40 or 41	ANSWER	D 0 X X 0 0 8 0					Set error logging mode. Reset error logging mode. Concurrent run rate selection. Parameter display mode, YY = parameter bytes. I/O address entry mode. Routing is being loaded. Routine or test running. Dynamic error display, ZZ = error bytes. Invalid keyboard entry. Routine ready for execution. Waiting for CE-intervention. End of test (no error detected). Diagnostic parameter entry mode. ILT monitor release level display Diagnostic error stop display, ZZ = error bytes. Diagnostic error stop display, ZZ = error bytes. Program error stop display.	See control option 36 (page 4435 and 4460). See control option 35 (page 4435 and 4460). See control option 33 (page 4435 and 4460). See control option 20 or 2X (page 4430 and 4455). See control option 31 (page 4435 and 4455). None. None, or press ENTER to stop. None (see page 4425 'Dynamic Error Display'). See F on page 4450. See A on page 4440. See B on page 4440. None, or restart, or terminate. See control option 10 (page 4430 and 4455). See control option 3C (page 4435 and 4460). Go to corresponding MAP. Go to corresponding MAP (Note 2). Go to corresponding MAP.
	42 or 43	ANSWER	D 0 X X 0 0 8 0						
	50	ANSWER	D 0 X X 0 0 8 0						
	6X	ANSWER	D 0 X X Y Y 8 0	YY	YY	YY	YY		
	70 or 71	ANSWER	D 0 X X 0 0 8 0						
	82	LOADING	D 0 X X 0 0 8 0						
	8C	RUNNING	D 0 X X 0 0 8 0						
	8D	ERROR	D X X X Z Z 8 1	ZZ	ZZ	ZZ	ZZ		
	C0	INVALID	D 0 X X 0 0 8 1						
	CA	ANSWER	D 0 X X 0 0 8 0						
	CE	ANSWER	D 0 X X 0 0 8 0						
	CF	STOPPED	D 0 X X 0 0 8 0						
	DX	ANSWER	D 0 X X 0 0 8 0						
	E0	ANSWER	D 0 X X 0 0 8 0						
	EX	ERROR	D X X X Z Z 8 1	ZZ	ZZ	ZZ	ZZ		
	EX	ERROR	D X F F F F 8 1	ZZ	ZZ				
	F5	ERROR	D 0 X X 0 0 8 1						

Run Options - Explanation

- Are offered by the 'Disk/Tape Inline Run/Control Options' picture.
- Allow selection of a particular routine run mode, if the default run mode ('08') is not desired.
- Selection of a run option de-activates the option previously selected.
- Selection is possible via operator console or via CE panel. Diagnostic execution must be stopped before.
- The selected run option is displayed in the field 'SEL RUN OPT.' of the 'RUN INFO' on screen.

Dynamic Error Display

- Run options 01, 03, 05, and 07 do not stop the test when an error is detected. Errors are displayed dynamically, while the test continues execution.

The error status information is displayed as follows:

Line 17 and 18 on the screen:

The message DIAGN ERROR, and up to 15 error bytes.

Line 23 on the screen:

The inline status '8D', the message ERROR, and the reference code.

- In case of intermittend errors, the message ERROR (line 23) is replaced by the message RUNNING while the error status information (line 17 and 18) remains on the screen.
CAUTION: The error status information will be reset when the loop is stopped (control option 00).
- The dynamic error display is also used for certain I/O device adjustments. As long as the adjustment is not satisfactory, the message ERROR is displayed (line 23). When the adjustment has been corrected, ERROR is replaced by RUNNING. In this case the error status information (line 17 and 18) is meaningless.

Run option (Hex)	Meaning of bits				Description		
	4 Reset run options	5 Inhibit routine linking	6 Loop routine	7 Bypass error stop			
01				X	Single execution	of a stand - alone routine or a linked series of routines	Dynamic error display
02			X		Looping	of a stand - alone routine or a linked series of routines	Stop on error
03			X	X	Looping	of a stand - alone routine or a linked series of routines	Dynamic error display
04		X			Single execution	of a stand - alone routine or any routine of a linked series of routines	Stop on error
05		X		X	Single execution	of a stand - alone routine or any routine of a linked series of routines	Dynamic error display
06		X	X		Looping	of a stand - alone routine or any routine of a linked series of routines	Stop on error
07		X	X	X	Looping	of a stand - alone routine or any routine of a linked series of routines	Dynamic error display
08 (default)	X				Single execution	of a stand - alone routine or a linked series of routines	Stop error

Disk/Tape Inline Tests (continued)

Control Options - Explanation

- Are offered by the 'Disk/Tape Inline Run/Control Options' picture.
- Allow selection of a particular control mode if the default control mode ('00') is not desired.
- Selection is possible via operator console or via CE panel. Diagnostic execution must be stopped before.
- Selection of a particular control option is indicated by an accompanying status display.

Opt.	Name	Description																		
00	Start/stop routine execution (default).	• Allows starting/stopping or restarting of diagnostic execution by pressing ENTER.																		
10	Start diagnostic parameter entry	• Allows entering of parameters to loop tests for scoping or to define seek addresses, etc. For details of parameters, refer to the routine description of the corresponding I/O manual. • <i>Parameters Selection for Test Run</i> If a routine consists of more than one test, the first diagnostic parameter allows to select different run modes of test execution: XX = first diagnostic parameter - selects test number -- selects test run parameter The following test run parameters are valid: <table><tr><th>Run</th><th>Meaning</th></tr><tr><th>Parameter</th><th></th></tr><tr><td colspan="2">-----</td></tr><tr><td>X'00'</td><td>Start routine execution with test 1 and run to end of routine (default).</td></tr><tr><td>X'0X'</td><td>Loop test (X).</td></tr><tr><td>X'2X'</td><td>Start routine execution with test (X) and run to end of routine.</td></tr><tr><td>X'4X'</td><td>Start routine execution with test 1 and run to end of test (X) and loop test (X).</td></tr><tr><td>X'8X'</td><td>Execute one pass of test (X).</td></tr><tr><td>X'CX'</td><td>Start routine execution with test 1, run to end of test (X) and stop.</td></tr></table> If an invalid test number or a wrong run parameter is entered, the error code '01' is displayed. Example: DD710181.	Run	Meaning	Parameter		-----		X'00'	Start routine execution with test 1 and run to end of routine (default).	X'0X'	Loop test (X).	X'2X'	Start routine execution with test (X) and run to end of routine.	X'4X'	Start routine execution with test 1 and run to end of test (X) and loop test (X).	X'8X'	Execute one pass of test (X).	X'CX'	Start routine execution with test 1, run to end of test (X) and stop.
Run	Meaning																			
Parameter																				

X'00'	Start routine execution with test 1 and run to end of routine (default).																			
X'0X'	Loop test (X).																			
X'2X'	Start routine execution with test (X) and run to end of routine.																			
X'4X'	Start routine execution with test 1 and run to end of test (X) and loop test (X).																			
X'8X'	Execute one pass of test (X).																			
X'CX'	Start routine execution with test 1, run to end of test (X) and stop.																			

Opt.	Name	Description
20	Advance error/parameter display	1. If entered during status display 'CE ANSWER', the last error message will be retrieved and displayed in lines 17, 18 and 23. • The status display on the screen and in the Program Control Display of the CE panel will be 'E1'. • The first error message byte will be intensified in line 18, and will be displayed in the Data Display of the CE panel. 2. If entered during status display 'EX ERROR', the current error message on the screen will be repeated. • The status display on the screen and in the Program Control Display of the CE panel will advance to 'EY' (Y = X + 1). • The error message byte Y will be intensified in line 18, and will be displayed in the Data Display of the CE panel. 3. If entered during status display '6X ANSWER', the diagnostic parameter display on the screen will be repeated, and • The status display on the screen and in the Program Control Display of the CE panel will advance to '6Y' (Y = X + 1). • The diagnostic parameter byte Y will be intensified in line 18, and will be displayed in the Data Display of the CE panel. Note: Byte number X is advanced by 1 every time option 20 is entered until the end of the error message or the end of the diagnostic parameter display is reached. This is indicated by status 'CE' on the screen and in the Program Control Display of the CE panel.
2X	Select byte 'X' of error/parameter display	• To be used mainly for diagnostic execution via CE panel (like option '20'). Allows selection of a particular error byte or parameter byte to be displayed. • The selected byte is displayed on the CE panel, and also on the screen as the first byte in the 'Additional Information Bytes' of the status field (line 23). The selected byte is intensified in the error/parameter record on the 'Run/Control Options' picture.



Control Options - Explanation (continued)

Opt.	Name	Description
30	Terminate inline mode	Used to terminate inline testing of the selected device.
31	I/O address entry	- Used to select another device for inline testing, after testing of the previously selected device is finished. To run inlines subsequently for other devices (for example, during installation) use control option '31'. - Stop diagnostic execution by pressing ENTER. - Enter control option '31'. The status field  will ask for the channel portion of the I/O address. - Enter channel address, format '0C', 'C' is channel number (Example: '02' for 3310). The status field  will ask for device address of I/O device. - Enter the control unit and device address, format 'UU' Control Unit address _____ Device address _____ Example: '42' for 3310 The status field  will show 3310 CE ANSWER DO XXXX 80 indicating that the I/O address has been accepted.
33	Concurrent run rate selection	- Allows selection of a variable run rate for diagnostic execution concurrent to customer's application. The customer should be consulted before run rate selection because the run rate may influence the customer's system performance and the CE time to repair a device out of order. - Run rate options '00' to '08': 00 = Fastest diagnostic run rate with the greatest impact on system performance. 05 = Default run rate, set automatically during initiation of inline mode. 08 = Slowest diagnostic run rate with the least impact on the system performance. - The selected run rate has no effect if the PU is stopped or on nonconcurrent maintenance. <i>continues in next column</i>


Opt.	Name	Description
33		Invalid run rate entries (higher than 08) will force automatically default run rate 05.
35	Reset error logging mode	Resets logging mode for one device. Error logging mode set for other devices remains active.
36	Set error logging mode	- Allows logging of detailed sense information about successfully retried errors during customer operation. It is possible to set this option for more than one device in order to investigate device interrelationships. Once set, the option will remain set until a reset (control option 35) is issued or the machine is IML-ed. - If more than one device is to be set to this mode, the option must be applied separately for each device address. CAUTION: 'Intervention Required' may be indicated if a device is selected for inline mode concurrent with customer operation. Therefore, notify the system operator that the selected device is temporarily not available for his application program. The customer can use the device again after you have terminated inline mode.
37	Start diagnostic parameter displays	- Allows displaying of the actual diagnostic parameters (default parameter or entered parameters) - If this option has been selected via the operator console, all parameters are displayed in the message area of the 'Run/Control Options' picture: Byte 0 in place of Error Code. Bytes 1 to 4 in the 'Additional Information' of the status field (line 23). Status '60' ANSWER is displayed. - The first byte is displayed in the 'Program Control Display' of the CE panel. To display additional bytes or to select a particular byte 'X', option '20' or '2X' may be selected. - If status '6X' is displayed, the 'X' corresponds to the parameter byte 'X'.
3C	Display ILT monitor release level	Displays the release level of the PU part of the ILT monitor.
40 to FF	Routine ID selection	When execution of a selected routine is completed, another routine may be selected by entering the routine ID.

Inline Test Handling


1. On devices with a CE panel (for example, 3340), set the CE switch to CE mode.
2. For 3340: Bring inset on the handle of the data module in 'write enable' position.




Inline Test Handling (continued)



Inline Test Handling (continued)



Inline Test Handling (continued)



MLX Cross Reference

Outgoing References

Exit from 4331 Documentation	To	
	3340 MLM*/ 3344 MLM*	3370 MIM*
Page/Subject	Exit #	Exit #
MAP OE00	1	1
MAP DA70	2	
MAP DE70		2
STM page 4440	3	
STM page 4411		3
STM page 4360 for 4331-1 and page 4355 for 4331-2 (Control Interface Test)		4

* Refer to the MLX pages of the referenced MLM/MIM.

Incoming References

Entry from 3340 MLM/ 3370 MLM/MD 3344 MLM		To 4331 Documentation
Entry #	Entry #	Page / Subject
1		STM Disk Inlines
5,7,9,10, 11	1,2,3,4,5, 6,7,8,9	These entries are covered by reference codes. The reference codes given are direct entries to the respective 4331 MAPs. If no reference code is indi- cated go to the 4331 MAP 0000.
	11	Go to page 4410, 'Disk Tape Inline Test'
	12	See Note 1

Note 1: For editing and printing of logged records from the CE-cylinder of the 3370, use the 'compatibility feature environmental data edit program, DMPCECYL'. Use the description which is delivered together with the utility program 'IBM 2311/2314/3330/3340 Emulation on Fixed Block Disks', program number 5747-SA2.

Utilities Program Selection

LV: 80239203

4331 UTILITIES PROGRAM SELECTION

0 = MES UPDATE (A)

1 = REMOTE SUPPORT (B)

2 = MANUAL MCTF INSTALLATION (C)

3 = ALTER CHANNEL NUMBER

4 = FTA CONFIGURATOR

5 = BMPX CONFIGURATOR

6 = HSC CONFIGURATOR

7 = MCTF DISKETTE LOADER (C)

8 = RECORD DISPLAY (D)

9 = DISKETTE IDENTIFICATION (E)

A = COPY CONFIGURATOR (A)

B = DIAGNOSTIC COMMUNICATION (F)

C = TOD CORRECTION

D = DISPLAYS AND PRINTERS

SELECTION: C

4MB VSE TIMER:ON
TOD: SEC

DATA:

ADDR:

0803

- (A) See Section 6
- (B) See the following pages
- (C) See page 4530 and following pages
- (D) For use in case of support
- (E) See page 4542
- (F) See page 4543

Remote Support Facility

Tool Handling - Actions

Prerequisites

- The two RSF cards must be available in position 01A-A2W2 and 01A-A2X4. For switch setting, if an integrated modem card is plugged, see page 4503.
- For additional installation information refer to Installation Manual, page 2060.

How to Select Remote Console Support

RSF is on both the control and the diagnostic diskette.

- Call M/S PROGRAM SELECTION **A**.
Hold down ALT key and press DIAG key.
- Key in selection for 'UTILITIES', press ENTER **B**.
- Select REMOTE SUPPORT, press ENTER **C**.
- Select CONSOLE SUPPORT, press ENTER **D**.
- Give your input.
- Now your system is to be remotely controlled.
- Disconnect the remote link. Most connections will disconnect automatically; field **A** in line 25 disappears.
A connection which does not disconnect automatically must be disconnected by pressing the ALT key and the INTERRUPT key at the same time on the operator's console.

Tool Handling - Results

Screen displays:

A IBM MAINTENANCE AND SERVICE PROGRAM SELECTION

B UTILITIES PROGRAM SELECTION

C REMOTE SUPPORT SELECTION

D


REMOTE CONSOLE SUPPORT	
MACHINE-TYPE...: 4331	CE - NAME.....: - - - - -
MACH-SERIAL-NO: xxxxx	CUSTOMER-NAME.: - - - - -
BRANCH-OFFICE.: - - - - -	CUST.TELEPHONE: - - - - -
REMOTE CONSOLE WITH '3275'.....(Y/N): -	
VOICE TO DATA SWITCHING BY KEYBOARD(?/Y/N):	B
LOW SPEED (600 BPS) WANTED.....(Y/N):	-
INTEGRATED TEST (SEE NOTE).....(Y/N):	Y
GIVE YOUR INPUT AND DEPRESS 'ENTER'	
NOTE: FOR WT INTEGRATED MODEM (38LS) THE TEST MUST NOT BE EXECUTED IF THE HANDSET IS OFF HOOK !	
=====	
TIMER:OFF	DATA: ADDR:
TOD:SEC	A

A Indicator field in line 25.
For explanation see next page.

B By typing in a '?' the following picture appears

REMOTE CONSOLE SUPPORT	
+-----+ VOICE TO DATA SWITCHING BY KEYBOARD (Y/N) +-----+	
THE ANSWER TO THIS QUESTION SHOULD BE 'Y' IF ONE OF THE FOLLOWING SET-UPS ARE INSTALLED AT THE MACHINE:	
. WORLD-TRADE INTEGRATED MODEM (38LS) WITH PSN-FEATURE (LINE-PLATE)	
. EXTERNAL MODEM (E.G.3976-3) WITH 'CONNECT-DATA-SET-TO-LINE' STRAPPING	
. ACOUSTIC COUPLER (E.G. UPAC/EPAC)	
IN THESE CASES THE 'COMMUNICATION-REQUEST' BOTTON (ALT.REQ.) WILL SWITCH THE DATA SET FROM VOICE TO DATA AND VICE VERSA.	
PRESS 'ENTER' TO RETURN	

Remote Console Support Indicator Field (Line 25, Pos. 65 - 80)



Note: If information is required, contact your specialist.

1. System has been set to 6 B. Remote Console

CEM 04 0245

1) C 11
2) 5XN, Enter
3) R370/R Enter

RSF Adapter Interface Cards

The RSF consists of two cards, the 'Common Communication Adapter' (CCA) card and the 'Modem' card, or 'External Interface' card.


The RSF may have one of the following configurations:

CCA	MODEM TYPE	CD CODE	MODEM TYPE
With clock Card code SDI	Integrated Modem	CE 60 or SD 5	US SNAA
	Integrated Modem	CE 62 or SD8	WT SNAA
	Integrated Modem	CE 65 or SE 1	WT LL
	External-Interface EIA/CITT	SD3	Extern
Plug position 01A-A2W2	Plug position 01A-A2X4		

The integrated modem cards have two sets of eight rocker switches as shown in Figure A.

The switches A-H and I or R, depending on the modem card (see Figure B), are used for transmit level setup.

Switch Identification



Note: Only the numbers 1 to 8 are shown on the card.
Figure A

Transmit Level Set-Up

Consult your telephone coordinator for the correct transmit level switch setting




Figure B

External Modem Interface Card - EIA/CCITT V24

General Description

The EIA Interface Card is a 2W-3H Logic Card, which converts the VTL-levels of the CCA card to EIA/CCITT levels of the modem and vice versa.

Wrap


The wrap option 'card wrap' is jumpered to personalize the EIA card to respond to the card wrap test.

Card Wrap Test

If you select the 'integrated test' under REMOTE CONSOLE SUPPORT or the 'adapter test' under RSF DIAGNOSTICS, the following takes place (see also next page):

A command string is executed which performs:

- a) A static CCA card test
- b) A dynamic CCA card wrap test
- c) A dynamic EIA card wrap test




Note: If you execute the cable wrap test, the data path 'C' will then include the cable between the EIA card and the modem.

Jumper Setting

Wrap Options	JUMPERS						
	A	B	C	D	E	F	G
Card Wrap	Remove	Remove	Remove	Install	Remove	Install	Remove

Note: The clocking (modem or CCA clock) does not affect the jumpering.




Voltage: Automatic voltage adaption.

For part numbers refer to plug list in binder MI 30

Signal Flow and Wrap Test in the External Modem Interface


(EIA Adapter Interface)



Signal Type	Meaning
————	These lines are used by the RSF function. They are tested during execution of the adapter test and the EIA cable wrap test (RSF-Diagnostics).
-----	These lines are used by the test function only.
.....	Not used.

Signal Flow in the Integrated Modem Interface

Modem Type: US Switch Network Auto Answer (US SN AA) Card Code CE 60 (SD5)



Note: Set the transmit level as specified by the telephone company. See 'Transmit Level Setup' on page 4503 for adjustment.

US and Canada Modems Adjustments


Card Code	Modem Type	Line Type	Rocker Switch Setting						
			J	K	L	M	N	P	R
CE 60 or SD 5	US SNAA	Switched	OFF	ON	OFF	OFF	OFF	OFF	OFF

The following are obtained automatically:

- 2-wire line connection
- Clear to send delay 230 MS
- Echo Clamp 150 MS
- Signal threshold:
 - ON at 43 dBm (10-20 ms delay)
 - OFF at 48 dBm (5-15 ms delay)

Signal Flow in the Integrated Modem Interface

Modem Type: WT Switched Network, Manual Answer (WT SNMA), Card Code CE 62 (SD8)



WT Modem Adjustment Procedure

1. Equalizer Setting (Receive Level)

Card Code	Modem Type	Line Type	Equalizer Switches						
			I	J	K	L	M	N	P
CE62	WT SNMA	Switched Normal settings: ->	ON	ON	ON	OFF	OFF	ON	ON

The following are obtained automatically:

- Two-wire line connection
- Clear to send delay 230 ms
- Echo Clamp 150 ms
- Signal threshold:
 - On at 43 dBm (10-20 ms delay)
 - Off at 48 dBm (5-15 ms delay)

Note:
Equalizer switches
N - Normal Delay
J - High frequency delay
P - Mid frequency delay
I - Low frequency delay
M - HF amplifier boost

Switch off = delay enabled
Switch on = delay disabled

If unsatisfactory operation is encountered contact your TP specialist for specific information for your installation.

2. Transmit Level Setting

The switch setting for proper transmit level is shown in figure B on page 4503.

Jumper Setting on PSN Feature (Line Plate)

On the PSN (Public Switched Network) the jumpers A, G, K, M, and N must be plugged.

Note on Jumper A: The normal telephone DC voltage level supplied ranges from 26-50 V.

Note on Jumper G: If no telephone set is installed, plug jumper H instead of G.

Connect the DC voltmeter to TP1 and TP2 on the line plate, see Figure 1, to check the DC voltage.

If the supplied DC voltage deviates from the 'normal' range replug jumper A according to the table, Figure 2.





Figure 1

Voltage Level (V)	Jumper Setting
0.5 - 2	F
2 - 3.5	E
3.5 - 4	E
4 - 6	E
6 - 8	C
8 - 9	C
9 - 14	D
14 - 26	B
26 - 37	A) Normal
37 - 50	A)

Figure 2

Signal Flow in the Integrated Modem Interface

Modem Type: WT Leased Line (WT LL), Card Code CE 65 (SE 1)



WT Modem Adjustment Procedure

1. Equalizer Setting (Receive Level).

See figure on the right side for proper switch setting.

Note 1: Equalizer Switches

- CC - Normal delay
- AA - Disable High Frequency Delay
- DD - Disable Mid Frequency Delay
- BB - Disable Low Frequency Delay
- N - Disable HF AMP BOOST

If unsatisfactory operation is encountered on 'worst case' lines, the equalizer switches, AA, BB, CC, DD, and N should be set to off before setting any other equalizer switch.

Contact your TP specialist for specific information for your installation.

2. Transmit Level Setting

Note 2: Set the transmit level as specified by the PTT. See 'Transmit Level Setup' on page 4503 for adjustment. Contact your TP specialist for specific information for your installation.

Card Code	Modem Type	Line Type	I	J	K	L	M	N	P	AA	BB	CC	DD
CE65	WTLL	Leased 2-wire CTS = 30 MS Set Equalizer = Normal CTS = 80 ms CTS = 230 ms	OFF	OFF	ON	X	ON	ON	OFF	ON	ON	ON	ON

The following are obtained automatically:

- Signal threshold:
 - On at -43 dBm (10-20 ms delay)
 - Off at -48 dBm (5-15 ms delay)

Echo clamp setting :
ON = 50 ms delay
OFF = 150 ms delay

See Note 1

RSF-Line Error Statistics

Purpose

Whenever a TP-link is established, a line error statistic is generated. This statistic records the total of send and receive operations and the total of errors which occurred during these operations.

The value of these statistic counters is stored in the support processor and can be displayed with the maintenance program selection 'Line Error Statistics'.

The statistics are generated for each individual TP-session (for example, Data Bank or Remote Console Connection), but the counters are reset at the beginning of each session.

How to Display the Line Error Statistics

The statistics can be displayed with either control or diagnostic diskette inserted.

1. Call the M/S Program Selection **A** .
2. Key in selection for 'UTILITIES, press ENTER **B** .
3. Select REMOTE SUPPORT, press ENTER **C** .
4. Select LINE ERROR STATISTICS **D** .

The statistics can be selected locally or from the remote location, even during a TP-session.

Line errors which occur during a TP-session are also indicated at the system screen picture. In this case the symbol ∇ is displayed in line 25 of the screen.

Screen displays:

A IBM MAINTENANCE AND SERVICE PROGRAM SELECTION

B UTILITIES PROGRAM SELECTION

C REMOTE CONSOLE SUPPORT

D

```
REMOTE-SUPPORT LINE ERROR STATISTICS

NUMBER OF RECEIVE-OPERATIONS: 0000
NUMBER OF RECEIVE-ERRORS.... *0000*
NUMBER OF SEND-OPERATIONS... 0000
NUMBER OF SEND-ERRORS..... *0000*

COUNTERS WILL BE AUTOMATICALLY ERASED WITH
THE NEXT TP-LINK-ENABLE.
PRESS ANY FUNCTION KEY TO RETURN TO THE SELECTION MENU
=====
```

RSF - Diagnostics

Program Handling	-	Actions
------------------	---	---------

Prerequisites

- Remote Support Facility must be installed.
- Control or diagnostic diskette inserted.

How to Select the RSF - Diagnostics

1. Call M/S program selection [A].
2. Key in selection for UTILITIES/REMOTE [B].
3. Select Remote Support [C].
4. Select Diagnostics [D].

How to Use the Individual Tests

The menu offers various tests to check out the remote support facility. Always run the adapter test first.

The selection menu remains on the screen when a test is selected. A status is displayed in field (A) and the message field (B) will display the result of the test. In some cases additional information is given in (B). Whenever a test has ended or is stopped, any test from the diagnostic menu can be selected just by entering the proper selection.

Adapter Test

Enter the proper selection in the selection field, press ENTER. The test starts to run displaying RUNNING in the status field and a message that the test has started [E]. The test cannot be stopped; however, after the test has ended you may restart it by pressing ENTER.

The test ends with SELECT in the status field and a message if the test has encountered an error or not. [F]

Test Handling	-	Results
---------------	---	---------

Screen displays:

- [A] IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
- [B] UTILITIES PROGRAM SELECTION
- [C] REMOTE SUPPORT SELECTION

(A)

SELECT

[D] REMOTE TP-DIAGNOSTICS

A = ADAPTER-TEST D = EIA(V24)-CABLE WRAP-TEST

B = SEND TEST-PATTERN (1200BPS) E = SCOPE RECEIVED TEST-PATTERN (1200BPS)

C = SEND TEST-PATTERN (600BPS) F = SCOPE RECEIVED TEST-PATTERN (600BPS)

R = RESET MODEM TO 'TALK-MODE' (SELECTION 'R' FOR WT ONLY)

(B)

SELECTION:

=====

- (A) STATUS FIELD
- (B) MESSAGE FIELD

[E] R = RESET MODEM TO 'TALK - MODE' (SELECTION 'R' FOR WT ONLY)

>> ADAPTER-TEST STARTED...(RUNTIME =40 SEC) <<

>> NOTE: FOR WT INTEGRATED MODEM (38LS) THE TEST MUST <<

>> NOT BE EXECUTED IF THE HANDSET IS OFF HOOK ! <<

SELECTION: A

=====

[F] R = RESET MODEM TO 'TALK- MODE' (SELECTION 'R' FOR WT ONLY)

>> ADAPTER-TEST ENDED, NO ERROR FOUND<<

>> NOTE: FOR WT INTEGRATED MODEM (38LS) THE TEST MUST <<

>> NOT BE EXECUTED IF THE HANDSET IS OFF HOOK | <<

SELECTION: A

=====

In case of error, see example printout of [F] on next page.

RSF Diagnostics (continued)

Sending a Test Pattern

This test allows you to send test patterns to a remote location for analysis.

You can choose between two selections to send a test pattern with 600 or 1200 BPS. Type in the proper selection and press ENTER. The test normally responds with message H .


If you have an external modem you must switch your modem to 'data' before starting the test, otherwise you get a message G .

The test sends a continuous test pattern until it is stopped by ENTER. The test pattern can also be altered. Stop test and press any PF-key. This causes the message:

SELECT NEW PATTERN: -

to be displayed above the selection field. Type in the new pattern and press ENTER. Any character can be entered but all non-hexadecimal characters are converted into hex characters. The character actually sent is indicated in message H .

A typical test pattern would be X'AA'.



or X '55'



All other characters generate non-regular waveforms.

F (continued)

>>ADAPTER-TEST ENDED <<
>> NOTE: FOR WT INTEGRATED MODEM (38LS) THE TEST MUST <<
>> NOT BE EXECUTED IF THE HANDSET IS OFF HOOK! <<
** HARDWARE ERROR, SEE REFCODE FOR DETAILS **

G

R = RESET MODEM TO 'TALK-MODE' (SELECTION 'R' FOR WT ONLY)
** DATA-SET NOT READY, SWITCH MODEM TO'DATA' **
SELECTION: B >> PRESS 'ENTER' TO STOP THE TEST <<
=====

H

R = RESET MODEM TO 'TALK-MODE' (SELECTION 'R' FOR WT ONLY)
>> NOW SENDING CONTINUOUS X'AA'-PATTERN (1200 BPS) <<
(PRESS ANY PF-KEY TO CHANGE THE SEND PATTERN)
SELECTION: B >> PRESS 'ENTER' TO STOP THE TEST <<
=====

Receiving a Test Pattern

This test allows you to receive a test pattern from a remote location. See also use of acoustic coupler.

Two selections are available to receive the test pattern on either 600 BPS or 1200 BPS. For this test a jumper has to be installed. The first display after the test has been selected **J** tells you the jumper position. Do not forget to remove the jumper at test completion. The test runs continuously but can be stopped/restarted any time by pressing ENTER.

The test pattern received is displayed on the screen together with an 'should be' value and tolerance limits

K

Use of the Acoustic Coupler

If available the EPAC (european portable acoustic coupler) can be used or the UPAC (for US only) to generate the remote signal.

Insert the silent handset of your data phone in the EPAC or UPAC and turn the switch to 'test mode'.

Resetting the Modem to Talk Mode


To switch your data set back from data mode to talk mode enter the selection for 'Reset Modem to Talk Mode' and press ENTER.

```
[J] R = RESET MODEM TO 'TALK-MODE' (SELECTION 'R' FOR WT ONLY)
>> TO SCOPE A TEST-PATTERN ON THE LINE, JUMPER 01A-A2w2-U05 TO U13. <<
1200BPS-SCOPE STOPPED (REMOVE JUMPER AFTER SCOPING)
NOT TRIGGERED
|.....|.....|.....|.....|.....|.....|41.6 US PER DIV
```

[illegible]

- Ⓒ This line displays the selected speed of the test, and in this example the test is stopped.
- Ⓓ Indicates if the received signal is triggered or not.

The trigger point is the slope from 'mark' to 'space'.



This means if you receive a signal with all marks or all spaces the signal would not be triggered.

- (E) The center line shows the expected slope picture of the received signal. The upper line shows the actual received signal. This signal should match with the expected one with variations allowed on both ends, indicated by the outer range on the lower line.
- (F) Time scale in connection with signals displayed (E).

...|.....:.....|..

↑
--One interval=41,6ms if 1200 BPS or
83,3m if 600 BPS

RSF - Diagnostics (continued)

Cable Wrap Test for External Modem
EIA (V24)

This test allows you to check out the inter-
face to the external modem.

The prerequisite for this test is an an
errorfree run of the adapter test.

Enter the proper selection and press ENTER.
This causes picture **L** to be displayed.
Now install the wrap connector and press
ENTER. Test starts and the screen displays
picture **M** showing the signals wihich are
tested.

The test runs continuously allowing the CE to
probe the signals if an error is indicated.
Test must be stopped by pressing ENTER.

L

R = RESET MODEM TO 'TALK-MODE' (SELECTION 'R' FOR WT ONLY)
>> THIS TEST CHECKS EXTERNAL MODEM CABLE ONLY. <<
>> (PREREQUISITE: ERROR FREE RUNNING ADAPTER-TEST)<<
>> INSTALL WRAP CONNECTOR AND PRESS 'ENTER'. <<
SELECTION: D
=====

M

R = RESET MODEM TO 'TALK-MODE'
>> CABLE-TEST ENDED <<
>> NO ERROR FOUND <<

Or in case of error:

G

R = RESET MODEM TO 'TALK-MODE' (SELECTION 'R' FOR WT ONLY)
>> CABLE-TEST ENDED <<
SIGNAL | EIA | BOARD | TLGTE | MDM | | MDM | TLGTE | BOARD | EIA | SIGNAL
(OUT) | CRD | CNCTR | 01E | PLG | | PLG | 01E | CNCTR | CRD | (IN)
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----
+ DTR | J02 | V6D02 | D02 | 20 | --> | 6 | D09 | X6A02 | J09 | DSR +
+ RTS | G03 | V6E04 | B03 | 4 | --> | 5 | B10 | X6B04 | G10 | CTS +
+ SSB | G05 | W6B04 | B05 | 11 | --> | 8 | D12 | X6E02 | J12 | DCD +
+ DRS | J06 | W6C02 | D06 | 23 | --> | 22 | B13 | X6E04 | G13 | RI +
+ TD | G07 | W6D04 | B07 | 2 | --> | 3 | B04 | W6A04 | G04 | RD -
-----|-----|-----|-----|-----|-----|-----|-----|-----|-----|-----
+ = APPROX. +6V - = APPROX. -10V OR FLOATING
** HARDWARE ERROR, SEE REFCODE FOR DETAILS **
SELECTION: D
=====

- G** This line shows an error. The signal TD (Transmit Data) was sent
out with a + level but returned as RD (Receive Data) with - level.
- H** For signal names refer to page 4505.

Temporary Storage and Display of Data Bank Information

Program Handling - Actions

Purpose

This function allows to store up to 20 screen pictures onto the diagnostic diskette for retrieval.

Each time a new data bank connection is established, the data retrieved is stored starting in position 1 of the 20 position storage area, thus overwriting the information received during the last data bank connection.

How to Store Data Bank Information

1. Insert diagnostic diskette into system drive.
2. Establish data bank connection. Information retrieved from the data bank may be stored picture by picture pressing the COPY key. The Copy-key function causes at the same time a printout, if a console printer is attached.

How to Display the Stored Data Bank Information

1. Call M/S Program Selection **A**
2. Key in selection for UTILITIES **B**
3. Select REMOTE SUPPORT **C**
4. Select REF CODE FIX DISPLAY **D**

Press ENTER after picture D appears on the screen. This displays the first picture of the stored data bank information. Use the Copy-key function to get a printout on the console printer, or use the FRIEND PRINT LOG function. Press ENTER to get next picture displayed, and so on until the message ALL SCREENS DONE is displayed.

Program Handling - Results

Screen displays:

- A** IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
- B** UTILITIES PROGRAM SELECTION
- C** REMOTE SUPPORT SELECTION

D

```
*** REF-CODE FIX DISPLAY ***

TO PRINT THE SCREENS STORED BY
REMOTE ACTIVITIES THE COPY PRINTER
MUST BE ACTIVE OR FRIEND MUST BE SET UP
TO PRINT THE SCREEN.

PRESS ENTER TO START, THEN ENTER FOR NEXT DISPLAY.
PRESS COPY KEY TO PRINT.
FOR IRECA UPDATE OR
MCTF LOCATE PRESS PF1      See Note
```

Note: For installing a IRECA update or MCTF received from a data bank refer to page 4517.

FRIEND PRINT LOG Function

Use this function to get a copy printout of the screen display on a channel-attached printer. Proceed as follows:

1. Perform system IML with the control diskette (if not done before).
2. Perform system reset clear (manual operation selection 'C').
3. Change diskette - insert the diagnostic diskette.
4. Call M/S Program Selection, key in selection for FRIEND.
5. Wait until 'FRIEND LOAD IS COMPLETED' is displayed on screen.

6. Change diskette - insert the control diskette.

7. Perform 'Program Reset' (manual operation selection 'P'), then

- Press CANCEL key
- Press START key
- Press ENTER

The FRIEND picture is now displayed.

8. Enter the secondary printer address together with the keyword LOG separated by a comma; for example, 2E,LOG.

9. Press ENTER.
The intensified display PRNTLOG is shown in the status field.

10. Select screen image or log picture to be printed. Press the COPY key to get a copy printout. For every screen display you want to copy, the COPY key must be pressed again.

To restart the FRIEND after the PRNTLOG function, insert the control diskette, call the MODE SELECTION picture and perform:

1. Program Reset
2. Program Restart

You may now proceed with any other FRIEND function or if you want to use PRINT LOG again, continue with item 8 of the described procedure.

How to Install an IRECA Update or MCTF Received from a Data Bank

Purpose

With the help of utility programs it is possible to retrieve 'fix-data' from a data bank, see 'Temporary Storage and Display of Data Bank Information'. The utility program REF-CODE FIX DISPLAY offers a subsection which allows you to search the received data for any IRECA update or MCTF. If an IRECA update or MCTF is found it can be directly written onto the proper diskette by applying the following procedure.

Handling Procedure

- 1. Insert the diagnostic diskette on which the data bank information is stored.
- 2. Call M/S Program Selection
- 3. Key in selection for UTILITIES
- 4. Select REMOTE SUPPORT
- 5. Select REF-CODE FIX DISPLAY
Press PF1 to locate first IRECA update or MCTF. The program searches the data received from the data bank for any IRECA update or MCTF. The first update found is displayed together with the message

PRESS PF1 FOR MCTF/IRECA UPDATE; OR PF10 TO CONTINUE

Press PF1 to update IRECA with the displayed data or to install the displayed MCTF.
Press PF10 to continue to search the received data for the next IRECA update or MCTF.
To install a located IRECA update or MCTF proceed as follows:

For IRECA Update

- 6a After you have located the desired update, press PF1. You are then prompted to insert the correct diskette (DD1 for 4331-1 or DD2 for 4331-2). Insert the diskette to be updated, press ENTER. The corresponding update program is called and the

update is stored without further manual intervention. After the completion of the update, the REF-CODE FIX DISPLAY program changes automatically to the IRECA program.
If more than one update has to be installed, repeat procedure starting with item 2.

For MCTF Update

- 6b After the desired MCTF is located press PF1. You are then prompted to insert the correct diskette. Insert diskette to which the displayed MCTF applies, press ENTER. The MANUAL MCTF INSTALLATION picture is called with the MCTF information you want to install. Before the program stops it executes a 'diskette read/write test'. A message is displayed asking you not to interrupt the test. When the test stops the selection for storing a MCTF is already entered in the SELECT field by default. Press ENTER to store the MCTF. If more than one MCTF has to be installed repeat the procedure starting with item 2.
- 7. Perform IML before the machine is returned to the customer.

Manual MCTF Installation

```
+-----+
| Tool Handling - Action |
+-----+
```

Prerequisites

1. IML of support processor complete.
2. Link list available.
3. MCTF data available.

How to Select the Manual MCTF

Installation Display

1. Insert diskette on which a MCTF has to be installed. The MCTF installation program resides on both the control and the diagnostic diskette.
2. Call MAINTENANCE/SERVICE PROGRAM selection. A
3. Key in selection for UTILITIES. B
4. Select MANUAL MCTF INSTALLATION. C

Selection Menu

The MCTF installation screen offers 5 sub-sections. These are:

- STORE
- DISPLAY
- ERASE ALL
- ERASE MCTF NUMBER
- PF12 CANCEL

Enter the appropriate selection behind 'SELECTION'. Then follow the individual description.

How to Install a MCTF Manually

1. Select STORE. The cursor moves to the first entry field. Enter the MCTF data as received and press ENTER. Any typing error will result in an error message after pressing ENTER. **D**

Does the screen show a reference code?
If 'YES' enter the correct MAP.
If 'NO' continue procedure.

2. File the MCTF data (or a copy) in the machine history.
3. Record the MCTF number of the installed MCTF in the link list, Section F.
4. Install MCTF also on the backup diskette (control diskette only).

Repeat Function

After a MCTF has been stored the message
MCTF STORED (REPEAT MCTF = PF3)
is displayed. If the same MCTF has to be
installed on another diskette, insert this
diskette and press PF3.

How to Display an Installed MCTF

Select DISPLAY. You may now enter a specific MCTF number then press ENTER. The MCTFs are displayed one after the other, beginning with the selected or the oldest one and ending with the most recent MCTF. If a MCTF was just entered the display starts with this one. The MCTF display picture has the same format as picture C.

Display is terminated by PF4 key or after all MCTFs have been displayed.

How to Erase an Installed MCTF

Two modes are available:

- Erase a single MCTF by number
- Erase all MCTFs

Erase a Single MCTF

Select ERASE MCTF NUMBER and specify MCTF number, press ENTER. The original data is restored in the load module.

Erase all Installed MCTFs

Select ERASE ALL, press ENTER. All MCTFs are erased. Also the MCTF log area is cleared.

Cancel Function

A MCTF which had been entered but was not accepted by the system can be cancelled by pressing PF12 thus clearing the screen for new data entry.

```
+-----+
| Tool Handling - Results |
+-----+
```

[A] IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'

[B] UTILITIES PROGRAM SELECTION

C

```

E1PT03 80267163          MANUAL MCTF INSTALLATION
MCTF NUMBER: P417UC04      ** EXTERNAL REFERENCE **
LOAD ID:    0118           LOAD ID:    0119
CSECT ESID: 0004           CSECT ESID:  0009 (X)
MEMBER NAME: BBDMEW01-08   MEMBER NAME: BBDFHC10-03
ASSEMB.ADDR: 000000        ASSEMB.ADDR: 0000FE
CROSS-CHECK: 000001 = 019F CROSS-CHECK: 0000FE = 011F
HASH-TOTAL: F139          OFFSET:     0100 (Z)

MCTF: *0001=60Z(1,3).....
.....
.....
.....
.....
.....
.....
.....
O = STORE    1 = DISPLAY   2 = ERASE ALL   3 = ERASE MCTF NUMBER
              CANCEL = PF12                MCTF STORED (REPEAT MCTF = PF3)
SELECTION: O
                          370 TIMER:ON       DATA:      ADDR:
                          TOD:SEC

1F05

```

D

Possible Error Messages

UPDATE AREA OVERFLOW
PARAMETER WRONG OR NOT FOUND
CROSS-CHECK MISMATCH
MCTF ALREADY INSTALLED
INVALID SELECTION
TYPING ERROR (WRONG HASH)

The cursor is positioned under the beginning of the field in error.

Manual MCTF Installation(continued)

How to Read and Identify the Link List-General

The link list you receive with your diskette is a unique list which can only be used with this diskette.

The pages of the list are sequentially numbered, but the list is also divided into sections. These sections are identified by a letter behind the page number.

How to Identify the Link List and the Diskette

The header page (section A page 1) of the link list contains most of the information needed to identify the link list, see Figure 1, page 4532. The following information must compare on the diskette label and on the link list header.

- (A) EC number
- (C) Machine serial number
- (D) Link date on the diskette label and time on the link list


How to Identify the Link List

Check the volume ID on the header page: (E)


FU = Control (Function) diskette link list
DD = Diagnostic diskette link list

How to Identify the Diskettes

- a) Check the load volume ID: (F)



- b) Check field (G). This field shows the sequence number of the diskette set.
For example:



In this example the total micro code is written on two diskettes (F). Both diskettes are considered as one group set. This is indicated by the sequence number 1 (G). The duplicate set (only for control diskette) is identified by the sequence number 2. The diagnostic diskette shows the sequence number 3.

Which Patches are Applied to the New Diskette EC


Check Section F of the new link list. All MCTFs listed here are automatically incorporated. Section B gives more detail about these MCTFs.

Only those MCTFs which have been installed previously and are not listed in Section F of the new link list, must be again manually installed on the new diskette.
Note that for the same fix a new patch is necessary, see also 'Problem Number Assignment'.

Section I lists all the installed module IDs. The numbers in column A and D point to the lines in the respective section where this module is used.

Problem Number Assignment

The problem number is composed in the following way:



- (A) This is a unique number assigned to a problem.
- (B) This code points to a distinct area in the system.

A = SUPPORT PROCESSOR (MSSS)
B = DIAGNOSTICS
*C = CHANNELS and ATTACHED I/Os
D = DISKETTE DRIVES (SYSTEM and USER DISKETTE)
*E = DISK EMULATORS (231X 33XX)
F = FTA AND ATTACHED I/Os (3310, 8809, 3340, 3370)
G = DCA AND ATTACHED I/Os (3262, 3278-2A, 3278-2, 3279-C, 3287, 3289-4)

H = ECA, FBM, FFBM
I = PU
J = INSTALLATION
K = RESERVED
*L = LA
*M = 14XX EMULATOR
N = BBA
O = PERFORMANCE
P = POWER AND COOLING
Q = SOFTWARE
R = REMOTE SUPPORT
S = MAINSTORE AND PU CONTROL STORE
T = COMMUNICATIONS ADAPTER
U = MISCELLANEOUS
*V = IOSS (5424)
W = MCTF DISK UPDATE LIST
X TO Z RESERVED
O TO 9 RESERVED

* Not applicable for system 4321

- (C) Last three digits of the microcode EC number (taken from link list). If you suspect an hardware error, enter 000. Note that the problem number changes if the problem exists for more than one microcode EC since these three digits will change.

If you install an MCTF, these three digits must compare with the last three digits of your EC on the link list and diskette.

How to Read and Identify the Link List




Figure 1: Header page of link list

- (A) EC of link list
- (B) As required REA number
- (C) Machine serial number
- (D) Date and time of link run - Note 1
- (E) FU = Control diskette link list
DD = Diagnostic diskette link list
- (F) EC number of link program
- (G) Part number of link list
- (H) MFI BMs (Feature BMs) installed
(Description on page PA 015, Vol 30)

How to Read the Diskette Label




Figure 2: Diskette label

- (A) EC number
- (B) Machine type
- (C) Machine serial number
- (D) Date and time of link run - Note 1
- (E) P/N of diskette
- (F) Load volume continuation sequence number
- (G) Diskette set sequence number
- (H) Generation identifier
- (J) Factory order number
- (K) Diskette writing date
- (L) Diskette drive type
- (M) Installation sequence number
- (N) Latest mandatory REA
- (P) Indicates if an overflow diskette exists
and gives number of diskette (1 of 2 or 2 of 2)

Note 1: These numbers must compare between the link list and diskette label.

MCTF Update via MCTF Diskette

Select the specific option or enter selection 5 to get additional information from the HELP FUNCTION offered in the MCTF DISKETTE SERVICES OPTION menu.

With the MCTF diskette and the MCTF DISKETTE LOADER program (on the control diskette CNTRL FU1) the CE is able to install MCTFs directly onto the control and/or diagnostic diskettes.

Proceed as follows:

- 1. Insert the control diskette FU1 and make IML.
- 2. Call M/S PROGRAM SELECTION from the control diskette.
- 3. Select UTILITIES, press ENTER.
- 4. Select AUTOMATIC MCTF INSTALLATION, press ENTER.

The MCTF loader program frame is displayed showing the message LOAD IN PROCESS. After the load is completed the following screen is displayed and the indicated actions have to be performed.

LVL:81055045 LOADER FOR MCTF PROGRAM
MCTF LOAD DONE, PROCEED AS FOLLOWS:
1. PRESS MODE SELECT KEY
2. PERFORM PROGRAM RESET (P)
3. PERFORM RESTART (R)

After action three the COMMUNICATION ROUTINE program is automatically selected.

*
* COMMUNICATION ROUTINE PU <==> MSSS IS READY TO RUN *
*

ENTER: M = AUTOMATIC MCTF UPDATE
 F = FRIEND AND OTHER APPLICATIONS

SELECTION: M

Select option M and press ENTER.
If available the use of the I/O diskette drive is now prompted. Use of this drive reduces diskette swapping. If the I/O diskette drive is not available the MCTF PRIMARY OPTION MENU is displayed.

*** MCTF SERVICE IS ACTIVE ***

DO YOU WANT TO USE THE I/O DISKETTE DRIVE ? (Y/N)

SELECTION: Y

Enter Y if the I/O diskette is available. If Y is entered you are prompted by the screen to:

INSERT MCTF DISKETTE INTO I/O DRIVE
AND PRESS 'ENTER'.

After ENTER or if you have entered 'N' as selection, the following screen picture is displayed:

*** MCTF SERVICE IS ACTIVE ***
M C T F P R I M A R Y O P T I O N M E N U

1 = INSTALL MCTFS ON FUNCTIONAL DISKETTE 1
2 = INSTALL MCTFS ON FUNCTIONAL DISKETTE 2
3 = INSTALL MCTFS ON DIAGNOSTIC DISKETTE 1
4 = INSTALL MCTFS ON DIAGNOSTIC DISKETTE 2

X = END OF SESSION

SELECTION:

Diskette Identification

Program Handling - Actions

Purpose

This utility program allows you to display all MFI
BMs installed and lists you all REAs and MCTFs
installed.

Prerequisite

Any control or diagnostic diskette inserted.

How to Select the Utility Program

1. Call M/S Program Selection A
2. Key in selection for UTILITIES B
3. Select DISKETTE IDENTIFICATION

This selection display offers you three sub-sections:

M = MFI DISPLAY [C]
D = DISKETTE IDENTIFICATION [D]
C = DISPLAY CONFIGURATION (see Note)
L = DISKETTE LINK INFORMATION (see [1] on next page)

4. Enter the appropriate selection, press ENTER.

Note: This selection allows only to display the hardware configurator (no change is possible). It might only be used on request from your support function in cases where problems are expected due to configuration errors.

- A full description is available for the support function in the FSC Manual, Vol. 23.
- For meaning of power configuration bits refer to MI POWER in Vol. 16 subject 'Before Calling for Assistance'.
- See also 'MES Update Without a New Diskette' in Section 6 of this manual.

Program Handling - Results

Screen displays:

- A** IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
- B** UTILITIES PROGRAM SELECTION

- C** * 4331 DISKETTE IDENTIFICATION *
MODEL: 002 SERIAL NO: 70-50150 FUNCTIONAL DISKETTE 1 EC:
LINK DATE OF DISKETTE: 79/300/17/35/15
MFI BM'S USED FOR THIS LINK 041

(A)

END OF DISPLAY. HIT ENTER TO CONTINUE

- Ⓐ In this field the actual MFI BM numbers which are used for this link are shown.

- D * 4331 DISKETTE IDENTIFICATION *

```
MODEL: 002   SERIAL NO.: 70-50150      FUNCTIONAL DISKETTE 1   EC: .....
LINK DATE OF DISKETTE: 79/300/17/35/15
```

MICRO CODE REA'S INSTALLED	NONE	} (B)
MCTF'S INSTALLED BY LINK	NONE	
MANUAL INSTALLED MCTF'S	NONE	
MCTF'S INST. BY MCTF DISKETTE	NONE	

END OF DISPLAY, HIT ENTER TO CONTINUE

- ⑧ Any REAs, or MCTFs installed will be listed in the lines after the header.
Instead of the word NONE the actual count of installed REAs, MCTFs is given.

Diskette Directory (DDIR) Display

Program Handling - Actions

The 'Diskette Directory' replaces part of the former hard-copy link list and is written onto the control-, as well as onto the diagnostic diskette.

This directory contains the:

- Module (Load) ID
- Number, name(s) and level of MEMBER(s)
- Number of CSECT(s)
- LINK ORIGIN (Linked Storage Address)

Of all modules making up the microprogram for a particular machine.


The purpose of the diskette directory (when displayed) is to show the microprogram configuration (presence or absence of a module).

The following procedure shows how to display information from the diskette directory.

1. Call M/S PROGRAM SELECTION picture.
2. Select UTILITIES (C).
3. Select DISKETTE IDENTIFICATION (9).
4. Select DISKETTE LINK INFORMATION (L).
(The picture DISKETTE DIRECTORY DISPLAY appears on screen) **1**.
5. Enter desired ID or MEMBER name, or DESTINATION, press ENTER. Information about the specified ID or MEMBER or DESTINATION needed (e.g. for installation of MCTFs) is displayed **2**.

For information on 'How to Install MCTFs' refer to:

- How to Install an IRECA Update or MCTF Received from Data Bank
- Manual MCTF Installation
- MCTF Update via MCTF Diskette



- A** DESTINATION.....see next page
- B** WITH/WITHOUT ADDRESS:..see next page
- C** ID = 012E.....ID which was keyed in
- D** D = 1Number of Diskette (1 = normal, 2 = overflow)
- E** Number of MEMBERS.....Member count
- F** MEMBER = BBAFHN99-51...Name of member and its level
- G** Number of CSECTS.....CSECT count
- H** ESID = 000B.....Name of CSECT
- J** ADDR UNIT.....Specifies wether a fullword (FWORD) or BYTE is addressed.

- Note:**
- If the information to be displayed fills more than one screen the message 'MORE..., PRESS ENTER FOR NEXT DISPLAY' appears instead of 'DISPLAY COMPLETE, etc.'.
 - If an invalid member name (or ID) name was keyed in the message 'MEMBER NOT FOUND, CHECK YOUR INPUT!' appears together with the wrong member (or ID) name instead of 'DISPLAY COMPLETE, etc.'.

Diskette Directory Display (continued)

When DESTINATION (A on previous page) was entered, all IDs are listed with their START- and END Address and their location.
Input (to be keyed-in) for DESTINATION is either:

- PU for Processing Unit 3, or
- SP for Support Processor 4, or
- IO for the processor of the I/O Subsystem.

The location for an ID (Destination PU) is either:

- Control Storage, or
- BSM (Microcode area), or
- Data Storage (Area in BSM, which is usually not used as microcode area).

The location for an ID (Destination SP or IO) is either:

- Data Area, or
 - Instruction Area, or
 - Mixed Area
- } All areas in storage of Subprocessor

If an address is specified in the field WITH/WITHOUT ADDRESS:..... (B on previous page), the ID(s) which use the specified address are listed with their START and END address and their location.

DISKETTE DIRECTORY DISPLAY				
DISKETTE TYPE: 001FU1				
ID= 0100	START ADDR.= 000000	END ADDR.= 001300	DEST.= PU	CONTROL STORE
ID= 0101	START ADDR.= 001300	END ADDR.= 001460	DEST.= PU	CONTROL STORE
ID= 0141	START ADDR.= 00A7F8	END ADDR.= 00AE88	DEST.= PU	B S M
ID= 0142	START ADDR.= 00AE88	END ADDR.= 00B800	DEST.= PU	B S M
ID= EFOA	START ADDR.= 000000	END ADDR.= 002000	DEST.= PU	DATA STORAGE
ID= EF10	START ADDR.= 000000	END ADDR.= 0032B0	DEST.= PU	DATA STORAGE
DISPLAY COMPLETE, PRESS ENTER TO RESELECT				
MAN	370 TIMER:ON	DATA: 0000	ADDR: 000000	
6062	TOD:SEC			

DISKETTE DIRECTORY DISPLAY				
DISKETTE TYPE: 001FU1				
ID= 0003	START ADDR.= 005000	END ADDR.= 005AE0	DEST.= SP	MIXED AREA
ID= 0007	START ADDR.= 002000	END ADDR.= 006696	DEST.= SP	MIXED AREA
ID= 0010	START ADDR.= 009800	END ADDR.= 00E85E	DEST.= SP	DATA AREA
ID= 0011	START ADDR.= 00E880	END ADDR.= 00F200	DEST.= SP	DATA AREA
ID= 0012	START ADDR.= 00F200	END ADDR.= 00FC00	DEST.= SP	DATA AREA
ID= 0015	START ADDR.= 008000	END ADDR.= 00FFEA	DEST.= SP	INSTR AREA
ID= 0020	START ADDR.= 006800	END ADDR.= 006E5C	DEST.= SP	MIXED AREA
ID= 0051	START ADDR.= 006B00	END ADDR.= 007440	DEST.= SP	MIXED AREA
MORE... PRESS ENTER FOR NEXT DISPLAY				
MAN	370 TIMER:ON	DATA: 0000	ADDR: 000000	
6062	TOD:SEC			

DISKETTE DIRECTORY DISPLAY				
DISKETTE TYPE: 001FU1				
ID= 0010	START ADDR.= 009800	END ADDR.= 00E85E	DEST.= SP	DATA AREA
ID= 0015	START ADDR.= 008000	END ADDR.= 00FFEA	DEST.= SP	INSTR AREA
DISPLAY COMPLETE, PRESS ENTER TO RESELECT				
MAN	370 TIMER:ON	DATA: 0000	ADDR: 000000	
6062				

This page has been
intentionally left blank

Tests for DCA and Attached Devices

Overview

There are six online tests available to test devices attached to the display cluster adapter (DCA) and to display error information for these devices and the DCA. The DCA is part of the support subsystem.

Purpose of Tests

Test 0 (Zero)

This test checks the communication path between the DCA and the devices attached to it. In addition a type A device is functionally tested.

Test 1

This test displays error statistics for the DCA and attached display units, and printers.

Test 2

Not available.

Test 3

This test displays the type and status (off, on, disabled) for all configured devices.

Test 4

This test resets the DCA and device error logs.

Test 5

Not available.

Test 6

This test displays the device control blocks (DCB)with the extention (DCBE) and the DCA control block (DCACB).

Test 7

This test is only available for the 3279 color display unit. It allows to converge the screen. The test can be selected only for one device at the time.

The online tests can be executed concurrent to the customer operation for all devices attached to port 1-15. For the operator console (port 0) the tests are only supported if the system is in MAN OP mode. To execute the tests enter Test Mode.

How to Invoke and Leave Test Mode

Port 1-15:

Hold down the ALT key and press the TEST key.

Port 0:

On line tests on the operator's console can be run only when the console is in manual operation state (MAN OP displayed on line 25). When your system has the color console installed and another display (port 1-15) is using Test 7 (color convergence) the message 'CONVERGENCE ON PORT NN' is displayed on line 23. If this message is displayed, consult the user of Test 7 before forcing manual operation state as this ends the Test 7 running on the other display, storing the convergence data completed so far. Other online tests are unaffected by entering manual operation state. Regardless whether your operator's console is a 3278-2A or 3279-2C, use the following procedure to run any online test:

1. Press CHG DPLY key.
If MAN OP appears on line 23, go to step 3.
2. If 'MODE-SEL CANCELS CONV!' appears on line 23, either press the CHG DPLY key and continue with other work (in which case the information message 'CONVERGENCE ON PORT NN' re-appears) or force MAN OP as follows:
 - a. Press MODE SEL key. The mode selection screen appears and the convergence test on the other display is terminated.
 - b. Press CHG DPLY. The previous user screen appears.
 - c. Press CHG DPLY again. MAN OP appears on line 25.
3. Hold down ALT key, press the COPY key, and release both keys. TEST appears on line 25.

To return to MAN OP mode on the OP-console repeat step 3 then step 2c. For any other display hold down the ALT key and press the TEST key.

To select a test enter the request message in the following form:

NN/n ENTER

NN = Port number of tested device
n = number of test

Any test request message must be delimited by at least one blank or empty (X'00') position. An empty position is entered by moving the cursor. If NN is omitted the test is executed on the display you entered the request.

Hitting any key which is not required for test operation will return input inhibited minus function indicator (XC - f). The same result is achieved by requesting an invalid test function (for example, Test 6 for a not configured device).

Test 0

Overview

This test performs the following functions:

- Transmits a test pattern to the requesting display and uses this test pattern to test certain functions. For details refer to the I/O maintenance manual.
- Executes a communication path test to the DCA attached printers.

Test 0 Request for a Display Unit

If Test 0 is requested for a display unit a test pattern is transmitted from the support processor to the display unit. This display unit may be the one from which the test was requested or if a port was specified with the request message the unit attached to this port. The test will be executed except under the following conditions:

- If requested for port 0 (operator console), the test pattern function is not performed. Input inhibited minus function indication is returned. For Test 0 on the operator console see 'How to Request Test 0' on next page.
- If the device is busy (executing a command that requires asynchronous ending status), input inhibit minus function indication is returned.

Test 0 Request for a Printer

If the test is requested for a DCA attached printer only the communication path test is executed, to check continuity of the coax cable.

Tests for DCA and Attached Devices (continued)

Display of Test 0 Result

The test result is shown at the requesting display behind the entered test request message. The result will be either a +, -, or a 0, whereby:

- + = Test successful or path OK
- = Test failed, device disabled due to error
- 0 = Test not executed, device powered off or already in TEST mode.

In addition a test pattern is displayed at the tested display unit. If the tested unit is the one you are entering the request the test result (+,-,0) is not shown. The appearance of the test pattern means test successful. Refer to next heading for test pattern layout.

How to Request Test 0

- Enter TEST mode.
- Insure that the cursor is at location zero (0), then enter the request message in the following form:
 - Enter the port numbers of the device you wish to test. Enter any one of two digit numbers from 1 to 15 (see Note).
 - A slash (/).
 - A zero (0).

Note: The entry of a slash only following by ENTER defaults to test zero on the requesting display. Selection of test zero for an other port is possible except for port 0. For the operator console test zero must be requested in the form slash (/) ENTER.
- If you are testing a display unit, the following pattern will appear on the screen, if the test is successful:

TEST: I;NN
?SEL PEN SEL PEN
&SEL PEN >SEL PEN
DISPLAY INSERT CK

NN = The port number of the terminal that requested the test.

- Use the appropriate Display Station Maintenance Information Manual to run the functional tests with the above test pattern.
- Exit Test Mode.

Test 1

Test 1 displays device and adapter error information. Formats for entering a Test 1 request are as follows:

- 0 to 15/1 Displays error information of any device from port 0 to 15.
- A1/1 Displays the DCA error information.

The error information is resident in the support processor storage. It is lost with either power off or IML. If any of the statistical counters displayed in the error information exceeds the value X'FF' a reference code is displayed and a log is saved on the system diskette. The general format of all logs reflects two things:

- The most recent error event.
- Statistical counters reflecting the type of errors occurring. The statistical counters record errors using hexadecimal values. The maximum value for any counter display is hex 'FF'.

The following is a summary of all error events generating a 200-series error number (2NN). Note that only the low order two digits of the error number are displayed.

200 Series Error Numbers

Device Type	Error Number	Meaning
3278 and 3279	203 204 207 208 209 211 229	Feature error Device check Lost operation complete Invalid operation complete Command Q failure Invalid status received FSU storage parity error if 3279 or configuration error if 3278.
3279 only	228	Storage parity error
3287	203 204 207 208 209 211 231	Feature error Device check Lost operation complete Invalid operation complete Command Q failure Invalid status received Printer equipment check
DCA	292 293 294 296 298	Invalid entry in the error queue Unconfigured device attached End cycle steal error Status lost due to over 63 counter Command Q cycle steal machine check

Device Error Information Display

The device error information should be accessed whenever a specific device is suspected to be experiencing intermittent or difficult to define errors. These errors may or may not be generating 2NN numbers for the failing device. Since there are two (2) formats of device error information available when using Test 1, it is necessary to determine what type of device (3278, 3279 display or 3262, 3287 or 3289 printer) is attached to the port (0-15) for which you are requesting Test 1.

Device Error Information Display (continued)

Line 1
This line is returned exactly as you entered your request.
Example: You entered 01/1 and the first line of the display sent back to you should be 01/1.

Line 2
This line displays the current low order digits of 200 series error numbers. If there are no errors generating 2NN numbers, the second line of this display will appear as follows:

0000 0000

If error information had been recorded, the second line of this display could appear as follows:

0400 0000

04 = The most recent 200 series error, in this example 204, which is a device check.

The 200 numbers appear in the leftmost position. The rest is always '0'.

Line 3
This line displays the statistical counter information associated with this device. If there are no errors recorded for this device, the counters will display as follows:

0000 0000 0000

Counter 01 Counter 06

The counters are not numbered when they are displayed. They are, however, assigned counter position numbers. The leftmost two digit position is counter number 01 and the rightmost counter position is counter number 06. The value in each counter is given in hexadecimal. If errors were being recorded for this device, the display for line 3 could appear as follows:

02FF 1A00 0013

Counter Number 01 = X'02' = 02 Errors Total
Counter Number 02 = X'FF' = 255 Errors (Maximum)
Counter Number 03 = X'1A' = 26 Errors Total
Counter Number 04 = X'00' = No Errors
Counter Number 05 = X'00' = No Errors
Counter Number 06 = X'13' = 19 Errors Total

The counter numbers are assigned specific meaning according to the device for which the error information is requested. The counter meanings for the different device types are listed in the following table.

Meaning of Error Information Counters

Printer Log for 3262, 3287 or 3289		Display Log for 3278, 3279
Cntr.	Meaning	Meaning
01	Coax Timeouts	Coax Timeouts
02	Coax Parity Errors	Coax Parity Errors
03	32nd Poll Timeout	32nd Poll Timeout
04	Device Checks	Device Checks
05	Error Status	Error Status
06	Equipment Check	Not used

DCA Error Information Display

The DCA error information is accessed by using A1/1 test request message. The information returned consists of the last 2NN number recorded, the basic adapter status information at the time of the failure, and statistical counters similar to the device error counters. The error statistical information can be used to determine:

1. What is the frequency of errors
2. What was the adapter doing at the time of error
3. How did the operation end, etc.

How to Interpret the Test Display

Line 1
Returned the same as input, A1/1.

Line 2
Four (4) bytes are displayed on this line; however, only three are currently used. The individual bytes are not labeled when displayed. Each byte is assigned a specific meaning. See the example below for byte identification:

0000 0000
NNXX SSSS

The leftmost byte is labeled NN. This code represents the two low-order digits of any 200 series error number.

The next byte to the right of NN is XX, which is always 00 and not used. The next two bytes to the right of XX are labeled SSSS and represent the adapter status associated with the last failure. See the following table:

DESCRIPTION	BIT	MEANING IF BIT IS TURNED ON
Left SS Byte	0	Counter Overflow
	1	Read Time Out
	2	Turnaround or Read Line Parity Error
	3	Read Data Byte Parity Error
	4	Stop Poll
	5	Timer
	6	Error Q Entry
Right SS Byte	7	Not Used
	0	Extended Status Set
	1	Command Completed
	2	Adapter Active
	3	Keystroke or Status Q Entry
	4	Not Used
	5	Machine Check
	6	Enable / Disable
	7	Interrupt

Tests for DCA and Attached Devices (continued)

How to Interpret the Test Display (continued)

Line 3
This line displays the statistical counter information associated with this adapter. If there are no errors recorded for this adapter, the counters will display as follows:

```
0000 0000 0000 0000
|           |
Counter 01  Counter 08
```

The counters are not numbered when they are displayed. They are, however, assigned counter position numbers. The leftmost two-digit position is counter number 01 and the rightmost counter position is counter number 08. The value in each counter is given in hexadecimal. The maximum value for any counter display is X'FF'.

Each counter is assigned a specific meaning. See the following table:

COUNTER	MEANING
01	Status Q Entry Placed in Error Q
02	Interrupt from an Unconfigured Device
03	Cycle Steal Ended in Error
04	Invalid Adapter Status
05	Lost Status Due to Over 63
06	Not Used
07	Cycle Steal Machine Check
08	Not Used

Test 2

Not available.

Test 3

This test displays the status of all configured terminals. Test 3 can be invoked after using the ALT and TEST keys to enter TEST MODE. An entry of /3 from any functioning display, and then an ENTER, will display the following format on the screen:

```
Line 1  /3
Line 2  0123456789012345
Line 3  1101101--1000101
Line 4  DDSCDSPDDD DDP P
```

Line 1
The entered test request message is returned. In this example /3 is returned.

Line 2
Displays the digits corresponding to the low order digit of the coax port address, namely port 0 = position number 0 and port 15 = position number 15 (the second 5 from the left).

Line 3
Displays the status,
1 = on
0 = off or not configured
- = disabled,
of each attached device.

Line 4
Shows the device type attached to each port.
D = Display
P = Terminal Printer
C = 1052 Copy Printer
S = System Printer

Test 4

This test allows to reset the DCA and device error information areas. The display must be in test mode before the test request message can be entered. Enter the request message in the following format:

```
0 to 15/4 Resets the log for the device
           attached to the specified port to
           all zeros (0).
A1/4      Resets the DCA log to all zeros (0).
```

Test 4 may be used to clear the error information area without performing IML. This allows to track intermittent failures.

Test 5

Not available.

Test 6

Overview

This test allows to display the control block for DCA attached devices (DCB) and for the DCA itself (DCACB).

The device control block (DCB) contains common subsystem information and information pertaining to a specific device. The Test 6 display represents the most current information regarding a device.

The DCB has two parts: The common part (from byte 0 to X'18') and the device specific part (starting at byte X'19' to byte X'3F').

The common part has the same layout for all devices on the DCA. The layout of the device specific part varies for the different device types. The common part is used for communication between the BBA level program and the work level program. The device specific part is used for communication between work level program and Display Cluster Adapter (DCA) program and for work level or DCA program internal usage.

The DCB has an extension, the device control block extension (DCBE). The DCBE is used and maintained only by the DCA.

Test 6 (continued)

To invoke test 6 you must first enter TEST MODE by using the ALT and TEST key . The DCB for any configured device may be displayed by keying the port number (in decimal) followed by a slash (/), the number 6, an empty (X'00') or blank character, and then hitting the ENTER key. Each DCB consists of one display of 128 bytes each. The individual bytes are not labeled. There are 11 lines to each display. The first line is always returned the same as input (0-15/6) for each device. The second line of the display will show the start address of the DCB. Then there will be four lines reflecting the two parts of the DCB.

The 7th line shows the DCB-extension address followed by the DCBE in line 8 through 11.

Byte Number Chart for DCB Display

NN/6 - Returned as input										
XXXX - DCB address										
Byte #*	0	1	2	3	4	5	6	7	8	9
0	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
1	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
3	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
YYYY - DCBE address										
0	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
1	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
2	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000
3	0000	0000	0000	0000	0000	0000	0000	0000	0000	0000

NN = port number 0 to 15
*Byte numbers are not displayed.

Asking for a not configured device, or a not supported TEST number, will result in a locked keyboard and XC-f displayed on the status line.

DCB Display - Common Part Byte 0 to X'18'

Byte	Meaning
00	Byte zero contains a combination of the DCA address (bit 5 - 7) and the port number (bit 0 - 4). X'02' port 0 X'0A' port 1 X'12' port 2 and so on X'7A' port 15
01	Reserved
02	Byte 02 holds the modified logical device address. The value derived by the modification depends on the configuration of the machine. In addition to the address, there is information for several occasions stored in byte 02. The layout of byte 02 for status presentation is: 0 1 2 3 4 5 6 7 ...Device address... Reserved 0 = No incorrect length handling 1 = Incorrect length handling 0 = No count correction necessary 1 = Count correction necessary

Byte	Meaning
02 cont'd	The layout of the byte for data transfer request is: 0 1 2 3 4 5 6 7 ...Device address... Reserved 0 = No count correction 1 = Count correction 0 = Normal data transfer 1 = Data transfer for data chained CCW The byte layout for successful data transfer is: 0 1 2 3 4 5 6 7 ...Device address... Reserved Not used 0 = No more data transfer 1 = Another data transfer will follow.
03	Contains the /370 CCW command after initial selection and reselection. If zero, a pseudo command is stored in byte 04.

Tests for DCA and Attached Devices (continued)

DCB Display - Common Part Byte 0 to X'18' (continued)

Byte	Meaning
04	If the byte 03 is set to X'00', byte 04 indicates the function which has to be performed. Information if bit is set to 1: Bit 0: Selective reset 1: Halt I/O - Halt device 2: Stop chaining 3: End of data chaining 4: End data and command chaining 5-7: Reserved
05	Reserved
06	Holds the /370 unit STATUS (Basic Status Byte). It is reset to X'00' by the BBA program after status presentation.
07	Reserved
08,09	Flags concerning the device - BBA interface are stored in this halfword. Information if bit is set to 1: Byte 08: Bit 0: Device not ready 1: Command chaining in process 2: Initial selection 3: Device busy with a command 4: =0: Data transfer from SP to PU =1: Data transfer from PU to SP 5: Last data transfer for this device 6: =0: Data transfer ended normal =1: Data transfer ended abnormal 7: Data chaining is going on

Byte	Meaning
0A,0B	This halfword reflects the device type. Information if bit is set to 1: Byte 0A: Bit 0: 3277 emulator 1: 1052 emulator 2: Reserved 3: 3284 emulator 4: Slave printer 5: Operator console 6-7: Reserved Byte 0B: Bit 0: Reserved 1: Color 2-4: Reserved 5: Katakana keyboard 6,7: Keyboard type 00: Typewriter 01: Data entry 1 10: Data entry 2
0C,0D	This halfword indicates the number of bytes which have been transferred through the BBA. In case of count correction it contains the number of not processed bytes.
0E,0F	This halfword indicates the number of bytes which shall be transferred through the BBA.
10,11	This is the start address of a data buffer from/to where the BBA should cycle steal the data.
12,13	The sequence number of this device control block (bit significant) is stored here.

Byte	Meaning
14	Byte 14 holds the dispatcher mask (or worklevel ID). It is used to select the work level program which handles the request for that device.
15	Reserved
16,17	This halfword contains the address of a command decoding routine which is associated with the device.
18	Sense Byte 0 contains the first byte (Byte 0) of the printer sense Bytes retrieved with a /370 sense operation.

DCB Display - Device Specific Part Byte X'19' to X'3F' Devices 3278/3279 and 3287

Byte	Meaning
19	Holds the last /370 CCW command executed for that device. It might differ from the one stored in byte 03.
1A,1B	Address of the command queue used in processing of /370 CCW commands associated with the user program for this device.
1C,1D	Operator Console: Address of the command queue used in handling RAS requests. Other Devices: Base address for local copy requests.
1E	Last encountered Attention ID
1F	Write Control Character (WCC) of the last WRITE command.

Device 3278/3279 and 3287 (continued)

Byte	Meaning
20,21	Current cursor address in hex
22,23	Control flags for the DCA interface. Meaning if bit is set to 1: Byte 22: Bit 0: RAS or TEST mode 1: Data transfer pending 2: Inhibit keyboard entries 3: Keyboard locked due to system key 4: Attribute information invalid 5: Cursor on attribute 6: Upshift lock 7: Auto shift Note: Bit 2 is always on in case of test 6 to same device. Byte 23: Bit 0: Device busy 1: Keystroke being processed 2: Numeric lock active 3: Insert mode 4: Status available 5: Read terminal status pending 6: Status queue response expected 7: CMD queue initiated
24,25	DCA error status
26	Error queue entry
27	Keystroke queue entry
28	Interface condition indicator

Byte	Meaning
29	Reserved
2A	3287 status
2B	Status queue entry
2C	Status area for display unit
2D	Most recent error event of the device
2E	Control register in case of display unit
2F	Reserved
30,31	Screen boundary in hex notation
32,33	Address of DCB extension
34,35	Current buffer address
36,37	Translate table address
38,39	Command start address
3A,3B	Flags for device specific operation. Information if bit is set to 1: Byte 3A: bit 0: Device waiting for BBA interrupt 1: Device waiting for DCA interrupt 2: Last /370 CCW command was an immediate one 3: Channel End presented, Device End pending 4: Buffer swap pending 5: MODE SELECT pending 6: Data for chained CCW expected 7: Command decode active

Byte	Meaning
3B	Byte 3B: Bit 0: 1052 emulator - CMD X'01' 1: 1052 emulator - READ outstanding 2-4: Reserved 5: Copy in MAN OP mode ended 6: Reset initiated by BBA 7: Waiting for device reset
3C,3D	Remote support flags
3E-3F	Reserved

Device 3289 and 3262

Byte	Meaning
19	Sense Byte 1 contains Byte 18 (Status code) of the printer sense bytes. See 'Printer Sense Bytes' at the end of this table.
1A,1B	The address of the command queue used in processing of /370 commands for this device associated with the user program.
1C-21	Reserved
22-2B	Same as for 3278
2C	3289-E device status
2D	Most recent device error event
2E,2F	Address of entry point for BBA requests
30,31	Address of entry point for DCA requests
32,33	Address of DCB extension
34-3B	Save area
3C	Status byte of 'A'-device
3D	Timer count for 1 CCW
3E,3F	Address of SENSE byte area

Tests for DCA and Attached Devices (continued)

DCB Extension

Byte	Meaning
00,01	DCA command queue start address
02,03	DCA READ DEVICE STATUS command queue address.
04,05	Interface condition queue start address
06,07	Indicator control table start address
08,09	Basic keystroke table start address
0A,0B	Address of currently used keystroke table
0C,0D	Address of previously used keystroke table (if not test mode)
0E,0F	Canadian-french keyboard table segment pointer
10	Device flags. Information if bit is set to 1: Bit 0: Device disabled due to power off 1: Power on active 2: Worklevel initiated power on sequence 3: Clear key stack in progress 4: Cleared stack indicator transmitted 5: TEST mode initiated from other port 6: Security key on 7: Device disabled due to error
11	Reserved
12-15	Addresses save area for transient SP routines
16	Keystroke stack flags. Information if bit is set to 1: Bit 0: Stack active 1-7: Reserved

Byte	Meaning
17	Keystroke stack count
18,19	Pointer to keystroke stack input position
1A,1B	Pointer to keystroke stack output position
1C,1D	Stored status entry for READ DEVICE STATUS command
1E	Interface condition queue flags. Information if bit is set to 1: Bit 0: Interface condition queue active 1: Interface condition queue empty 2-7: Reserved.
1F	Interface condition queue byte count
20,21	Interface condition queue input pointer
22,23	Interface condition queue output pointer
24	Current attribute character
25	Next attribute character
26,27	Position of current attribute character
28,29	Position of next attribute character

Printer Sense Byte

With a /370 sense operation the printer sense bytes are transferred to the system printer adapter. The sense bytes are stored in a temporary sense area. This area is available to the operating system for evaluation. Sense byte 0 is also stored in the DCB byte 18 and the printer status code (Sense byte 18) in DCB byte 19. In a few cases the system internally generates status codes for attempted print operations. These status codes (see following table) are also set in DCB byte 19 and are moved into byte 18 of the temporary sense area. Byte 3E, 3F of the DCB point to this temporary sense area.

The following printer status codes are generated by the system and are displayed as hex code indication on the customer screen.

Byte	Meaning
F0	Command Queue Error: The sequence number of commands sent to the device cluster adapter (DCA) did not comply with the prescribed rules.
F1	Timeout Error: Each time a command is sent out to the device (printer), a timeout is started. The timeout is reset upon a response from the printer. F1 is set when the timeout has elapsed prior to receiving a response.
F2	DCA-Error: The device cluster adapter has a hardware/controlled polling operation going. This polling operation is also supervised by a timeout. F2 is set when no response to the poll is received within the allotted time.

DCB Extension (continued)

Byte	Meaning
2A	Information about ownership of currently executing command queue. Owner if bit is set to 1: Bit 0: Manual operation request 1: DCA level request 2: DCA level - READ STATUS request only 3: 3289-E level 4: 3278, 3279 or 3287 level request 5: RAS preparation level request 6: RAS level request 7: Reserved
2B	Information about ownership of next command queue. The same flags are set as in byte 2A.
2C,2D	Address of indicator row
2E-39	Save area
3A,3B	If Canadian French: Information about dead keys If Katakana: Shift mode to be restored
3C	Command queue retry count
3D	Reserved
3E,3F	Color control block address

DCA Control Block Display - Byte 0 to X'3F'

The DCA Control Block (DCACB) is displayed in TEST mode by entering the sequence A1/6 ENTER in line 1 of the display. There will be six lines displayed. The first line is as the input (A1/6). The second line shows the DCACB start address. Lines 3 to 6 reflect the DCACB, following the pattern outlined under Test 6, Byte Number Chart.

Byte	Meaning
00	Support processor bus address of the DCA
01	Reserved
02,03	Status of the DCA
04,05	DCA control flags. Information if bit set to 1: Byte 04: Bit 0: Command queue active on DCA 1-3: Reserved 4: Interface condition queue to dispatch 5: Keystroke entries into stack 6: Dispatch 'clear keystroke stack' indicator 7: READ STATUS command queue to start Byte 05: Bit 0: Overflow of over 63 queue counter 1-7: Reserved
06,07	Address of a routine which scans for service requests
08	Counter for DCA timer interrupts
09	DCA request byte
0A,0B	Address of error queue 1
0C,0D	Address of status queue 1
0E,0F	Address of keystroke queue 1
10,11	Cycle steal control information
12,13	Address of error queue 2
14,15	Address of status queue 2

Byte	Meaning
16,17	Address of keystroke queue 2
18,19	Address of inactive error queue start
1A,1B	Address of inactive error queue end
1C,1D	Address of inactive status queue start
1E,1F	Address of inactive status queue end
20,21	Address of inactive key queue start
22,23	Address of inactive key queue end
24,25	Address of the DCB for the device, for which a command queue is initiated.
26,27	Address of the initiated command queue
28,29	Address of the initiated data queue
2A,2B	Save area
2C,2D	Address of DCB address table in port sequence
2E,2F	Address of indicator row control table
30,31	Address of first NDS device control block
32	Most recent DCA error
33	Reserved
34,35	DCA basic status at error event
36,37	Address of timer request halfword
38,39	Transient request halfword
3A,3B	Test 7 requestor base address
3C,3D	Power up convergence requests
3E,3F	Reserved

Test for DCA and Attached Devices (continued)

Test 7

This test allows to optimize (converge) the screen the settings of the primary colors red, green, blue to produce a pure compound color on the 3279 screen. For example, white contains all three primary colors. If the convergence is not correct, you can see traces of each color at the edges of a white character.

For the correct convergence adjustment procedure refer to the

- 3279-2C MIM SY33-0090 or if available
- 3279 Color Display Station Problem Determination Guide GA33-1525

Only one display at the time can execute the convergence test. If another display unit is already using this test when you are selecting it, Xc-F displayed. The same indication is given if the operator screen is in MAN OP mode or the color reset is not yet completed for the concerned device.

A successful attempt for TEST 7 on any but the operator screen gives the message 'COLOR CONVERGENCE ON PORT NN' on the operator screen.

If the 3279 is configured as 3278 the screen displays only in green.

SP Trace

SP Trace Handling - Actions

Prerequisites:

- Power on or
Power incomplete light

How to Select the Trace

- Set the CE mode switch on the CE panel to ON.
- Press the three function keys A, B, and C on the CE panel at the same time **A**.

How to Terminate the Trace


- Key in function 'Z', press ENTER.
- Set CE mode switch to OFF.

Lamp Test for SP Display Indicators

CAUTION: Do not use this procedure when any system activity is in progress (for example, customer job or diagnostic test is running) or when the machine is in an error hang (for example, dead system).

1. Perform IML with the control or diagnostic diskette (if not already done).
2. Set the display switch on the CE panel to 'ON'.
3. Select the SP Trace (A, B, C key on the CE panel).
4. Key in function C and data FFFF. Press ENTER. (Display on screen: >C< FFFF*RUN*)
5. Press function key B on the CE panel. All LEDs should light.
6. Select the SP Trace again.
7. Key in function C and data 0000. Press ENTER. (Display on screen: >C< 0000 *RUN*)
8. Press function key B on the CE panel. All LEDs should be dark.
9. Select the SP Trace again.
10. Key in function Z. Press ENTER.

SP Trace Handling - Results



A Function to be selected

FUNCTION		EXPLANATION
D,	Press ENTER	Display Storage
E,	Every time when ENTER is pressed the next even storage position is displayed.	Display storage (address +2)
Z,	Press ENTER	Switch off the TRACE

B Key in the address of the storage position you are told to display by the MAPs. If an odd address is keyed in, it will change to the even address just before the odd one when pressing ENTER.

C This is the displayed data received from the addressed storage position.
CAUTION: If you insert an odd address the second byte of the displayed data is the one belonging to the odd address.

For example: >D<2021 XXXX
 after ENTER
 >D<2020 8AC1

Support Processor Display

Introduction

Machine errors normally cause a reference code to be displayed on the screen. During the IML-phase it is not always possible to display a reference code. In these cases the error status can be retrieved on the CE panel via the SP display indicators.

These indicators display one byte at the time while the complete error status has ten bytes. See 'SP display handling procedure'.


Before starting to display the error status, ensure that the displayed information is valid. Check this by the following:

- The SP must hang in an error loop. This is the case when
- The keyboard of the operator console is locked (for example, dead system situation) or

- The test pattern 'OPERATOR CONSOLE TEST OF DISPLAY' is not displayed on the screen within 30 seconds after Power On or IML.
- The indicators must not flicker. Wait another 30 seconds to check for a stable display.

Do not operate the SP switches as long as you have no error loop hang condition.


SP switch D causes IML, see also page 1225 in Section 1.



Handling Procedure for SP-Display

- The SP switches A to C must be operated in the sequence given in the pictures below. Information may be lost if the switches are operated in a random sequence.
- Switches must be held down while reading the information.
- Refer to the 'SP Display Introduction' to ensure that the displayed information is valid.

- Use the 'SP Display' sheet or take a copy of this sheet, and write down the 10 different displays.
- Start with display 1 to 5. Press only the switches highlighted in the pictures.
- Press switches A and C together to reset the display registers 1 to 5.
- Continue with displays 6 to 10.
- Convert displays 3, 4, 8, and 9 to hex value.



Messages that Appear on Screen

Message	LOG	TEST	TOOL	Reset Condition
REFERENCE CODE	By log-in program	By analysis part of test program		By system reset or IML or next log
STARTED		Appears when the ENTER key is pressed first time to start a test.		
RUNNING		Appears when a test is running.		
STOPPED		Appears when the ENTER key is pressed a second time to stop the test. Stop occurs only at routine end.		
ANSWER	Appears on the screen when an CE interven- tion is required.	Intervention required at device under test.		
INVALID	Wrong handling Caused by an invalid selection	Wrong handling Caused by an invalid selection of an adapter or a test routine	Wrong handling Caused by an invalid selection	Repeat the handling
LOOPING		Displayed as long as a test loops.		
ERROR		Any machine malfunction or intervention re- quired at device under test but due to an error.	Machine malfunction (If manual operation selected, disable it.)	
LOADING	Appears when the control program is loaded into the processors during IML.			
CHECKSTOP	If an irrecoverable error condition is detected or if 'Stop before Log' becomes active. 1. PSW was disabled 2. Hard stop mode or 'stop before log' is active. 3. More than one log with the same unit type was requested in one log process. EXECPTION: MPX/ BMPX allow a higher number of logs in the same log process to support Operating System Recovery. 4. The PU has stopped after a log was taken. 5. The error was not recoverable.			By System Reset or IML

Messages that Appear on Screen (continued)

Message	LOG	TEST	TOOL	Reset Condition
LOG Pending	When the 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is selected. Action required: Press CANCEL .	When the 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION' is selected. Action required: Insert Control diskette, press CANCEL .	When the Customer Manual Operations are selected. Action required: Press CANCEL .	By log-in program, or system reset or IML.
Log in Process REFCODE LOG AREA FULL 2)	Appears when a pending log is stored onto diskette by the log-in program.			
HARD STOP MODE	By check control set to hardstop			By System Reset or IML
TEST		TEST displayed on line 21 is an indication for inline mode active.		
IML ERROR	Error coming up during IML			
STOP Before Log	The 'Stop before Log' Mode stops the system immediately after it has detected an error in a selected unit. The system is set to check stop state, too.			By log mode program, or System Reset.
LOOP WAIT Q WAIT 1)	By log loop condition			By System reset or IML

1) This messages comes up during IML if the 53FD is operated by a 43FD adapter. It means diskette drive not ready, wait approx. 20 seconds.

2) This message replaces 'LOG IN PROCESS' if the available entries in the reference code log area are ten or less than ten.

Supplement to MAPS, Section 5: Diskette Drive Maintenance Information

Table of CONTENTS

Title	Page	Title	Page	Title	Page
Contents of Section 5	5000				
INTRODUCTION		HEAD/CARRIAGE ASSEMBLY		DISKETTE DRIVE CONTROL CARD	
000 General Description	5001	480 Head/Carriage Service Check	5012	870 Control Card Removal	5030
010 Diskette Description	5001	490 Head/Carriage Adjustment	5013	880 Control Card Replacement	5030
020 Maintenance	5001	500 Head/Carriage Removal	5014	890 Control Card Test Pins	5030
030 Special Tools	5001	510 Head/Carriage Replacement	5014	900 Control Card Socket and Connector Pins	5030
MACHINE CHARACTERISTICS		HEAD LOAD SOLENOID AND BAIL		910 Control Card Head Cable Pins	5030
060 Electrical Characteristics	5002	520 Solenoid and Bail Service Check	5015	920 Control Card Interface Description	5031
080 Functional Characteristics	5002	530 Solenoid and Bail Adjustment	5016	930 Signal Routing	5032
SAFETY		540 Solenoid and Bail Removal	5017	940 CDF Setup and Removal	5033
100 Personal Safety	5003	550 Solenoid and Bail Replacement	5017	Glossary	5050
110 Machine Safety	5003	AC DRIVE PARTS		Legend	5050
120 Diskette Safety	5003	560 Belt Tracking Service Check	5018	I/O DISKETTE DRIVE TESTS	
DISKETTE DRIVE PARTS		570 Belt Tracking Adjustment	5018	Test Handling	5100
130 Parts Location	5005	580 Belt Removal	5018	Test Selections	5100
Cover Assembly		590 Belt Replacement	5018	Selection 1	5100
AC Drive Parts		600 Drive Motor Removal	5018	Selection 2	5110
Stepper Drive Parts		610 Drive Motor Replacement	5018	Selection 3	5110
Read/Write Parts		620 Drive Pulley Removal	5018	Selection 4	5110
Head Load Parts		630 Drive Pulley Replacement	5018	Selection 5	5110
Index Detection Parts		640 Idler Assembly Removal	5018	Selection 6	5110
Diskette Drive Control Card		650 Idler Assembly Replacement	5018	Selection 7	5120
THEORY		AC Drive Parts (continued)	5019	Selection 8	5130
140 Typical Operation	5000	STEPPER DRIVE PARTS		Selection 9	5140
150 Typical Timing Sequence	5006	680 Stepper Motor Removal	5020	Sense Byte 2 Explanation	5150
160 Control Card Interface	5006	690 Stepper Motor Replacement	5021	SYSTEM DISKETTE DRIVE TESTS	
170 Read/Write Principles	5007	700 Pulley and Clamp Removal	5022	Tests available	5200
180 FM Scoping Charts	5008	710 Pulley and Clamp Replacement	5023	Test Handling	5200
190 MFM Scoping Charts	5009	730 Drive Band Service Check	5024	Blank Page	5210
DISKETTE HANDLING		740 Drive Band Adjustment	5024		
400 Diskette Insertion	5010	750 Drive Band Removal	5025		
410 Diskette Removal	5010	760 Drive Band Replacement	5025		
COVER ASSEMBLY		770 Idler Assembly Removal	5025		
420 Cover Removal	5010	780 Idler Assembly Replacement	5025		
430 Cover Replacement	5010	LED AND PTX ASSEMBLIES			
440 Latch Assembly Removal	5010	790 Diskette Speed Service Check	5026		
450 Latch Assembly Replacement	5010	800 LED and PTX Alignment	5026		
460 Collet Removal	5011	810 LED Output Service Check	5027		
470 Collet Replacement	5011	820 LED Removal	5027		
		830 LED Replacement	5027		
		840 PTX Amplifier Service Check	5028		
		850 PTX Removal	5029		
		860 PTX Replacement	5029		


INTRODUCTION

000 General Description

IBM diskette drives are direct access, read/write, data storage devices. These drives use the flexible magnetic diskette for data entry, data exchange, and data storage.

The matrix below shows how diskettes are compatible between IBM diskette drives:

33FD	43FD	53FD	
•	•	•	Diskette 1
•	•	•	Diskette 2
•	•	•	Diskette 2D





- Connecting cables: One signal and DC power **B** one AC power **A**
- Diskette speed: 360 rpm

010 Diskette Description

The IBM diskette is a thin, flexible disk that is in a protective envelope. The disk surface is coated with a magnetic recording material. Data is available from both sides of a diskette 2 or 2D and one side of a diskette 1.

The two types of diskettes are identified by the physical location of the index hole **A**. When a diskette 1 is inserted in a 53FD diskette drive, index sensing circuits prevent the use of the blank side.

For more information about the IBM diskette, see *The IBM Diskette General Information Manual*, GA21-9182.



020 Maintenance

The 53FD diskette drive needs no scheduled maintenance. The MAPs guide the CE in diagnosing diskette drive failures; the MAPs refer to maintenance procedures in this manual when an adjustment, service check, or FRU replacement is needed.


The CE can verify a problem online (using the system) or offline (isolated from the system). The CE should verify a repair online using the system or device diagnostic programs.

The head/carriage assembly, head timing block, and drive hub and pulley assembly are adjusted and tested at the factory. The head timing block and the drive hub and pulley assembly are not field replaceable. If the head timing block or the drive hub and pulley assembly is damaged, the entire diskette drive should be replaced. The head/carriage assembly is replaceable in the field. However, do not repair or clean any part of this assembly.

030 Special Tools

The CE can use two timing pins (part 5562019, located inside the cover assembly) to align:

- The stepper motor shaft and pulley
- The LED assembly



MACHINE CHARACTERISTICS

060 Electrical Characteristics

The host system, or device, supplies all power to operate the diskette drive, which includes:

- DC voltage for the diskette drive control card:

Logic Voltage (DC)	Maximum Operating Current
- 5 V	0.10A
+ 5 V	0.80A
+24 V	0.59A

- One of the following AC voltages

60 Hz, single phase AC power:

Input Voltage (AC)	Average Operating Current
200V	0.55V
208V	0.55V
230V	0.55V

50 Hz, single phase AC power:

Input Voltage (AC)	Average Operating Current
200V	0.55V
220V	0.55V
235V	0.55V

Note: All voltage tolerances are 10% except the + 24 Vdc which has a tolerance of 12%.

080 Functional Characteristics

Diskette data formatting gives the diskette drive the following characteristics:

- Data capacity (in formatted data bytes):

	Diskette 1	Diskette 2	Diskette 2D
128 Bytes per Sector	242,944*	492,544**	
256 Bytes per Sector	284,160	568,320	985,088***
512 Bytes per Sector	303,104	606,208	1,136,640
1024 Bytes per Sector			1,212,416

- * Basic data exchange for a diskette 1
- ** Basic data exchange for a diskette 2
- *** Basic data exchange for a diskette 2D

- Data rate: 250,000 bits (31,250 bytes) per second (FM); 500,000 bits (62,500 bytes) per second (MFM)
- Cylinder to cylinder seek time: 5 ms plus 35 ms for the head/carriage assembly to stop. (The total seek time is the number of cylinders the heads moved across multiplied by 5 ms plus 35 ms).
- Tracks per diskette side: 77 (Cylinder 00 is the label cylinder; cylinders 01 through 74 are for data; cylinders 75 and 76 are reserved as alternative cylinders).

Note: On some systems cylinder 74 is reserved for alternative sector relocation.

- Sectors per track:

FM	MFM	
26	26	128 bytes per sector
15	26	256 bytes per sector
8	15	512 bytes per sector
8	8	1024 bytes per sector

For functional characteristic details on the diskette refer to 'The IBM Diskette General Information Manual', GA21 - 9182

SAFETY

100 Personal Safety

The system or device supplies AC and DC power. Voltages are present on the connector terminals in the diskette drive when the drive motor is turning.

Motor and solenoid cases become hot after continuous use; allow enough time for parts to cool before servicing.

Danger notices throughout this manual are personal safety precautions.

110 Machine Safety


Diskette drives can be damaged if operated or serviced improperly. Caution notices in this manual are machine safety precautions.

Do not use IBM cleaning fluid or other cleaning fluids near plastic parts.


Never use damaged diskettes in a diskette drive. Diskettes that are physically damaged (creased or bent) or contaminated (by pencil marks, finger marks, or cleaning fluid) can cause data errors, equipment errors, or head damage.

120 Diskette Safety


Return a diskette to its envelope whenever it is removed from the diskette drive.




Do not use clips or rubber bands on a diskette.




Do not place heavy objects on diskettes.




Do not lay diskettes near food, drink, or ashtrays.




Do not place diskettes near materials that might be magnetized. Data can be lost from a diskette exposed to a magnetic field.




Do not expose diskettes to heat greater than 51.5° C (125° F) or direct sunlight.



Do not touch or clean diskette surfaces. Contaminated diskettes must be discarded.



Do not write outside the label area on diskettes.




DISKETTE DRIVE PARTS

130 Parts Location

Cover Assembly (420 through 470)

- A** Latch assembly (440 and 450)
- B** Collet (460 and 470)

Open the diskette drive cover assembly to insert a diskette. The collet centers and holds the diskette against the drive hub when the cover is closed.



AC Drive Parts (560 through 650)

- G** Belt (560 through 590)
- E** Drive motor (600 and 610)
- F** Drive pulley (620 and 630)
- H** Idler assembly (640 and 650)


The AC drive parts turn the diskette at 360 rpm.

Stepper Drive Parts (680 through 780)


- K** Stepper motor (680 and 690)
- R** Stepper motor pulley (700 and 710)
- S** Stepper motor pulley clamp (700 and 710)
- P** Stepper drive band (730 through 760)
- L** Drive band idler assembly (770 and 780)

The stepper motor shaft turns in either direction under control of access pulses.

The stepper drive parts move the heads across the diskette surface.



Front View



Read/Write Parts

- N** Head/Carriage Assembly (480 through 510)

Two read/write heads, which are mounted on a common carriage, move under control of the stepper motor. The read/write heads perform the read, write, and erase functions of the diskette drive.

Head Load Parts

- D** Solenoid (520 through 550)
- O** Bail (520 through 550)

The head load solenoid causes the bail to load the heads.

Index Detection Parts

- M** LED (800 through 830)
- C** PTX (800 and 840 through 860)

The LED (the light source) and the PTX (the light sensing device) work together to detect the diskette index.

Diskette Drive Control Card

- F** 53FD (870 through 920)

The diskette drive control card has the drive circuits for the stepper motor, the head load solenoid, and the write and erase functions. This control card also has the amplifiers for the read heads and the index sensing circuits.


Note: Different control card versions are shipped. Refer to 890 to verify which card version is plugged in your diskette drive.

THEORY

140 Typical Operation

1. The host system starts the diskette drive motor.
2. Inserting a diskette and closing the cover assembly starts the diskette turning.
3. Index pulses are sensed every revolution (166.7 ms). The diskette sense line identifies the type of diskette inserted; an active level indicates a diskette 2 or 2D.
4. Seeking to the selected cylinder is done by sequencing the four access lines to move the head/carriage assembly in (toward the hub) or out (away from the hub). Activating two sequential access lines turns the stepper motor a distance equal to one cylinder. The two access lines for the last cylinder reached remain activated. Data is valid after 40 ms (minimum time for the head and carriage assembly to stop).
5. A head load command can be issued before or during a seek to activate the head load solenoid. Data is valid 80 ms after the heads are loaded. Head location is found by reading the address bytes of the first available ID (identifier) field.
6. Reading or writing can occur 40 ms after seeking to the last cylinder or 80 ms after the heads are loaded.
7. The heads are unloaded after the read or write operation if no other read or write operation is to be performed.

150 Typical Timing Sequence



Note: Seeking and head loading are not timed to the index.


160 Control Card Interface

Refer to 920 for Detailed Description


170 Read/Write Principles

Write Data


For each change of the write data signal, the current switches in the read/write head. This process records the data on the diskette surface.



In FM encoding, the time between clock pulses is 4 μs. Both a clock bit and either a data bit for a 1 or no data bit for a 0 are recorded within this 4 μs period.



In MFM encoding, the constant clock pulse is removed. A clock bit is recorded only when a 0 (no data bit) is followed by a 0. Therefore, the time between data bits is 2 μs. Either a data bit for a 1 or no data bit for a 0 is recorded within this 2 μs period.



Read Data

- The sine wave signal for FM encoding is:
125 kHz: 13 to 560 mV (all 0's)
250 kHz: 6.5 to 420 mV (all 1's)
- The sine wave signal for MFM encoding is:
125 kHz: 13 to 560 mV (alternate 0's and 1's)
250 kHz: 6.5 to 420 mV (all 0's or all 1's)

The voltage is higher at the outer tracks because of the higher track speeds and lower bit density.

For FM, an all 0's pattern has a higher voltage amplitude than an all 1's pattern.

For MFM, an alternate 0's and 1's pattern has a higher voltage amplitude and is half the frequency of an all 0's or all 1's pattern.



File Data

File data is a series of clock and data pulses that represent the read data. These pulses are 150 to 500 ns in duration and are sent to the VFO circuits for separation of the clock and the data pulses.

Write Operation

For a write operation, write gate activates the write circuits and deactivates the read circuits as shown A.

Erase gate is active during a write operation to erase the edges of the data track just recorded. This erasing process prevent crosstalk between tracks during later read operations.



Format Write Operation

The format write operation writes a full track replacing all the ID (identifier) fields, data fields, and gaps. The index to first ID field gap is 73 (146 for MFM) 8-bit bytes.

Write gate is activated within 50 (100 for MFM) bytes from the leading edge of the index pulse B. Write gate is deactivated within 51 (102 for MFM) bytes after the leading edge of the next index pulse C.

Erase gate is activated the same time as write gate. However, erase gate is deactivated 537 μs after write gate is deactivated D.



Re-read (Update) Write Operation

Update operations are performed on a data field and its VFO sync field only. ID fields and gaps are not written.

Write gap is activated within 237 μs after the last ID character is read E. Write gate is deactivated within 5 μs after the last clock of the 2-bit pad is written F.

Erase gate is activated 537 μs after write gate G and is deactivated 537 μs after the fall of write gate H.

The new VFO sync field begins when write gate is activated J.





180 FM Scoping Charts

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	dc
Channel A slope	+
Channel A source	External
Trigger	Normal
Mode	Add
Channel 1 volts/division	5 mV/cm
Channel 2 volts/division	5 mV/cm
Channel 1 input	ac
Channel 2 input	ac
Invert	Pull out
Times per division	2ms/cm
Connect channel 1 to	Preamp TP1 A
Connect channel 2 to	Preamp TP2 B
Connect trigger to	+Index test pin C

Observe: The amplitude of the read signal should be between 6.5 to 560 mV.




Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	dc
Channel A slope	+
Channel A source	External
Trigger	Normal
Mode	Channel 1
Channel 1 volts/division	2.0 V/cm
Channel 1 input	dc
Times per division	2 μ s/cm
Connect channel 1 to	+File data D
Connect trigger to	+Index test pin C

Observe: Clock pulses every 4 μ s. Pulse duration should be between 100 and 500 ns. Pulses amplitude should be between 2.4 and 4.2 volts.

File Data
Example: 01010



KEY	SIGNAL	PIN
A	PREAMP TP1	THP13
B	PREAMP TP2	THP14
C	+INDEX	TPB9
D	+FILE DATA	TPB5



Note: See paragraph 890 for test pin locations

190 MFM Scoping Charts

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	dc
Channel A slope	+
Channel A source	External
Trigger	Normal
Mode	Add
Channel 1 volts/division	5 mV/cm
Channel 2 volts/division	5 mV/cm
Channel 1 input	ac
Channel 2 input	ac
Invert	Pull out
Times per division	2ms/cm
Connect channel 1 to	Preamp TP1 A
Connect channel 2 to	Preamp TP2 B
Connect trigger to	+Index test pin C

Observe: The amplitude of the read signal should be between 6.5 to 560 mV.




KEY	SIGNAL	PIN
A	PREAMP TP1	THP13
B	PREAMP TP2	THP14
C	+INDEX	TPB9
D	+FILE DATA	TPB5

Note: See paragraph 890 for test pin locations

Note: Use Tektronix 453, 454, or similar oscilloscope with x10 probes.

Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	dc
Channel A slope	+
Channel A source	External
Trigger	Normal
Mode	Channel 1
Channel 1 volts/division	1.0 V/cm
Channel 1 input	dc
Times per division	2 us/cm
Connect channel 1 to	+File data D
Connect trigger to	+Index test pin C


Observe: Clock or data pulses every 2 to 4 μs. Pulse duration should be between 100 and 500 ns. Pulse amplitude should be between 2.4 and 4.2 volts.



DISKETTE HANDLING

400 Diskette Insertion

1. Open the diskette drive cover assembly.
2. Remove the diskette from its protective envelope.
3. Place the diskette squarely into the diskette drive (with the label facing the cover).
4. Close the diskette drive cover assembly.



410 Diskette Removal

1. Open the diskette drive cover assembly.
2. Remove the diskette.
3. Insert the diskette in a protective envelope.
4. Close the diskette drive cover assembly.


COVER ASSEMBLY

420 Cover Removal

Select the removal procedure to match the installed mounting position.

Cover (Vertical Mount)

1. Open the diskette drive cover assembly.
2. Loosen the two pivot screws with a wrench.
3. While holding the cover assembly, remove the two pivot screws.
4. Lift the cover away from the diskette drive.



Cover (Side Mount)

1. Open the diskette drive cover assembly.
2. Disconnect the spring **A** from the cover.
3. Loosen the two pivot screws with a wrench.
4. While holding the cover assembly, remove the pivot screws.
5. Lift the cover away from the diskette drive.

430 Cover Replacement

Select the replacement procedure to match the installed mounting angle.

Cover (Vertical Mount)

1. Align the diskette drive cover assembly with the mounting holes in the casting. Then reinstall the two pivot screws.
2. Tighten the pivot screws with a wrench.
3. Close the diskette drive cover assembly.

Cover (Side Mount)


1. Align the diskette drive cover assembly with the mounting holes in the casting. Then reinstall the two pivot screws. (Ensure that the spring **A** is installed.)
2. Tighten the pivot screws with a wrench.
3. Connect the spring **A** to the cover.
4. Close the diskette drive cover assembly.

440 Latch Assembly Removal

Select the removal procedure to match the latch installed.

Latch (Standard)

1. Open the diskette drive cover assembly.
2. Remove the two latch mounting screws **C**.
3. Pull the latch **B** toward the front of the cover assembly.



Latch (Side Mount)


1. Open the diskette drive cover assembly.
2. Remove the two latch mounting screws **F**.
3. Carefully remove the latch **E** and the two pivots by pulling the latch toward the rear of the cover assembly. Do not lose the spring **D**.

450 Latch Assembly Replacement

Select the replacement procedure to match the latch installed.

Latch (Standard)

1. Place the latch **B** into position in the cover assembly.
2. Reinstall the two latch mounting screws **C**.
3. Close the diskette drive cover assembly.



Latch (Side Mount)


1. Place the latch **E** into the cover assembly. Then position the two pivots. Be sure to reinstall the spring **D**.
2. Reinstall the two latch mounting screws **F**.
3. Close the diskette drive cover assembly.

460 Collet Removal

- 1. Remove the diskette drive cover assembly (refer to 420).
- 2. Remove the mounting screw **A**.
- 3. Remove the collect assembly **B** along with the parts on the collet assembly shaft.
- 4. Remove the clip **C** and the collet.
- 5. Inspect all parts for wear and install new parts as needed.

470 Collet Replacement

- 1. Reinstall the collet and the clip **C**.
- 2. Reinstall the remaining parts on the collet assembly shaft in the order shown.
- 3. Reinstall the collet assembly **B** and the mounting screw **A**.
- 4. Reinstall the diskette drive cover assembly (refer to 430).



HEAD/CARRIAGE ASSEMBLY

WARNING
The head/carriage assembly is adjusted and tested at the factory. Do not repair or clean any part of this assembly.

480 Head/Carriage Service Check

WARNING
The head/carriage service check must be performed with the diskette drive installed (or in the same position as when installed) or the adjustment might not be accurate.


1. Power off.
2. Remove the diskette drive cover assembly (refer to 420).
3. Remove the wiper assembly **B**.
4. Insert a strip of clean paper between the heads to keep the head surfaces from touching.
5. Turn the stepper motor pulley by hand to cylinder 40 and insert a timing pin **A**.
6. Disconnect the drive motor power cable.

DANGER
Voltage is still present at the socket when the power cable is disconnected.

7. Power on.
- WARNING**
To do the following procedure correctly, make sure the access lines are not active and cannot be activated by an external source.

8. Install a jumper from TPA 13 (ground) to TPH 11 (- align access 0), see 490 **A**.
9. Does the timing pin pass freely through the stepper motor pulley into the timing slot in the casting?
Y N
— Remove the timing pin **A**.
— Remove the jumper 490 **A**.
— Power off.
— Go to 490 step 5.
10. Remove the timing pin **A**.
11. Remove the jumper end from THP11. Then install the jumper end to TPB10 (MC-3).
12. Verify that this is cylinder 39 by visually checking for no gap **C** between the timing pointer and the timing block.
13. Remove the jumper end from TPB10 (MC-3). Then install the jumper end to THP11 (- align access 0).

14. Verify that this is cylinder 40 by visually checking that the timing hole in the pulley lines up with the timing slot in the casting. (Do not use a timing pin.)
15. Verify the 0.508 mm (0.20 inch)gap **D** as follows:
— Visually check that the head/carriage assembly does not move while carefully inserting a 0.0195 thickness gauge **E**
— Visually check that the head/carriage assembly moves slightly while carefully inserting a 0.021 thickness gauge **E**
- Note: Because of the torque characteristics of the stepper motor, this step can be performed only once. If it is necessary to perform this step again, go back to step 11 of this service check.
16. Is the adjustment correct ?
Y N
— Go to 490, step 13.
17. Remove the jumper 490 **A**.
18. Reinstall the wiper assembly **B**.
19. Was the head/carriage assembly replaced?
Y N
— Remove the paper from between the heads.
— Reinstall the cover assembly (refer to 430).
— Power off.
— Connect the drive motor power cable.
— Power on.
— End of procedure.
20. Go to 520, step 6.



490 Head/Carriage Adjustment

CAUTION

The head/carriage assembly adjustment must be performed with the diskette drive installed (or in the same position as when installed) or the adjustment might not be accurately made.

1. Power off.

2. Remove the diskette drive cover assembly (refer to 420).

3. Remove the wiper assembly **F**.

4. Insert a strip of clean paper between the heads to prevent the head surfaces from touching.

5. Measure and record the gap **B** between the stepper motor pulley and the casting.

Gap is:

6. Loosen the clamp screw **C** so the stepper motor shaft can turn inside the pulley.

7. Turn the stepper motor pulley by hand to cylinder 40 and insert a timing pin **E**.

8. Disconnect the drive motor power cable.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

9. Power on.

WARNING

To do the following procedure correctly, make sure the access lines are not active and cannot be activated by an external source.

10. Install a jumper **A** from TPA13 (ground) to THP11 (-align access 0).

11. Make the gap **B** the same size as the gap recorded in step 5 and tighten the clamp screw **C**. (Ensure that the timing pin passes freely through the stepper motor pulley into the timing slot in the casting.)

12. Remove the timing pin **E**.

13. Loosen the two band clamping screws **D**.

14. Remove the jumper end from THP11. Then install the jumper end to TPB10 (MC-3).


15. Remove the jumper end from TPB10. Then install the jumper end to THP11 (-align access 0).

16. Verify that this is cylinder 40 by visually checking that the timing hole in the pulley lines up with the timing slot in the casting. (Do not use a timing pin.)

17. Insert a 0.020 thickness gauge **G** between the timing pointer and the timing block. (Put light finger pressure to the top of the carriage to hold the thickness gauge in place.)

18. Tighten the band clamping screws **D**. (Ensure that the drive band is straight.)

19. Go to 480, step 11.



Jumper:

Cylinder 40	Cylinder 39
THP 11 (-align access 0)	TPB10 (MC-3)
-- to --	-- to --
TPA 13 (ground)	TPA 13 (ground)

500 Head/Carriage Removal

- Power off.
- Remove the diskette drive cover assembly (refer to 420).
- Remove the wiper assembly **C**.
- Carefully remove the head cable from the diskette drive control card. (Remember the cable path for the replacement procedure.)
- Place the head/carriage assembly to about cylinder 40.
- Remove the two band clamping screws **A** and the clamp. Place the head and carriage assembly at the lower limit (cylinder 00).
- Loosen the screw **G** and remove the guide rod **F**.
- Carefully lift and turn the head/carriage assembly to remove it from the guide rod **D**.

510 Head/Carriage Replacement


WARNING
When installing the head/carriage assembly, ensure that the bail **K** is under the tab **L** of the carriage arm. Ensure that the bail return spring **H** is properly installed. Also, ensure that a strip of clean paper is inserted between the head surfaces during installation.

- Carefully install the head/carriage assembly on the guide rod **D**. Then place the head/carriage assembly at the lower limit (cylinder 00).
- Reinstall the guide rod **F** and tighten the screw **G**. (Ensure that the guide rod notch **E** is aligned with the screw and is seated as shown **D**.)
- Place the head/carriage assembly to about cylinder 40.
- Reinstall the clamp and the two band clamping screws **A**. (Do not tighten these two screws now.)
- Carefully place and connect the head cable to the diskette drive control card.
- Turn the stepper motor pulley to cylinder 40, then insert a timing pin **B**.
- Disconnect the drive motor power cable.

DANGER
Voltage is still present at the socket when the power cable is disconnected.

- Power on.
- WARNING**
To do the following procedure correctly, make sure the access lines are not active an cannot be activated by an external source.
-
-
-
-

- Install a jumper from TPA 13 (ground) to THP11 (align access 0),see figure 490 **A**.
- Does the timing pin pass freely through the stepper motor pulley into the timing slot in the casting?
Y N
— Remove the timing pin **B**.
— Remove the jumper 490 **A**.
— Power off.
— Go to 490, step 5.
- Remove the timing pin **B**.
- Go to 490, step 14.




HEAD LOAD SOLENOID AND BAIL
520 Solenoid and Bail Service Check





- 1. Power off.
- 2. Disconnect the drive motor power cable.

DANGER
Voltage is still present at the socket when the power cable is disconnected.

- 3. Remove the diskette drive cover assembly (refer to 420).
- 4. Insert a strip of clean paper between the heads to prevent the head surfaces from touching.
- 5. Power on.
- 6. Install a jumper **A** to activate the head load solenoid.
- 7. Verify a 0.4 ± 0.13 mm (0.015 ± 0.005 inch) gap **C** between the bail and the carriage arm for all of the carriage movement (cylinder 00 to cylinder 76).



- 8. Is the gap OK?
Y N
- Go to 530, step 7.
- 9. Remove the jumper **A**.
- 10. Remove the paper from between the heads.
- 11. Reinstall the diskette drive cover assembly (refer to 430).
- 12. With the head load solenoid deactivated and the cover closed, visually check for a gap **B** of approximately 2,4 to 3,2 mm ($3/32$ to $4/32$ inch) of an inch between the head surfaces. (This gap cannot be measured).
- 13. Is the gap OK?
Y N
- Go to 530, step 14.
- 14. Power off.
- 15. Connect the drive motor power cable.
- 16. Power on.



530 Solenoid and Bail Adjustment

1. Power off.
2. Disconnect the drive motor power cable.

DANGER

Voltage is still present at the socket when the power cable is disconnected.

3. Remove the diskette drive cover assembly (refer to 420).
4. Insert a strip of clean paper between the heads to prevent the head surfaces from touching.
5. Power on.
6. Install a jumper **F** to activate the head load solenoid.

DANGER

The solenoid case becomes hot after continuous use.

7. Loosen the solenoid locking screw **B**.
8. Turn the solenoid in the casting for a 0.4 ± 0.13 mm (0.015 ± 0.005 inch) gap **C** between the bail and the carriage arm (a clockwise turn decreases the gap).

9. Is the gap OK for all of the carriage movement (cylinder 00 to cylinder 76)?

Y N

— Go back to step 8.

10. Tighten the solenoid locking screw.

WARNING

Check for clearance between the idler arm and the solenoid. Reform the tab on the idler arm to obtain the clearance.

11. Remove the jumper **F**.
12. Remove the paper from between the heads.
13. Reinstall the diskette drive cover assembly (refer to 430).
14. With the head load solenoid deactivated and the cover closed, visually check for a gap **D** of approximately $3/32$ to $4/32$ of an inch between the head surfaces. (This gap cannot be measured.)
15. Is the gap OK?



Y N

— To correct the gap, turn the bail stop setscrew **E** clockwise until the heads just touch, then counterclockwise one complete turn.

16. Power off.

17. Connect the drive motor power cable.

18. Power on.



540 Solenoid and Bail Removal
(All Versions)

1. Power off
2. Disconnect the drive motor power cable.
3. Remove the diskette drive cover assembly (refer to 420).
4. Insert a strip of clean paper between the heads to prevent the head surfaces from touching.
5. Remove the bail return spring **E**
6. Remove the mounting screw **D** and the bail **C** (This pulls the solenoid plunger out of the solenoid. Be careful not to damage the plated surface of the plunger).

Early Version

- 7.1 Remove safety cover **H**
- 7.2 Remove the solenoid leads **G** from the taper pin terminal block **F** (Remember the cable path for the replacement procedure).

Danger
The 28 ohm resistor becomes very hot during normal usage.

Late Version

- 7.1 Disconnect the diskette drive control cable from position A2 **L**
- 7.2 Remove the two screws **K** and the connector covers.
- 7.3 Remove the two solenoid Leads **M** by pushing down on the tabs with a small screwdriver.
8. Remove the plunger from the bail.
9. Loosen the solenoid locking screw **A**
10. Remove the head load solenoid by turning it counterclockwise.

550 Solenoid and Bail Replacement
(All Versions)

1. Install the solenoid about four turns clockwise into the casting.
2. Install the plunger to the bail. (Be careful not to damage the plated surface at the plunger).
3. While inserting the plunger into the solenoid; reinstall the bail **C** and the mounting screw **D**. Ensure that the bail is under the tab **B** of the carriage arm.
4. Reinstall the bail return spring **E**

Early Version

- 5.1 Carefully place and connect the solenoid leads **G** to the taper pin terminal block **F**

Note: The 28 ohm resistor must not touch any other components.

- 5.2 Replace safety cover **H**

Danger

Voltage is still present at the socket when the power cable is disconnected.


Late Version

- 5.1 Insert the two solenoid Leads **M** into the diskette drive control cable connector. Ensure that the locking tabs **N** on the terminals lock in the connector slots.
- 5.2 Replace the cable connector covers and the two screws **K**
- 5.3 Plug the cable into position A2 **L** on the diskette drive control card socket.




Danger

Voltage is still present at the socket when the power cable is disconnected.


6. Power on.
7. Go to 530, step 6.



Early Version



Late Version



AC DRIVE PARTS

560 Belt Tracking Service Check

1. With power on, check that the drive belt is centered on the hub pulley and the drive pulley.
2. If the drive belt is not centered, go to 570.

570 Belt Tracking Adjustment

1. Power off.
2. Loosen the idler locking screw **E** and the drive pulley setscrew **C**.
3. Slide the idler assembly and the drive pulley in or out so the belt is centered on the hub pulley and the drive pulley when the drive pulley is turned counterclockwise.
4. Tighten the idler locking screw and the drive pulley setscrew. Ensure that the drive pulley setscrew is at 90° to the flat surface of the drive motor shaft.

WARNING

Check for clearance between the idler arm and the solenoid. Reform the tab on the idler arm to obtain the clearance.

5. Power on.
6. Go to 560.

580 Belt Removal

1. Power off.
2. Release the idler tension by hand and remove the driver belt.

590 Belt Replacement

1. Install the drive belt, ensuring that the idler is positioned as shown **A**.
2. Power on.
3. Go to 560.

600 Drive Motor Removal

1. Power off.
2. Disconnect the drive motor power cable.
3. Remove the diskette drive cover assembly (refer to 420).
4. Remove the drive belt (refer to 580).

DANGER

The motor case becomes hot after continuous use.

5. Remove the two motor bracket mounting screws **D** and remove the drive motor and the bracket as an assembly. (Be careful not to lose the bail return spring and bracket **G**.)
6. Loosen the setscrew **C**. Then remove the drive pulley.

610 Drive Motor Replacement

1. Reinstall the drive pulley onto the new motor. Ensure that the setscrew **C** is at 90° to the flat surface of the motor shaft.

DANGER

(60 Hz motors)
To prevent personal injury, ensure that the two large holes **B** in the motor case are positioned up and under the bracket.

2. Install the motor and bracket assembly and the two screws **D**. (Ensure that the bail return spring and bracket **G** is installed.)
3. Reinstall the diskette drive cover assembly (refer to 430).
4. Connect the drive motor power cable.
5. Go to 590.

620 Drive Pulley Removal

1. Power off.
2. Remove the drive belt (refer to 580).
3. Loosen the setscrew **C**. Then remove the drive pulley.

630 Drive Pulley Replacement


1. Install the drive pulley on the motor shaft with the setscrew **C** at 90° to the flat surface of shaft.
2. Go to 590.


640 Idler Assembly Removal

1. Power off.
2. Remove the drive belt (refer to 580).
3. Remove the idler spring **F**.
4. Remove the locking screw **E** and the idler assembly.

650 Idler Assembly Replacement

1. Install the idler assembly and the locking screw **E**.
2. Reinstall the idler spring **F**.
3. Go to 590.





STEPPER DRIVE PARTS

680 Stepper Motor Removal

1. Power off.
2. Remove the diskette drive cover assembly (refer to 420).
3. Disconnect the head cable from the diskette drive control card.
4. Remove the card retainers and the diskette drive control card.
5. Disconnect the cable from location A2 **I**.
6. Remove the two screws **G** and the two connector covers.
7. Remove the stepper motor leads **H** from the cable connector by pushing down on the terminal tabs with a small screwdriver.
8. Remove the wiper assembly **F**.
9. Loosen the two idler mounting screws **E**. Push the idler assembly against the spring tension, then tighten the screws.






CAUTION

While performing the following steps, be careful not to damage the drive band.

10. Remove the clamp screw **B** and the band clamp.
11. Carefully remove the drive band ends from the pulley pin.
12. Measure and record the gap **A** between the stepper motor pulley and the casting.

Gap is:

13. Loosen the clamp screw **C**, then remove the stepper motor pulley.
14. Remove the three stepper motor mounting screws **D**, then remove the motor.



690 Stepper Motor Replacement


- 1. Install the stepper motor using the three mounting screws **G**. (Position the motor cable toward the diskette drive control card.)
- 2. Insert the stepper motor leads **M** into the cable connector. Ensure that the locking tabs **K** on the terminals lock in the connector slots.
- 3. Reinstall the connector covers and two screws **L**.
- 4. Connect the cable to location A2 **N**.
- 5. Reinstall the stepper motor pulley. (Keep the clamp screw **E** loose so that the motor shaft can turn inside the pulley.)
- 6. Carefully reinstall the drive band ends on the pulley pin as shown **D**. Reinstall the band clamp (with the notch facing away from the stepper motor) and the screw **C**. (Do not tighten the screw.)
- 7. Loosen the two mounting screws **H** and let the spring tension position the idler.
- 8. Tighten the mounting screws and center the drive band on the idler pulley as shown **I**.
- 9. Reinstall the diskette drive control card and the card retainers.
- 10. Reinstall the head cable on the diskette drive control card.
- 11. Turn the stepper motor pulley to cylinder 40 and insert a timing pin **F**. Two timing pins are located in the cover assembly (refer to 030).
- 12. Disconnect the drive motor power cable.

DANGER
Voltage is still present at the socket when the power cable is disconnected and power is on.





13. Power on.

WARNING
To do following procedure correctly, make sure the access lines are not active and cannot be activated by an external source.

- 14. Install a jumper **A** from TPA13 (ground) to THP11 (-align access 0).
- 15. Make the gap **B** between the pulley and the casting the same size as the gap that was recorded in 680 step 12.
- 16. Tighten the clamp screw **E**.
- 17. Remove the timing pin **F**.
- 18. Remove the jumper **A**.
- 19. Tighten the band clamp screw **C**. (Ensure that the drive band is straight.)
- 20. Power off.
- 21. Turn the stepper motor pulley by hand and check to see that the drive band is centered **I** on the idler pulley in all of the head/carriage assembly movement (cylinder 00 to cylinder 76).
- 22. Is the drive band centered?
Y N
| - Go to 740, step 4.
- 23. Go to 480, step 4.



Jumper:
Cylinder 40
THP 11
(-align access 0)
--to--
TPA 13
(ground)



700 Pulley and Clamp Removal

1. Power off.
2. Remove the diskette drive cover assembly (refer to 420).
3. Remove the wiper assembly **D**.
4. Disconnect the head cable from the diskette drive control card.
5. Remove the card retainers and the diskette drive control card.
6. Loosen the two idler mounting screws **E**. Push the idler assembly against the spring tension, then tighten the screws.


CAUTION

While performing the following steps, be careful not to damage the drive band.

7. Remove the clamp screw **B** and the band clamp from the pulley.
8. Carefully remove the drive band ends from the pulley pin.
9. Measure and record the gap **A** between the stepper motor pulley and the casting.

Gap is:

10. Loosen the clamp screw **C**, then remove the pulley and the clamp.



710 Pulley and Clamp Replacement

1. Reinstall the pulley, the clamp, and the clamp screw **C**. (Keep this screw loose so that the motor shaft can turn inside the pulley.)
2. Carefully reinstall the drive band ends on the pulley pin as shown **D**. Then reinstall the band clamp (with the notch facing away from the stepper motor) and the screw **C**. (Do not tighten the screw.)
3. Loosen the two idler mounting screws **G** and let the spring tension position the idler.
4. Tighten the mounting screws. (Center the drive band on the idler pulley as shown **H**.)
5. Reinstall the diskette drive control card and the card retainers.
6. Reinstall the head cable on the diskette drive control card.
7. Turn the stepper motor pulley by hand to cylinder 40 and insert a timing pin **F**. Two timing pins are located in the cover assembly (refer to 030).
8. Disconnect the drive motor power cable.


DANGER
Voltage is still present at the socket when the power cable is disconnected.

9. Power on.

WARNING

To do the following procedure correctly, make sure the access lines are not active and can not be activated by an external source.

10. Install a jumper **A** from TPA13 (ground) to THP11 (-align access 0).
11. Make the gap **B** between the pulley and the casting the same as the gap that was recorded in 700 step 9.
12. Tighten the clamp screw **E**.
13. Remove the timing pin **F**.
14. Remove the jumper **A**.
15. Tighten the band clamp screw **C**. (Ensure that the drive band is straight.)
16. Power off.
17. Turn the stepper motor pulley by hand between cylinders 00 and 76. The drive band should track without movement to the left or right on pulley **H**.
18. Is the drive band centered?
Y N
— Go to 740, step 4.
19. Go to 480, step 4.




730 Drive Band Service Check

- Power off.
- Remove the diskette drive cover assembly (refer to 420).
- Remove the wiper assembly **D**.
- Turn the stepper motor pulley by hand between cylinders 00 and 76. The drive band should track without movement to the left or right on pulley. **G**
- Does the band track properly?
Y N
| — Go to 740, step 4.
- Reinstall the wiper assembly **D**.
- Reinstall the diskette drive cover assembly (refer to 430).
- Turn the stepper motor pulley by hand a few times to center the drive band on the idler pulley **G**.
- Place the head/carriage assembly to about cylinder 40. Check to see that the band mounting slots **A** are centered (left to right) over the mounting holes on the carriage pad.
- Repeat step 10 with the head/carriage assembly at cylinder 76 and cylinder 00.
- Are the mounting slots centered?
Y N
| — Loosen the clamp screw **C**.
| — Loosen the band clamp screw **B**.
| — Position the stepper motor pulley to center the mounting slots and tighten the clamp screws **C** and **B**.

740 Drive Band Adjustment

- Power off.
- Remove the diskette drive cover assembly (refer to 420).
- Remove the wiper assembly **D**.
- Disconnect the head cable from the diskette drive control card.
- Remove the card retainers and the diskette drive control card.
- Place the head/carriage assembly to about cylinder 40.
- Remove the two band clamp screws **E** and the clamp.
- Loosen the two idler mounting screws **F** and let the spring tension position the idler. Tighten the mounting screws.
- Reinstall the clamp and the two clamp screws **E** (do not tighten).
- Reinstall the diskette drive control card and the card retainers.
- Connect the head cable to the diskette drive control card.
- Go to 490, step 4.



750 Drive Band Removal

- 1. Power off.
- 2. Remove the diskette drive cover assembly (refer to 420).
- 3. Remove the wiper assembly **E**.
- 4. Disconnect the head cable from the diskette drive control card.
- 5. Remove the card retainers and the diskette drive control card.
- 6. Loosen the two idler mounting screws **C**. Push the idler assembly **D** against the spring tension and tighten the mounting screws.
- 7. Place the head/carriage assembly to about cylinder 40.
- 8. Remove the two band clamp screws **A** and the clamp. Then place the head/carriage assembly at the lower limit (cylinder 00).
- 9. Remove the clamp screw **B** and the clamp.
- 10. Remove the drive band ends from the pulley pin. Then remove the band.

760 Drive Band Replacement



- 1. Place the drive band around the idler assembly.
- 2. Install the drive band ends on the pulley pin as shown **F**.
- 3. Reinstall the band clamp (with the notch facing away from the stepper motor) and the clamp screw **B**. (Ensure that the drive band is straight.)
- 4. Go to 740, step 8.

770 Idler Assembly Removal

- 1. Remove the drive band (refer to 750).
- 2. Loosen the two mounting screws **C**.
- 3. Remove the idler spring **B**.
- 4. Remove the mounting screws and the idler assembly **D**.

780 Idler Assembly Replacement

- 1. Reinstall the idler assembly **D** and the two mounting screws **C**. (Do not tighten the screws.)
- 2. Reinstall the idler spring **B**.
- 3. Push the idler assembly against the spring tension. Then tighten the mounting screws.
- 4. Go to 760.



LED AND PTX ASSEMBLIES


790 Diskette Speed Service Check

1. Insert a diskette. (Ensure that the diskette drive cover assembly is closed.)
2. Install a jumper **A** to activate the head load solenoid.
3. Set up an oscilloscope as follows:

Note: Use a Tektronix 453, 454, or a similar oscilloscope with x10 probes.


Channel A sweep mode	Normal
Channel A level	+
Channel A coupling	DC
Channel A slope	+
Channel A source	Internal
Trigger	Normal
Mode	Channel 1
Channel 1 volts/division	1.0 V/cm
Channel 1 input	DC
Times per division	20 ms
Channel 1 probe to B	+Index Test Pin

4. Observe an index pulse width of 1.5 to 3.0 ms **E** occurring every 166.7 ± 4.2 ms **C**. Pulse amplitude should be between 2.4 and 4.2 Vdc **D**.
5. Remove the jumper **A**.
6. Remove the diskette.



800 LED and PTX Alignment

1. Power off.
2. Remove the diskette drive cover assembly (refer to 420).
3. Loosen the PTX mounting screw **F**.
4. Position the PTX assembly against the casting stop **G** (away from the leads); then tighten the mounting screw.
5. Loosen the two LED mounting screws **J**.
6. Insert two timing pins **H** through the LED into the PTX assembly and tighten the LED mounting screws. Two timing pins are located in the cover assembly (refer to 030).
7. Remove the timing pins.
8. Reinstall the diskette drive cover assembly (refer to 430).
9. Power on.



810 LED Output Service Check

- 1. Connect the negative probe of a multimeter to the ground test pin **C** on the diskette drive control card.
- 2. Set the multimeter scale to 5 Vdc and connect the positive probe to the 43FD LED voltage test pin **A**.
- 3. Check for a voltage level of 1 Vdc to 2 Vdc.
- 4. Move the positive probe to the 33FD LED voltage test pin **B**.
- 5. Check for a voltage level of 1 Vdc to 2 Vdc.

KEY	SIGNAL	PIN
A	43FD LED VOLTAGE	TPB14
B	33FD LED VOLTAGE	TPA12
C	GROUND	TPA6


Note: See paragraph 890 for test pin locations

820 LED Removal

- 1. Power off.
- 2. Remove the diskette drive cover assembly (refer to 420).
- 3. Disconnect the diskette drive control cable from location A2 **L**.
- 4. Remove the two screws **K** and the connector covers.
- 5. Remove the two 33FD LED leads **M** and the two 43FD LED leads **J** by pushing down on the tabs with a small screwdriver.
- 6. Remove the LED cable from the three retainers **F**. (Remember the cable path for the replacement procedure.)
- 7. Remove the four guide mounting screws **E** and the guide.
- 8. Remove the two LED mounting screws **G** and the nuts **H**. Then remove the LED assembly.

830 LED Replacement

- 1. Install the LED assembly, the two mounting screws **G**, and the nuts **H** onto the guide. (Do not tighten.)
- 2. Replace the guide and the four mounting screws **E**.
- 3. Follow the cable path through three retainers **F** and insert two 33FD LED leads (the wrapped pair of leads) **M** and two 43FD leads **J** into the diskette drive control cable connector. Ensure that the locking tabs **D** on the terminals lock in the connector slots.
- 4. Reinstall the cable connector covers and the two screws **K**.
- 5. Plug the cable into location A2 **L** on the diskette drive control card socket.
- 6. Go to 800, step 6.




840 PTX Amplifier Service Check

CAUTION
Always perform this service check with a diskette inserted backward (with the label facing the hub pulley), or the LED light will cause a wrong reading and can destroy the PTX.

1. Power off.
2. Disconnect the drive motor power cable.

DANGER
Voltage is still present at the socket when the power cable is disconnected.

3. Insert a diskette backwards. (Ensure that the diskette drive cover assembly is closed.)
4. Power on.



5. Connect the positive probe of a multimeter (15 Vdc scale) to the index test pin **D** on the diskette drive control card.
6. Connect the negative probe of the multimeter to the ground test pin **E**.
7. Check the multimeter for a reading of less than 1 Vdc.
8. Install one end of a jumper to the 43FD PTX test pin **B**.
9. While observing the multimeter, touch the other end of the jumper to the +5 Vdc test pin **A** several times. The multimeter should read 2.5 Vdc or more when the test pin is touched. (A wrong reading can occur the first time the test pin is touched.)
10. Repeat steps 8 and 9 with the jumper on the 33FD PTX test pin **C**.
11. Power off.
12. Remove the jumper.
13. Remove the diskette.
14. Connect the drive motor power cable
15. Power on.

KEY	SIGNAL	PIN
A	+5 VDC	TPB15
B	43FD PTX	TPB16
C	33FD PTX	TPA14
D	+INDEX	TPB9
E	GROUND	TPA6


Note: See paragraph 890 for test pin locations

850 PTX Removal

- 1. Power off.
- 2. Remove the diskette drive cover assembly (refer to 420).



CAUTION
While performing the following steps, be careful not to damage the LED leads.

- 3. Remove the four guide mounting screws **H** and the guide.
- 4. Disconnect the diskette drive control cable from location A2 **E**.
- 5. Remove the two screws **C** and the two connector covers.
- 6. Remove the two 33FD PTX leads **D** and the two 43FD PTX leads **B** by pushing down on the tabs with a small screwdriver.
- 7. Remove the PTX mounting screw **F** and the washer.
- 8. Remove the PTX assembly. (Remember the cable path for the replacement procedure.)



860 PTX Replacement


- 1. Install the PTX assembly against the casting stop **G** (away from leads,) then reinstall the screw **F** and the washer.
- 2. Follow the cable path and insert the two 33FD PTX leads (the wrapped pair of leads) **D** and the two 43FD leads **B** into the diskette drive control cable connector. Ensure that the locking tabs **A** on the terminals lock in the connector slots.
- 3. Reinstall the connector covers and the two screws **C**.
- 4. Plug the connector into location A2 **E** of the diskette drive control card socket.
- 5. Reinstall the guide and the four mounting screws **H**.
- 6. Go to 800, step 5.



DISKETTE DRIVE CONTROL CARD


870 Control Card Removal

1. Power off.
2. Disconnect the head cable **A** from the diskette drive control card **B**.
3. Remove the card retainers **C**.
4. Remove the diskette drive control card.



890 Control Card Test Pins

OLD card version P/N 8528195



890 Control Card Replacement


1. Reinstall the diskette drive control card **B**. Ensure that the card is seated in the socket.
2. Reinstall the card retainers **C**.
3. Connect the head cable **A** to the diskette drive control card.
4. Power on.

1	2	3
THP1 +Diskette Loaded	TPA1 +Write Data	TPB1 +Access 0
THP2 +Predrive MC-3	TPA2 +Erase Gate	TPB2 +Access 1
THP3 +Predrive MC-2	TPA3 +Write Gate	TPB3 +Access 2
THP4 +Predrive MC-1	TPA4 +Inner Tracks	TPB4 +Access 3
THP5 +Predrive MC-0	TPA5 +Select Head 1	TPB5 +File Data
THP6 +43FD Index	TPA6 Ground	TPB6 +Diskette Sense
THP7 +33FD Index	TPA7 +Erase Current Sense	TPB7 +Head Engage
THP8 Diff Read A	TPA8 +24 Vdc	TPB8 +Switch Filter
THP9 Diff Read B	TPA9 -5 Vdc	TPB9 +Index
THP10 -High Gain	TPA10 MC-1	TPB10 MC-3
THP11 -Align Access 0	TPA11 MC Common	TPB11 MC-0
THP12 -High Current	TPA12 33FD LED Voltage	TPB12 MC-2
THP13 Preamp TP1	TPA13 Ground	TPB13 -Head Load
THP14 Preamp TP2	TPA14 33FD PTX	TPB14 43FD LED Voltage
THP15 -High Gain A		TPB15 +5 Vdc
THP16 -High Gain B		TPB16 43FD PTX

4
For details refer to '910
Control Card Head Cable Pins'.

890 Control Card Test Pins (continued)


NEW card version P/N 4178065




TPB1	+Access 0
TPB2	+Access 1
TPB3	+Access 2
TPB4	+Access 3
TPB5	+File Data
TPB6	+Diskette Sense
TPB7	+Head Engage
TPB8	+Switch Filter
TPB9	+Index
TPB10	MC-3
TPB11	MC-0
TPB12	MC-2
TPB13	-Head Load
TPB14	43FD LED Voltage
TPB15	+5 Vdc
TPB16	43FD PTX

For details refer to '910 Control Card Head Cable Pins'.

900 Control Card Socket and Connector Pins



910 Control Card Head Cable Pins



920 Control Card Interface Description

Note: That two different cards (old and new card version) are in use

The following is a description of the interface lines at connector A1.

Access Lines 0 through 3: Two or four access pulses move the read/write heads from one cylinder to the next cylinder. Notice in the chart that the same pair of access pulses are repeated every four cylinders.

Cylinder Location	In	1	2	3	4	5	40	Out	74	75	76
Access 0	1	0	0	1	1	0	1	0	1	1	
Access 1	1	1	0	0	1	1	1	0	0	1	
Access 2	0	1	1	0	0	1	0	1	0	0	
Access 3	0	0	1	1	0	0	0	1	1	0	

The four access pulses are sequenced to move the heads in (toward the drive hub) or out (away from the drive hub).


+Write Data: For each change of the write data signal, the current switches in the read/write head. This process records the data on the diskette surfaces. (Refer to 170.)

+Write Gate: Write gate activates the write circuits and deactivates the read circuits for a write operation. (Refer to 170.)

+Erase Gate: Erase gate activates the erase circuits for a write operation. (Refer to 170.)

+Erase Current Sense: (Old card version) When this line is active, the erase circuits are working OK.

+Current Enabled: (New card version) This line is active when either the write circuits or the erase circuits are active.



920 Control Card Interface Description (continued)

+Select Head 1: When active, this line selects head 1. (Refer to 170.)

+Head Engage: When active, this line loads the read/write heads.

+Index: This line indicates the beginning of a track. This 1.5 to 3.0 ms pulse occurs every 166.7 ms.


+File Data: File data is a series of clock and data pulses that represent the data read from the diskette surface.

+Diskette Sense: When active, this line indicates that a diskette 2 or 2D is being used. This line is not activated by a diskette 1.


-*Diskette Drive Sense*: This line is normally minus indicating that the diskette drive installed uses type 2 or 2D diskettes.

+Inner Tracks: On a write operation, this line is used to reduce the amount of recording current beyond the middle cylinders. On a read operation, this line is used to compensate for bit shifting beyond the middle cylinders.

+Switch Filter: This line is used with the inner tracks line to further compensate for bit shifting beyond cylinder 60 for MFM encoding. This line is not used on a write operation.



930 Signal Routing




Direction of Signal To From Drive		Two Card Adapter	One Card Adapter	① Adapter Card (S)		② Board Connector		Cable Connector		⑤ Drive Control Card
								③ Board Side Drive 1 : ZF Drive 2 : ZE	④ Drive Side	
•	•	+ Access 0	+ Access 0	J 10	J 10	M6B02	Q6A02	D02	D02	B02
•		+ Access 1	+ Access 1	P 04	P 04	M6C02	Q6B02	D03	D03	B03
•		+ Access 2	+ Access 2	J 13	J 13	M6D02	Q6C02	D04	D04	B04
•		+ Access 3	+ Access 3	P 07	P 07	M6E02	Q6D02	D05	D05	B05
•		+ Write Data	- Write Data 1	J 11	J 11	M6B04	Q6A04	B02	B02	D02
•		+ Write Gate	+ Write Gate	J 12	J 12	M6E04	Q6D04	B05	B05	D05
•		+ Erate Gate	+ Erase Gate	S 08	S 08	M6D04	Q6C04	B04	B04	D04
•		+ Erase Current Sense	+ Erase Current Sense	U 12	U 12	N6D04	R6C04	B09	B09	D09
•		+ Select Head	+ Select Head	M 10	M 10	N6B04	R6A04	B07	B07	D07
•		+ Head Engage	+ Head Engage	U 04	U 04	N6E02	R6D02	D10	D10	B10
•		+ Index	+ Index 1	B 09	B 09	P6C02	S6B02	D13	D13	B13
•		+ File Data	+ File Data 1	B 08	B 08	N6B02	R6A02	D07	D07	B07
•		+ Diskette Sense	+ Diskette Sense	B 04	B 04	N6C04	R6B04	B08	D08	B08
•		+ Unused	- Diskette Drive Sense	-	U 09	N6D02	R6C02	D09	D09	B09
•		+ Inner Tracks	+ Inner Tracks	G 10	G 10	N6A04	Q6E04	B06	B06	D06
•		+ Switch Filter	+ Switch Filter	G 13	G 13	P6E02	S6A02	D12	D12	B12
</										


940 CDF Removal and Replacement

If you are told by the MAP to replace the complete disk drive unit perform the following steps:

- 1. Turn power off.
- 2. Remove diskette from drive to be replaced.
- 3. Remove connector retainer. ❶
- 4. Disconnect DC cable (position A1) from the diskette drive control card. ❷
- 5. Disconnect AC cable: ❸
- 6. Unscrew and remove nut and washer of lower mounting pin. ❹
- 7. Loosen the four screws holding the upper two shock mounts. ❺
- 8. Hold the drive unit and remove the four screws. Remove the whole unit together with the two upper shock mounts.
- 9. Install new drive unit. Perform the above steps in the reverse order.



WARNING:
Make sure that the motor holding
clamps do not touch the motor
housing.



Glossary and Legend

Glossary

AR (amplifier): An electronic circuit that increases the amplitude of a signal for distribution.

DET (detector): An electronic circuit that detects a carried signal and converts it to signal pulse.

AR DIF (differentiator-amplitude): An electronic circuit whose output signal is a function of the time rate of change of the input signal.

Diskette 1: A diskette used for storing data on only one surface.

Diskete 2: A diskette used for storing data on both surfaces.

Diskette 2D: A diskette used for storing data on both surfaces with twice the bit density used on a diskette 2.

DR (driver): An electronic circuit that increases the energy of a signal to a sufficient level to drive a pre-determined load.










LED (ligh emitting diode): An electronic part used as a source of light.

PTX (phototrasistor): An electronic part used to sense the ligh of an LED.

Preamplifier: See amplifier.

VFO (variable frequency oscillator): An electronic circuit used to synchronize the read and write circuits in FM and MFM recording.

Legend



I/O Diskette Drive Tests

Test Handling - Actions

Prerequisites

- Power complete
- IML complete
- Diagnostic diskette inserted in system drive
- Diskette to be tested inserted in I/O device

Caution: Some devices (for example 3741) are capable to flag up to two defective cylinders during initialization and assign alternative cylinders. The I/O diskette drive tests do not support testing with diskettes which do have alternative tracks assigned. The tests with selection 2, 3, 6, 7, and 8 will fail. See 'How to Check for Allocated Cylinders' under test selection 7.

How to Select the Tests

1. Call M/S Program Selection. [A]
2. Key in selection for 'CENTRAL COMPLEX', press ENTER. [B]
3. Select I/O Diskette Drive Maintenance Program. [C]
4. Key in the appropriate test selection.

Handling of Tests (Selection 1 to 8)

After entering the selection ID (1-9) press ENTER to start the test. The selection menu display will not change for selection 1 to 5 but additional information is displayed. [D]

To stop a running test, except test 8, press ENTER again. By pressing ENTER a third time a stopped test can be continued or restarted and so on.

To return to the test selection menu type in an 'R' and press ENTER, select new test.

How to Terminate the Test

If you want to run any test other than a diskette drive test return to M/S PROGRAM SELECTION. Select new test, otherwise perform the following steps:

1. Press ENTER to stop the test

2. Insert control diskette

3. Perform re-IML

4. Return machine

Test Handling - Results

Screen Displays

- [A] 'IBM MAINTENANCE AND SERVICE PROGRAM SELECTION'
- [B] 'CENTRAL COMPLEX TEST SELECTION'

[C]

I/O DISKETTE DRIVE MAINTENANCE PROGRAM

1 = ADAPTER TEST 2 = ACCESS TEST

3 = READ TEST 4 = WRITE TEST

5 = LOOP FUNCTION 6 = MANUAL SELECTION

7 = RECORD DISPLAY 8 = DISKETTE SURFACE

9 = COPY AND FORMATTING

SELECTION:

DATA: ADDR:

ANSWER

[D]

I/O DISKETTE DRIVE MAINTENANCE PROGRAM

1 DISK TYPE

1 = ADAPTER TEST 2 = ACCESS TEST

3 = READ TEST4 4 = WRITE TEST

5 = LOOP FUNCTION 6 = MANUAL SECTION

7 = RECORD DISPLAY 8 = DISKETTE SURFACE

9 = COPY AND FORMATTING

END OF TEST

SELECTION:

ACCESS TEST <-- [B]

TIMER: OFF DATA: ADDR:

STOPPED <-- [C]

[A] For selection 2 to 5 and 6 the disk type used is displayed here.

Diskette 1: One-sided diskette with 128, 256, or 512 bytes per record.

Diskette 2: Two-sided diskette with 256 bytes per record.

Diskette 2D: Two-sided, double density diskette with 256, 512 or 1024 per record.

[B] This field displays the name of the test currently executed, or a message indicating how to continue.

[C] Status field

I/O Diskette Drive Tests (continued)

Test Handling - Actions

Test Selection 1

By entering a 1 in the selection field, the adapter test is selected. Its purpose is to:

- 1. Reset the adapter and test for correct results.
- 2. Test if the drive is ready.
- 3. Test if the channel pointer is operational.
- 4. Test both adapter buffers with various data patterns.
- 5. Test if the access drive electronic switches properly.
- 6. Execute a head switching test.

Test Selection 2

By entering a 2 the 'access test' is invoked. Its purpose is to execute a:

- 1. Seek cylinder 0 and test if cylinder 00
- 2. Seek cylinder 76 and test if cylinder 76
- 3. Seek cylinder 1 and test if cylinder 01
- 4. Seek cylinder 75 and test of cylinder 75
- 5. To ... and so forth until all cylinders have been accessed.

Test Selection 3

By entering a 3 the 'read test' is invoked. Its function is the same as the access test, but in addition a 'read record' operation is performed after each access cycle.

Test Selection 4

By entering a 4 the 'write test' is invoked. Its purpose is to:

- 1. Execute a 'seek cylinder 0' and test of cylinder 0

- 2. Write various data pattern to record 3, cylinder 0, head 0
- 3. Read data written back into storage and compare write data with read data

Test Selection 5

By entering a 5 the 'loop function' is invoked. This function runs the before described tests (selection 1, 2, 3, and 4) as one test in the sequence of their selection number. At the end of test 4 the test string is repeated starting with test one again.

Test Selection 6

By entering a 6 in the selection field, the Manual Selection Menu is displayed. E

Two subselections are possible by entering :
1 for ACCESS or
2 for READ

Press ENTER.

Access

After selection of ACCESS the input field for the FROM and TO CYLINDER is displayed.

SELECT FROM-CYLINDER #: CC
SELECT TO-CYLINDER #: CC

Read


After selection of READ the input field for record number is displayed.

SELECT RECORD #: CCHRRR

CC	HH	RR	
			Record number (1 to 26)
			Head number
			Cylinder number

These parameters have to be entered in decimal notation. Otherwise the message 'INVALID' is displayed.

Test Handling - Results



- A Three asterisks are displayed behind the selected test.
- B Disk type used: For explanation see A on page 5100.
- C Data input field is displayed after test selection.

I/O Diskette Drive Tests (continued)

Test Handling - Actions

Test Selection 6 (continued)

For the head parameter any decimal number from one and higher is accepted as head one selection.

The ACCESS and READ routines we are running in a continuous loop. The loop can be stopped and/or started by pressing the ENTER key.

By stopping the test and entering an 'S' behind SELECTION the cursor moves to the parameter field thus allowing to alter the parameters. Press ENTER to continue the test with new parameters. To switch from ACCESS to READ or vice versa return to Main Selection Menu by entering 'R' behind SELECTION.

Test Selection 7

By entering a 7 as selection, the 'record display' picture is selected.


Enter the record number in the format 'cylinder-head-record' in decimal notation, press 'ENTER'. This causes the selected record to be displayed [F].

Up to 256 bytes can be displayed in a frame. If a 512 or 1024 byte record has to be displayed the display consists of two or four frames. When the first frame is displayed and the record exceeds 256 bytes the word 'AGAIN' is displayed behind 'Selection', press 'ENTER' to display next frame of record.

How to Check for Allocated Cylinders

Display record 5 enter for CCHHRR = 000005 to check for defective (allocated) cylinders. Check data bytes 7, 8, and 9 for X'404040'. If value differs, alternate tracks are assigned.

Test Handling - Results



- (A) Message field, giving the size of the record for example:
256 BYTES/RECORD
- on information how to proceed.
ENTER TO GO TO SELECTION

- (B) Status field, the message STOPPED, RUNNING, INVALID, or ERROR can appear. In addition to 'ERROR' a reference code is shown.
- (C) Enter field for the record to be displayed.
- (D) This field shows the number of the displayed record.

This means press ENTER to return to the main selection picture. In this case the displayed record information is lost.

I/O Diskette Drive Tests (continued)

Test Handling - Actions

Test Selection 8

By entering 8 the 'Diskette Surface Analysis' test is invoked. **G**

This test checks the diskette for defective tracks. Data of the first detected error on a track is displayed. Up to eight errors per line or a total of 32 errors can be displayed.

Example for an error display: ©

First Error				Second Error			
14	01	18	40	16	00	19	20
CC	HH	RR	-----				
			Error code				
			40 = CRC check				
			30 = Record				
			= not found				
			20 = Underrun/Overrun				

I/O Diskette Drive Tests (continued)

Test Handling - Actions

Purpose

This program is only intended to produce copies of control and/or diagnostic diskettes. These diskettes are two D-type diskettes with a 256 bytes/record format. Therefore the

- Diskette to be formatted must be a 2D-type diskette.
- Diskette is formatted for 256 bytes record.
- If other type diskettes are mounted unpredictable errors may occur.

Test Selection 9

By typing in a '9' the 'I/O Diskette Drive Copy and Formatting Program' is invoked. [H]

This program offers two subsections:

- 1 = Formatting and Copy Diskette Routine
- 2 = Copy only Diskette Routine
- The routine is about fifteen minutes for subsection one and seven minutes for subsection two. These programs cannot be stopped during execution.

Subselection 1

This subsection calls a program routine which in its first phase will format a diskette before the contents of another diskette is written (copied) one to one onto this new formatted one.

The messages displayed inform you which cylinder is just processed or, when the execution of a program step is finished, which action has to be taken to continue.

Subselection 2

The program called by this subsection allows you only to execute the copy function. Messages are displayed in the same way as for subsection 1.

Test Handling - Results

[H] I/O DISKETTE DRIVE COPY AND FORMATTING PROGRAM
1 = FORMATTING AND COPY DISKETTE ROUTINE
2 = COPY ONLY DISKETTE ROUTINE
SELECTION: DATA: ADDR:
ANSWER

Subselection 1 = Example for Message Display:

The first screen display for subsection one tells you

I/O DISKETTE FORMATTING ACTIVE

and asks you to

INSTALL DISKETTE TO I/O DRIVE.
ANSWER

Insert diskette to be formatted and written during the copy operation, press ENTER in reply to ANSWER.

The screen now tells you

I/O DISKETTE FORMATTING ACTIVE
CYLINDER-NUMBER 00 } Running
76 }

The program stops with

CYLINDER-NUMBER 00
FORMATTING END
ANSWER

Press ENTER in reply to ANSWER. This calls the next display message.

I/O DISKETTE COPY PROGRAM ACTIVE
INSTALL DISKETTE TO SYS DRIVE
ANSWER

The diskette just formatted remains in the I/O drive. During the copy program cycle which follows next, the diskette in the system drive is read and the information is written onto the diskette in the I/O drive. Insert the diskette to be copied into the system drive, press ENTER.

I/O DISKETTE COPY ACTIVE
CYLINDER-NUMBER 00 } Running
76 }

The program stops with

END OF COPY DISKETTE
ANSWER

If the diskette in the system drive is not the RAS diskette, reinsert the RAS diskette, then press ENTER to return to the 'M/S Program Selection' picture.

Sense Byte 2 Explanation

Sense byte 2 contains a Hex code for all errors, except command reject cases (which are programming errors). The information in sense byte 2 is a directory to recovery actions as well as an error log. The contents of sense byte 2 should be recorded on SYS REC for later retrieval via EREP.

Error Definition

The errors that may occur in the diskette drive and causing a hex code indication are:

- Data record errors (both when writing or reading data)
- ID field errors (both when writing or reading data)

Read or Write Data Errors

Write and read data errors during plain reading or readback after writing (as occurs on the last record) are indicated by equipment check and automatic retry (or permanent error). The hex code for the individual case is as follows:

Error Code	Type of Read Data Error	User Diskette Control Indication
D3	Data or delete control record CRC-error (data check, auto retry)	No indication
E4	Attachment overrun (equipment check, auto retry)	No indication
D0	Special record transferred (data check, special record transfer)	No indication
D9	Control flag invalid, that is, contains something other than C4 or C6 (EBCDIC) or 44 or 46 (ASCII) (data check, permanent error)	No indication

ID Errors During Read or Write Operations

These errors cause an error code to be displayed. This error code displays the contents of sense byte 2. The following error codes are possible:

Error Code	Type of ID field Error	User Diskette Control Indication
AE	No ID field addr. marker found (intervention required, motion malfunction, and retry after intervention complete)	Not ready, defective diskette
AF	ID field read with wrong cylinder number (intervention required, motion malfunction, retry after intervention complete)	Not ready, defective diskette
E9	ID field read with correct CRC but with incorrect head number, (something other than 0 or 1), or unknown length (equipment check, permanent error)	No indication
E2	Record not found but at least one valid ID found, CRC good (equipment check, auto retry)	No indication
E3	Fast or slow diskette speed (equipment check, auto retry)	Not ready
	Note: This error is used as an interim error when an I/O operation is issued to the attachment which is not ready (cover is opened). Because the error is retrievable, a subsequent retry operation will result in unit check with intervention complete indicated in the sense data.	

System Diskette Drive Test (53FD Diagnostics)

Tests Available

There are no tests available to check functions such as read, write, or seek. These functions are tested automatically during IML. The only function selectable for the system drive (only available if no I/O drive is installed) is the Diskette Surface Analysis test. This test allows the CE to check diskettes for defective tracks.

Test Handling - Actions

Prerequisites

- Power complete
- IML complete
- Diagnostic diskette inserted

How to Select the Test

1. Call M/S PROGRAM SELECTION [A]
2. Key in selection for CENTRAL COMPLEX, press ENTER. [B]
3. Select 53FD diagnostic test, press ENTER. [C] This selection will in this case (only system drive installed) directly display the DISKETTE SURFACE ANALYSIS screen picture. Follow the instructions given in the display. During the test execution the number of the currently tested track is displayed. At test end picture [D] is displayed. Error information varies depending of the test result.

Function

This test checks the diskette for defective tracks. Data of the first detected error on a track is displayed. Up to eight per line or a total of 32 errors can be displayed.

Example for error display: [C]

First error				Second error			
14	01	18	40	16	00	19	20
V	V	V		+>> Error code			
CC	HH	RR		40 = CRC check			
				30 = Record not found			
				20 = Underrun/overrun			
CC = Cylinder							
HH = Head							
RR = Record							

Note that this program when started can not be stopped except by pressing MOD SEL key which causes a return to the M/S PROGRAM SELECTION picture.

Test Handling - Results

Screen displays:

- [A] IBM MAINTENANCE AND SERVICE PROGRAM SELECTION
- [B] CENTRAL COMPLEX TEST SELECTION

[C] DISKETTE SURFACE ANALYSIS

.....

.....INSTALL DISKETTE TO BE TESTED TO DRIVE.....

.....PRESS ENTER TO START OPERATION.....

NUMBER OF DEFECTIVE TRACKS

SELECTION: TIMER:OFF DATA: ADDR:

STOPPED

[D] DISKETTE SURFACE ANALYSIS

[C] -->140118.40.160019.20.....

.....

.....

.....

NUMBER OF DEFECTIVE TRACKS 0002 <-- [B]

SELECTION: TIMER:OFF DATA: ADDR:

STOPPED

- [A] Four lines for error display. Up to eight errors can be displayed per line.
- [B] Total count of all tracks in error. This count can exceed the count of displayable errors which is 32.

This page has been
intentionally left blank


SUPPLEMENT TO MAPS, SECTION 6: CONFIGURE PROCEDURES

TABLE OF CONTENTS

TITLE	PAGE
CONTENTS OF SECTION 6	6000
OVERALL PICTURE OF CONFIGURE DOCUMENTATION	6004
CONFIGURE SCREENS	6008
I/O DEVICE ADDRESS CHART	6016
SYSTEM CHART (FILLED IN BY FE & CUST)	6018
SYSTEM CHART (CONTINUED)	6019
DISKETTE CONFIGURATION	6100
BLANK PAGE	6101
DETAILED SCREEN CONFIGURE INSTRUCTIONS	
SET TIME OF DAY CORRECTION	6110
ALTER CHANNEL NUMBER	6112
CONFIGURE NATIVE DISPLAYS AND PRINTERS	6124
CONFIGURE CUSTOMER DISKETTE	6126
CONFIGURE FTA 1 OR 3 (DISK)	6130
CONFIGURE FTA 2 - (8809)	6135
FTA CONFIGURE ERROR MESSAGES	6138
CONFIGURE HSC SUBCHANNELS	6143
HSC SCREENS AND ERRORS	6144
CONFIGURE BMPX SUBCHANNELS	6145
BMPX CONFIGURATION BLOCK ERRORS	6146
DEVICE TABLES FOR BMPX SUBCHANNELS	6146
CONFIGURATION OF CA	6160
CONFIGURATION OF THE LOOP	6165
BLANK PAGE	6166
COPY CONFIGURATION	6170
COPY CONFIGURE CHARTS	6172
COPY CONFIGURE CHARTS (CONTINUED)	6174
BLANK PAGE	6176
MES UPDATE WITHOUT A NEW DISKETTE	6190


TITLE	PAGE
BLANK PAGE	6191
DEVICE RESTRICTIONS ON THE 4331	6200
BLANK PAGE	6201

OVERALL PICTURE OF CONFIGURE DOCUMENTATION



CONFIGURE SCREENS

THIS PAGE IS INCLUDED HERE TO SHOW THE RELATIONSHIP BETWEEN THE CONFIGURE
SCREENS. THE PICTURES ARE SMALL SO THAT THEY CAN ALL BE SHOWN ON ONE PAGE.
FOR DETAILED INFORMATION, GO TO THE STM PAGE NOTED BY THE PICTURE.



SYSTEM CHART

CHANNEL ASSIGNMENTS

ASSIGNMENTS FOR 4331 MODEL 2		
CHANNEL NUMBER	ASSIGNED ADAPTER	REMARKS
0	MPX/CA/BBA	MUST BE CHANNEL 0
1	BMPX 1	
2	FTA 1	
3	FTA 2	EXCLUSIVE WITH BMPX 2 OR HSC
4	BMPX 2	EXCLUSIVE WITH FTA 2
5	FTA 3	EXCLUSIVE WITH HSC
6	HSC	EXCLUSIVE WITH FTA 2 OR FTA 3 INSTALLED

ASSIGNMENTS FOR 4331 MODEL 11		
CHANNEL NUMBER	ASSIGNED ADAPTER	REMARKS
0	MPX/CA/BBA	MUST BE CHANNEL 0
1	BMPX	
2	FTA 1	
3	FTA 2	

Note: Channel numbers are usually assigned as shown in in the charts. However, addresses 1 through 6 may be assigned to any channel except MPX by using the ter channel configure screen. See 'STM 6112'.

TIME-OF-DAY (TOD) CORRECTION IS E/W HRS

BBAO (DCA) IS CHANNEL 0								MPX IS CHANNEL 0								CA IS CHANNEL 0			LOOP ADAPTER		
PORT	DEV	TYPE	ADDR	T	PORT	DEV	TYPE	ADDR	T	DEV	TYPE	ADDRESS	DEV	TYPE	ADDRESS	INST	ADDR	LINE	TYPE	LOOP PRECONFIGURED BY MANUFACTURING TO TEST MACHINE AT INSTALLATION. ACTUAL CONFIGURING OF LOOP IS THE CUSTOMER'S RESPONSIBILITY.	
00					08											Y / N	30				
01					09											Y / N	31				
02					10											Y / N	32				
03					11											Y / N	33				
04					12											Y / N	34				
05					13											Y / N	35				
06					14											Y / N	36				
07					15											Y / N	37				
CUST DISKETTE IS CHANNEL 0								MFCU IS CHANNEL 0				CHANNEL SUMMARY:						SEE DETAILED LINE DESCRIPTION , STM FEATURES, CA SECTION AND MAP 88FF.			SEE DETAILED INFORMATION IN STM VOL.15 SECTION 6 'CONFIGURATION'.
INSTALLED				ADDRESS				INSTALLED				ADDRESS				FTA 1 IS CHANNEL		HSC IS CHANNEL			
Y		N						Y		N		4C		FTA 2 IS CHANNEL		BMPX 1 IS CHANNEL					
														FTA 3 IS CHANNEL		BMPX 2 IS CHANNEL					

SYSTEM CHART (CONTINUED)

FTA 1 (DISK)						FTA 2 (8809)		FTA 3 (DISK)							
DEV TYPE	ADDR	S/SW	.	DEV TYPE	ADDR	S/SW	DEV TYPE	ADDR	DEV TYPE	ADDR	S/SW	.	DEV TYPE	ADDR	S/SW
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N
_____	_____	Y/N	.	_____	_____	Y/N	_____	_____	_____	_____	Y/N	.	_____	_____	Y/N

BLOCK 1 MULTIPLEXER (BMPX)					BLOCK 2 MULTIPLEXER (BMPX)				
DEV TYPE	ADDR	.	DEV TYPE	ADDR	DEV TYPE	ADDR	.	DEV TYPE	ADDR
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____
_____	_____	.	_____	_____	_____	_____	.	_____	_____

HIGH SPEED CHANNEL (HSC)*				
DEV TYPE	ADDR	.	DEV TYPE	ADDR
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____
_____	_____	.	_____	_____

* Note: Any control unit, such as the 3880, which can run in data streaming mode, must be internally switched to data streaming mode! This allows 400 feet of interface cable length.

DISKETTE CONFIGURATION

THE FUNCTIONAL MICROCODE CAN BE ON ONE OR TWO DISKETTES. A 4331 CAN BE SHIPPED WITH ONE OR TWO SETS OF FUNCTIONAL MICRO CODE (CONTROL DISKETTES) AND ONE DIAGNOSTIC DISKETTE. THEREFORE, YOU WILL RECEIVE EITHER 1, 2 OR 4 CONTROL DISKETTES AND ALWAYS 1 DIAGNOSTIC DISKETTE.

WHEN YOU ARE READY TO CONFIGURE THE FIRST CONTROL DISKETTE (FUI, SEQ. 1), THERE MAY OR MAY NOT BE ANY ADDRESSES CONFIGURED.

YOU MUST CHECK/ADD/DELETE CONFIGURATION DATA SO THAT IT AGREES WITH THE PHYSICAL MACHINE AND THE CUSTOMER ADDRESS ASSIGNMENTS.

OPERATING THE 4331 WITH INCORRECT CONFIGURATION DATA CAN CAUSE HARD DIAGNOSE PROBLEMS WHEN CUSTOMER APPLICATIONS ARE RUN ON THE SYSTEM.

START MANUAL CONFIGURATION OF SYSTEM CONTROL DISKETTE.

THIS PROCEDURE SHOULD BE FOLLOWED TO DO A COMPLETE MANUAL CONFIGURATION OF THE 4331 SYSTEM. EACH CONFIGURATION STEP DIRECTS YOU TO DETAILED INFORMATION FOR THAT PARTICULAR CONFIGURATION ACTION. WHEN YOU HAVE COMPLETED THE ACTION, RETURN TO THE NEXT STEP ON THIS PAGE.

STEP 1. CHECK THE 'SYSTEM CHART.' STM - 6018 AND 6019.

RECORD ANY MISSING INFORMATION. THE 'SYSTEM CHART' WILL BE USED FOR STEPS 2 THROUGH 10.

STEP 2. SET TIME-OF-DAY CORRECTION. STM - 6110

USE INFORMATION FROM THE 'SYSTEM CHART' SET TOD CORRECTION. THIS MUST BE DONE SO THAT TOD ON THE LOGS WILL MATCH THE TOD OF THE ERROR.

STEP 3. ALTER CHANNEL NUMBER. STM - 6112

USE INFORMATION FROM THE 'SYSTEM CHART' TO CHECK OR ALTER CHANNEL NUMBER SETTINGS.

STEP 4. CONFIGURE NATIVE DISPLAYS AND PRINTERS. STM - 6124

USE INFORMATION FROM THE 'SYSTEM CHART' TO CONFIGURE NATIVE DEVICES.

STEP 5. ASSIGN ADDRESS TO CUSTOMER DISKETTE. STM - 6126 (SKIP IF NO CUSTOMER DISKETTE)

USE INFORMATION FROM THE 'SYSTEM CHART' TO ASSIGN THE CUSTOMER DISKETTE ADDRESS.

STEP 6. CONFIGURE FTA 1 OR 3. STM - 6130 (SKIP IF FTA NOT INSTALLED)

USE INFORMATION FROM THE 'SYSTEM CHART' TO CONFIGURE FTA 1 OR 3.

STEP 7. CONFIGURE FTA 2. STM - 6135 (SKIP IF FTA 2 NOT INSTALLED)

USE INFORMATION FROM THE 'SYSTEM CHART' TO CONFIGURE FTA 2.

STEP 8. CONFIGURE HIGH SPEED CHANNEL. STM - 6143 (SKIP IF HSC NOT INSTALLED)

USE INFORMATION FROM THE 'SYSTEM CHART' TO CONFIGURE BLOCK MPX.

STEP 9. CONFIGURE BLOCK MULTIPLEX CHANNEL 1 OR 2. STM - 6145 (SKIP IF BMPX(S) NOT INSTALLED)

USE INFORMATION FROM THE 'SYSTEM CHART' TO CONFIGURE BLOCK MPX.

STEP 10. CONFIGURE CA. STM - 6160 (SKIP IF CA NOT INSTALLED) IN ADDITION TO THE 'SYSTEM CHART' YOU WILL ALSO NEED THE DETAILED CA LINE DESCRIPTIONS FROM THE STM FEATURES, AND MAP 88FF. THE LINE DESCRIPTION CHARTS ARE AT END OF THE CA PAGES IN THE STM FEATURES BOOK.

STEP 11. LOOP CONFIGURATION STM 6165 (SKIP IF NOT INSTALLED). THE LOOP ADAPTER CONFIGURATION IS THE RESPONSIBILITY OF THE CUSTOMER. THE LOOP IS PRECONFIGURED TO ALLOW TESTING OF THE SYSTEM. CONTINUE WITH NEXT STEP.

BY COMPLETING STEPS 1 THROUGH 11 YOU HAVE WRITTEN YOUR EXACT CONFIGURATION ON ONE OF THE CONTROL DISKETTES. YOU MUST NOW COPY THIS DATA TO THE OTHER CONTROL DISKETTE. THE CONFIGURATION DATA MUST ALSO BE COPIED TO THE DIAGNOSTIC DISKETTE TO PREVENT INVALID ERROR STOPS DURING TESTING.

STEP 12. DO THE COPY CONFIGURE. STM - 6170

ALL OF THE SYSTEM DISKETTES ARE NOW CONFIGURED.

IF YOU WERE DIRECTED TO STM SECTION 6 BY SOME OTHER INSTRUCTIONS (EC, MES, INSTALL MANUAL, ETC.), RETURN TO THOSE INSTRUCTIONS.

This page has been
intentionally left blank

CONFIGURE TIME OF DAY CORRECTION

PURPOSE

OFTEN A CUSTOMER USES GMT (GREENWICH MEAN TIME) TO GIVE A COMMON TIME BASE THROUGHOUT HIS NATIONWIDE OR WORLDWIDE ORGANIZATION. HOWEVER, HE ALSO NEEDS LOCAL TIME FOR REALISTIC TIMESTAMPING OF PRINTOUTS AND CONSOLE MESSAGES. FOR THESE PURPOSES THE CUSTOMER HAS TO SET A TOD CORRECTION FACTOR (SOFTWARE) TO ADJUST BETWEEN GMT AND LOCAL TIME. THE CE ALSO NEEDS THIS CORRECTION FOR REALISTIC TIMESTAMPING OF HIS LOGS. BUT HE HAS NO ACCESS TO THE SOFTWARE TOD CORRECTION. THEREFORE THE SYSTEM HAS A SECOND CORRECTION FACTOR SETTING.

HANDLING

THE SOFTWARE TOD CORRECTION FACTOR IS SET BY THE CUSTOMER AT SYSTEM GENERATION OR IPL TIME TO SET THE SYSTEM CLOCK TO GMT AND TO ADJUST TO LOCAL TIME FOR TIMESTAMPING. THE SECOND TOD CORRECTION HAS TO BE SET BY THE CE/FE TO ASSURE THAT THE TIME RECORDED IN A LOG INDICATES THE LOCAL TIME, (SEE WARNING BELOW).

TO CONFIGURE TOD CORRECTION YOU MUST KNOW THE TOD CORRECTION USED BY THE CUSTOMER SYSTEM. MAKE SURE THE CUSTOMER TOD CORRECTION IS ENTERED ON THE 'SYSTEM CHART' ON STM 6018.

THE TOD ON LOGS WILL ONLY BE CORRECT IF YOUR TOD CORRECTION IS THE SAME AS THE TOD CORRECTION USED BY THE CUSTOMER SYSTEM. IF THE CUSTOMER INDICATES THAT NO TOD CORRECTION IS USED, THEN YOU MUST SET YOUR TOD CORRECTION 00 HOURS AND 00 MINUTES EAST OR WEST.

THE SCREEN EXAMPLE ON THIS PAGE SHOWS THE CORRECT SETTING FOR CHICAGO, DURING THE WINTER (CENTRAL STANDARD TIME). IN THE SUMMER WITH DAYLIGHT SAVING TIME, THE SETTING WOULD BE 07 HRS INSTEAD OF 06 HRS.

WARNING

THE LOOP FEATURE ALSO USES THE CE TOD-CORRECTION FACTOR TO GIVE CORRECT TIME TO THE LOOP TERMINALS. THEREFORE ALWAYS CONTACT THE CUSTOMER FIRST IF YOU WANT TO CHANGE THE TOD-CORRECTION FOR A SYSTEM THAT HAS THE LOOP FEATURE INSTALLED.

CONFIGURE PROCEDURE

- 1. DISPLAY THE 'TOD CORRECTION' SCREEN.
 - A. ALT KEY WITH MODE SEL TO GET THE MAINTENANCE SELECTION SCREEN.
 - B. SELECT 'UTILITIES/REMOTE'
 - C. SELECT 'TOD CORRECTION.'THE ACTUAL CORRECTION FACTOR IS DISPLAYED, DEFAULT = 00 00 E.
- 2. IF THE DISPLAYED TOD-CORRECTION IS CORRECT, GO TO STEP 4. IF NOT, ENTER THE CORRECT FIGURES, HIT ENTER AND WAIT FOR THE 'ACTION DONE' MESSAGE.

VERIFICATION

TO VERIFY WHICH TIME A LOG WILL GET AS TIME STAMP DO THE FOLLOWING:

AFTER THE CUSTOMER HAS PERFORMED IPL, SELECT EITHER 'ERASE SELECTIVE LOG' OR 'ERASE ALL LOGS' FROM THE 'LOG MODE' MENU. IF THE TIME DISPLAYED ON THE SCREEN ABOVE THE SYSTEM MODE (370 OR VSE) MATCHES THE LOCAL (REAL) TIME, TOD CORRECTION IS SET PROPERLY. IF THE TIME DOES NOT MATCH, CORRECT THE ACTUAL CORRECTION FACTOR BY THE DIFFERENCE OF LOCAL AND DISPLAYED TIME.

- 3. THE SCREEN DISPLAYS NOW THE NEW CORRECTION FACTOR WHICH WAS JUST WRITTEN ON THE DISKETTE. IF THE SETTING OF THE TOD CORRECTION IS NOT PART OF THE SYSTEM CONFIGURATION, DO COPY CONFIGURATOR TO GET THE NEW SETTING ON ALL OTHER DISKETTES.
- 4. ALT KEY AND MODE SEL WILL RETURN YOU TO THE MAINTENANCE SELECTION SCREEN.

THE TOD CONFIGURE ACTION IS COMPLETED.

LV: 79235180TIME-OF-DAY-CLOCK ZONE CORRECTION

THE TIME-OF-DAY-CLOCK IS SET TO GMT (GREENWICH MEAN TIME).

TO GET YOUR LOCAL TIME DISPLAYED IN ALL LOGS ENTER THE

ZONE CORRECTION VALUES FOR YOUR TIME ZONE.

YOU ARE 06 HOURS 00 MINUTES W EAST/WEST OF GREENWICH (GB).

370 TIMER:OFF DISK DATA: ADDR:

TOD:SECANSWER

0700

TOD ERROR MESSAGES

'WRONG INPUT' ALONG WITH RC FE622081.

MEANS: THE TOTAL OF THE HOURS AND MINUTES IS GREATER THAN 12 HOURS.

ALTER CHANNEL NUMBER

CONFIGURE PROCEDURE

1. DISPLAY THE 'ALTER CHANNEL NUMBER' SCREEN
A. ALT KEY WITH MOD SEL TO GET THE MAINTENANCE SELECTION SCREEN.
B. SELECT 'UTILITIES/REMOTE'
C. SELECT 'ALTER CHANNEL NUMBER'
2. IF THE DISPLAYED 'CURRENT CHANNEL NUMBERS' MATCH THE CHANNEL SUMMARY IN THE 'SYSTEM CHART', GO TO STEP 6.
3. MAKE ANY NEEDED CHANGES TO THE 'ALTER CHANNEL NUMBER' LINE AND HIT ENTER.

ERROR MESSAGES AND PROBABLE CAUSES ARE LISTED UNDER THE SCREEN PICTURE.
4. YOU MUST NOW ANSWER A QUESTION. --STORE Y/N--
IF THE SCREEN IS CORRECT, ENTER 'Y' AND WAIT FOR MSG 'CHANGE IS STORED ON DISKETTE.' IF THE SCREEN IS NOT CORRECT, ENTER AN 'N' AND GO BACK TO STEP 3.
5. HIT ENTER AGAIN IF YOU WANT TO DISPLAY THE NEW CHAIN CONFIGURATION.
6. MOD SEL WILL RETURN YOU TO THE MOD SELECTION SCREEN.

THE CHANNEL ADDRESS CONFIGURATION IS COMPLETE.

ALTER CHANNEL NUMBER

XXXXX IS INDICATED IF NO ADAPTER ATTACHED

ADAPTER NUMBER	0	1	2	3	4	5	6	7
ADAPTER TYPE	HSC	XXXXX	BMPX2	MPX	FTA1	BMPX1	XXXXX	BBA0
ADAPTER TYPE				CA				BBA1
CURRENT CHANNEL NUMBER	6	X	4	0	2	1	X	0
ALTER CHANNEL NUMBER:	.	.	.	0	.	.	.	0

16MB VSE TIMER:OFF DISK DATA: ADDR:
TOD:SEC

0700

ERRORS FOR ALTER CHANNEL NUMBER

- 'DUPLICATE CHANNEL NUMBER' --- CHECK SCREEN. ONLY ONE OF EACH CHANNEL NUMBER ALLOWED.
- 'NO ADAPTER ATTACHED' --- YOU HAVE ENTERED A NUMBER UNDER AN 'X'.
- 'CHANNEL NUMBER NOT VALID' --- ONLY 1 THRU 6 ARE ALLOWED.
- 'INVALID CHARACTER' --- CURSUR WILL POINT TO INVALID AREA.
- 'CHANNEL 0 WAS SPECIFIED' --- ONLY MPX, CA, BBA0 AND BBA1 CAN BE CHANNEL 0
- 'INVALID OR MISSING STORE COMMAND' --- ANSWER YES OR NO AND HIT ENTER.
- 'INCORRECT CONFIGURATION TABLE' --- YOU MUST COPY CONFIG FROM A GOOD DISKETTE TO CORRECT THIS.
- 'CHANNEL 0 MUST NOT BE CHANGED' --- MPX, CA, BBA0 AND BBA1 MUST BE CHANNEL 0.

CONFIGURATION OF NATIVE DISPLAYS AND PRINTERS

THE DISPLAY CLUSTER ADAPTER (DCA) SUPPORTS EITHER 8 OR 16 DEVICES. THE SCREEN SHOWN IS FOR 16 DCA PORTS. ON PORT 00, THE DEVICE/ADDR/T FIELDS ARE PRE-CONFIGURED FOR 3278-2A/01F/1. IF 3279-2C IS SHIPPED AS OPERATOR CONSOLE, THE PRECONFIGURED DEVICE TYPE FOR PORT 00 HAS TO BE CHANGED.

CONFIGURATION PROCEDURE

- 1. DISPLAY THE 'NATIVE DISPLAYS AND PRINTERS' SCREEN.
 - A. MODE SEL TO GET THE 'MODE SELECTION' SCREEN.
 - B. SELECT 'NATIVE DISPLAYS AND PRINTERS/ROCF'.
 - C. SELECT 'NATIVE DISPLAYS AND PRINTERS.'
- 2. IF THE DISPLAYED INFORMATION IS CORRECT ACCORDING TO THE 'SYSTEM CHART', GO TO STEP 5.
- 3. USING 'SYSTEM CHART', COMPLETE THE 'DEVICE/ADR/T' FIELD (T FIELD IS NOT NEEDED FOR THE 3289) FOR EACH PORT TO BE USED. VALID ENTRIES ARE SHOWN AT THE TOP OF THE SCREEN.

ONLY THE FIELDS MARKED WITH THE INTENSIFIED '.....' CAN BE CHANGED. ENTER THE DEVICE EXACTLY AS SHOWN, STARTING AT THE LEFT END OF THE FIELD.
THE MODEL NUMBER NEED NOT BE TYPED IN. ENTER ONLY THE 4 DIGIT DEV.TYPE LEFT ADJUSTED.

- 4. HIT ENTER, AND WAIT FOR 'UPDATE COMPLETE, PRESS IML' MSG. ** DO NOT IML ** THIS IS A CUSTOMER MESSAGE. IML AFTER ALL CONFIGURATION ACTIONS ARE COMPLETED. THE SCREEN NOW SHOWS YOUR CURRENT CONFIGURATION.

- 5. MODE SELECT TO RETURN TO THE 'MOD SELECTION' SCREEN.

CONFIGURATION OF 'NATIVE DISPLAYS AND PRINTERS' IS COMPLETE.

NATIVE DISPLAYS AND PRINTERS
(DEVICE ADDRESS RANGE: X'009' - X'01F')

ATTACH DEVICES: 3262, 3278, 3279, 3287, 3289 DETACH DEVICES: KEY IN 'X'
TRANSLATE TABLES(T) :TYPEWRITER (UNITED STATES) = 1
DATA ENTRY I (UNITED STATES) = 2

PORT	DEVICE	ADR	T	PORT	DEVICE	ADR	T	PORT	DEVICE	ADR	T	PORT	DEVICE	ADR	T
00	3278...	01F	1	01	XXXXXXX	XXX	X	02	XXXXXXX	XXX	X	03	XXXXXXX	XXX	X
															
04	XXXXXXX	XXX	X	05	XXXXXXX	XXX	X	06	XXXXXXX	XXX	X	07	XXXXXXX	XXX	X
															
08	XXXXXXX	XXX	X	09	XXXXXXX	XXX	X	10	XXXXXXX	XXX	X	11	XXXXXXX	XXX	X
															
12	XXXXXXX	XXX	X	13	XXXXXXX	XXX	X	14	XXXXXXX	XXX	X	15	XXXXXXX	XXX	X
															

370

TIMER:ON

DISK

DATA:

ADDR:

TOD:SEC

0700

NOTE: IF 8 PORTS ARE AVAILABLE ONLY, THE MESSAGE: 'ONLY 8 PORTS EFFECTIVE' WILL APPEAR ON SCREEN ON LINE 3.

ERROR MESSAGES:

- 'INVALID CHARACTER' -----
- 'INVALID DEVICE NAME' ----- YOU CAN ONLY ATTACH THE DEVICES SHOWN AT TOP OF THE SCREEN
- 'INVALID DEVICE ADDRESS' ----- SEE 'DEVICE ADDRESS RANGE' ON THE SCREEN
- 'INVALID CONFIGURATION' ----- 3278-2A/3279-2C ONLY ON PORT 0.
NO MORE THAN TWO 3289's ALLOWED.
- 'INVALID KEYBOARD LANGUAGE' ----- ONLY 1 OR 2 ALLOWED FOR 'T.' MUST BE ENTERED
DISPLAYS AND 3287.
- 'DUPLICATE DEVICE ADDRESS' ----- THIS ADDRESS IS ALREADY USED BY ANOTHER
DEVICE
- 'DUPLICATE DISKETTE ADDRESS' ----- THIS ADDRESS IS ALREADY USED BY THE
CUSTOMER I/O DISKETTE (SEE STM 6126)

CONFIGURE CUSTOMER DISKETTE


THE CUSTOMER DISKETTE ADDRESS LABELS ARE INSTALLED ON THE TOP COVER OF THE 4331 (SEE ILLUSTRATION BELOW). LABELS ARE PROVIDED WITH THE 4331 SHIP GROUP. THESE ADDRESS LABELS SHOULD MATCH THE ADDRESS CONFIGURED WITH THIS SCREEN.

CONFIGURE PROCEDURE

1. DISPLAY THE 'DISKETTE DEVICE ADDRESS' SCREEN.
 - A. MOD SEL TO GET THE 'MODE SELECTION' SCREEN.
 - B. SELECT 'DISKETTE DEVICE ADDRESS.'
2. IF THE DISPLAYED ADDRESS IS CORRECT, ACCORDING TO THE 'SYSTEM CHART', GO TO STEP 4.
3. ENTER THE DESIRED ADDRESS AND HIT ENTER. WAIT FOR THE MESSAGE: 'UPDATE COMPLETE, PRESS IML.' *** DO NOT IML *** THIS IS A CUSTOMER MESSAGE. IML AFTER ALL CONFIGURE ACTIONS ARE COMPLETED.

THE NEW DISKETTE ADDRESS IS NOW DISPLAYED ON THE SCREEN.
4. ALT KEY AND MOD SELECT WILL RETURN YOU TO THE MAINTENANCE SELECTION SCREEN.

THE CUSTOMER DISKETTE CONFIGURATION IS COMPLETE



```

*DISKETTE DEVICE ADDRESS*
DEVICE ADDRESS RANGE: X'009' - X'01F'

DEVICE ADDRESS: 00A
                *      *

16MB VSE TIMER:OFF  DISK      DATA:      ADDR:
                TOD:SEC
0700

```

ERROR MESSAGES

- ```
'DUPLICATE DEVICE ADDRESS' --- YOU CANNOT ASSIGN AN ADDRESS ALREADY
 USED BY A NATIVE DISPLAY OR PRINTER
 (SEE STM 6124)

'INVALID DEVICE ADDRESS' --- ADDRESS IS OUTSIDE OF X'009' TO X'01F'
 RANGE, OR YOUR ENTRY IS ONLY ONE OR
 TWO DIGITS.
```



CONFIGURE FTA 1 OR 3 - (DISK)

DISK ADDRESSES ARE USUALLY CONFIGURED IN PAIRS. IN OTHER WORDS, ONLY ONE ENTRY IS NECESSARY TO INSTALL DEVICE ADDRESSES '210' AND '211.' HOWEVER, SOME DISKS CAN HAVE JUST ONE DEVICE. THE LAST DIGIT (1 OR 2) OF DISK ENTRIES, INDICATES 1 OR 2 ADDRESSES USED.

CONFIGURE PROCEDURE

1. DISPLAY THE FTA 1 OR 3 CONFIGURE SCREEN.

A. ALT KEY WITH MOD SEL TO GET MAINTENANCE SELECTION SCREEN.  
B. SELECT UTILITIES/REMOTE  
C. SELECT FTA CONFIGURATOR  
D. SELECT FTA1 OR FTA3
2. THE CHART ON THIS PAGE SHOWS A TYPICAL FTA 1 CONFIGURATION BLOCK.
3. THE 'SYSTEM CHART' (STM - 6019) DEFINES THE FTA ADDRESSES USED BY YOUR SYSTEM. FOR DISKS ON THE FTA, THE 3 DIGIT 'DEVICE' ADDRESS IS BROKEN DOWN IN THE FOLLOWING EXAMPLE FOR 3340 ADDRESS '210.'

2 = CHANNEL ADDRESS AS SHOWN AT THE TOP OF THE SCREEN.  
1 = CONTROL ADDRESS AS SHOWN AT THE LEFT OF THE SCREEN.  
0 = DEVICE ADDRESS AS SHOWN ABOVE THE ENTRY AREA OF THE SCREEN.

4. IF THE DISPLAYED INFORMATION MATCHES THE 'SYSTEM CHART', GO TO STEP 9.

5. TO CHANGE DISK ADDRESSES ON FTA

TO REMOVE ENTRIES:

FIND THE FIRST '33XX-XX' ENTRY IN EACH ROW THAT IS NOT USED BY YOUR SYSTEM. CHANGE THESE ENTRIES FROM '33XX-XX' TO 'R3XX-XX', TO ERASE THE REST OF THE STRING.

TO ADD ENTRIES:

CHANGE '.....' TO '33XX-X2' FOR EACH PAIR OF DEVICE ADDRESSES, OR '33XX-X1' FOR A SINGLE ADDRESS.

6. IF STRING SWITCH IS INSTALLED ON ANY CONTROL UNIT, CHANGE THE 'N' TO A 'Y' IN THE STRING SWITCH COLUMN.

7. HIT ENTER. THE SCREEN SHOULD NOW SHOW THE DEVICES FOR YOUR SYSTEM. IF AN ERROR MESSAGE IS DISPLAYED, CORRECT IT AND HIT ENTER AGAIN.

AN ERROR MESSAGE SUMMARY FOR FTA IS ON PAGE 6138.

8. YOU MUST NOW ANSWER A QUESTION. -- STORE Y/N --

IF THE SCREEN IS CORRECT, ENTER 'Y' AND WAIT FOR THE DATA TO BE WRITTEN ON THE DISKETTE. IF THE SCREEN IS NOT CORRECT, ENTER 'N', AND GO BACK TO STEP 1 D.

9. ALT KEY AND MODE SEL WILL RETURN YOU TO THE MAINTFNANCE SELECTION SCREEN.

THE FTA 1 (DISK) CONFIGURE ACTION IS COMPLETE

EXAMPLE OF A TYPICAL FTA 1 CONFIGURATION

| CONFIGURATION BLOCK FOR FTA1, CHANNEL ADDRESS 2                                                                                              |                     |                                   |         |         |         |
|----------------------------------------------------------------------------------------------------------------------------------------------|---------------------|-----------------------------------|---------|---------|---------|
| CONTROL ADDRESS                                                                                                                              | STRING SWITCH (Y/N) | DEVICE ADDRESS/TYPE WITHIN STRING |         |         |         |
|                                                                                                                                              |                     | 0                                 | 2       | 4       | 6       |
| 0                                                                                                                                            | .                   | .....                             | .....   | .....   | .....   |
| 1                                                                                                                                            | N                   | 3340-A2                           | 3340-B2 | 3340-B2 | 3340-B2 |
| 2                                                                                                                                            | .                   | .....                             | .....   | .....   | .....   |
| 3                                                                                                                                            | N                   | 3370-A1                           | 3370-B1 | 3370-B1 | 3370-B1 |
| 4                                                                                                                                            | N                   | 3310-A1                           | .....   | .....   | .....   |
| 5                                                                                                                                            | N                   | 3310-A2                           | 3310-B2 | .....   | .....   |
| 6                                                                                                                                            | .                   | .....                             | .....   | .....   | .....   |
| 7                                                                                                                                            | .                   | .....                             | .....   | .....   | .....   |
| VALID DEVICE NAMES ARE:<br>3310-A2 3310-B2 3340-A2 3340-B2 3344-B2 3370-A1 3370-B1<br>3310-A1 3310-B1 3340-B1<br>R .... ERASE REST OF STRING |                     |                                   |         |         |         |
|                                                                                                                                              |                     | 1MB VSE TIMER:OFF DISK            |         | DATA:   | ADDR:   |
|                                                                                                                                              |                     | TOD:SEC                           |         |         |         |
| 0700                                                                                                                                         |                     |                                   |         |         |         |

THIS EXAMPLE SHOWS:

3340'S USING ADDRESSES 210 THRU 217  
3370'S USING ADDRESSES 230 THRU 237  
3310 USING ADDRESS 240  
3310'S USING ADDRESSES 250 THRU 253

4 STRINGS ON THIS FTA, WHICH IS THE MAXIMUM ALLOWED.

© Copyright International Business Machines Corporation 1980, 1981

4331 - 2  
STM

|                        |                        |                         |                            |         |
|------------------------|------------------------|-------------------------|----------------------------|---------|
| EC 366458<br>03 Nov 80 | EC 366390<br>10 Apr 81 | EC 366492<br>15 July 81 | P/N 5683289<br>Page 1 of 8 | 6 130 F |
|------------------------|------------------------|-------------------------|----------------------------|---------|

CONFIGURE FTA 2 - (8809)

CAUTION: THE 8809 ADDRESSES DIFFER FROM ANY OTHER DEVICE. THE DEVICE AND CONTROLLER ADDRESSES ARE REVERSED.

EACH 8809 ON THE FTA HAS A SEPARATE CONTROL UNIT. AN 8809 IS ADDRESSED BY ADDRESSING THE CONTROL UNIT FOR THAT 8809.

CONFIGURE PROCEDURE

1. DISPLAY THE FTA 2 CONFIGURE SCREEN.
  - A. ALT KEY WITH MOD SEL TO GET THE MAINTENANCE SELECTION SCREEN.
  - B. SELECT UTILITIES/REMOTE.
  - C. SELECT FTA CONFIGURATOR.
  - D. SELECT FTA2.
2. THE CHART ON THIS PAGE SHOWS A TYPICAL FTA 2 CONFIGURE BLOCK.
3. THE 'SYSTEM CHART' (STM - 6019) DEFINES THE FTA 2 ADDRESSES USED BY YOUR SYSTEM. FOR 8809'S ON THE FTA, THE 3 DIGIT 'DEVICE' ADDRESS IS BROKEN DOWN IN THE FOLLOWING EXAMPLE FOR 8809 ADDRESS '301.'  
  
3 = CHANNEL ADDRESS AS SHOWN AT THE TOP OF THE SCREEN.  
0 = DEVICE ADDRESS AS SHOWN ABOVE THE ENTRY AREA OF THE SCREEN.  
1 = CONTROL ADDRESS AS SHOWN AT THE LEFT OF THE SCREEN.
4. IF THE DISPLAYED INFORMATION MATCHES THE 'SYSTEM CHART', GO TO STEP 9.
5. CHANGE ADDRESSES ON FTA 2. (8809)  
  
NOTE: 8809 ADDRESSES MUST START WITH 300 AND CONTINUE IN ORDER (THAT IS 300, 301, 302, etc.)  
  
ONLY THE 1ST COLUMN IS USED AND THE 1ST ENTRY MUST BE ON THE 1ST LINE.  
  
TO REMOVE ENTRIES:  
  
FIND THE '8809' ENTRIES NOT USED BY YOUR SYSTEM AND CHANGE THEM ALL FROM '8809' TO 'R809'  
  
TO ADD ENTRIES:  
  
ALTER '.....' ENTRIES TO '8809...'
6. STRING SWITCH IS NOT USED FOR 8809'S. ENTERING A 'Y' IN THE STRING SWITCH COLUMN WILL GIVE AN ERROR MSG.
7. HIT ENTER. THE SCREEN SHOULD NOW SHOW THE DEVICES FOR YOUR SYSTEM. IF AN ERROR MESSAGE IS DISPLAYED, CORRECT IT AND HIT ENTER AGAIN.  
  
ERROR MESSAGE SUMMARY FOR FTA IS ON PAGE 6138.

8. YOU MUST NOW ANSWER A QUESTION. -- STORE Y/N --  
IF THE SCREEN IS CORRECT, ENTER 'Y' AND WAIT FOR THE DATA TO BE WRITTEN ON THE DISKETTE. IF THE SCREEN IS NOT CORRECT, ENTER 'N', AND GO BACK TO STEP 1 D.
9. ALT KEY AND MOD SEL WILL RETURN YOU TO THE MAINTENANCE SELECTION SCREEN.

THE FTA 2 (8809) CONFIGURE ACTION IS COMPLETE

EXAMPLE OF A TYPICAL FTA 2 CONFIGURATION

| CONFIGURATION BLOCK FOR FTA2, CHANNEL ADDRESS 3 |                     |                                   |       |       |       |
|-------------------------------------------------|---------------------|-----------------------------------|-------|-------|-------|
| CONTROL ADDRESS                                 | STRING SWITCH (Y/N) | DEVICE ADDRESS/TYPE WITHIN STRING |       |       |       |
|                                                 |                     | 0                                 | 2     | 4     | 6     |
| 0                                               | N                   | 8809                              | ..... | ..... | ..... |
| 1                                               | N                   | 8809                              | ..... | ..... | ..... |
| 2                                               | .                   | .....                             | ..... | ..... | ..... |
| 3                                               | .                   | .....                             | ..... | ..... | ..... |
| 4                                               | .                   | .....                             | ..... | ..... | ..... |
| 5                                               | .                   | .....                             | ..... | ..... | ..... |
| 6                                               | .                   | .....                             | ..... | ..... | ..... |
| 7                                               | .                   | .....                             | ..... | ..... | ..... |
| VALID DEVICE NAMES ARE:                         |                     |                                   |       |       |       |
| 8809                                            |                     |                                   |       |       |       |
| R .... ERASE REST OF STRING                     |                     |                                   |       |       |       |
| 1MB VSE TIMER:OFF DISK DATA: ADDR:              |                     |                                   |       |       |       |
| TOD:SEC                                         |                     |                                   |       |       |       |
| 0700                                            |                     |                                   |       |       |       |

THIS EXAMPLE SHOWS:

8809'S USING ADDRESSES 300 AND 301.

8809 ADDRESSING MUST ALWAYS START WITH X00, AND CONTINUE IN SEQUENCE.



FTA CONFIGURE ERROR MESSAGES

'XXX' NOT INSTALLED ERRORS

'FTA1 NOT INSTALLED' -----

'FTA2 NOT INSTALLED' -----

'FTA3 NOT INSTALLED' -----

'DEVICE TYPE NOT INSTALLED' -----

'STRNG SW. FEATURE NOT INSTALLED' -----

}

MEANS THAT THE FEATURE  
B/M IS NOT INSTALLED ON  
THE DISKETTE.  
FOR FEATURE B/M NUMBERS  
SEE PAGE PA015 IN VOL.30.

INVALID ENTRIES OR DATA ERRORS

'COPY THE CONFIGURATOR' -----

'INVALID CHARACTER' -----

'INVALID ENTRY' -----

'NO VALID FTA SPECIFIED' -----

'CONTROL ADDRESS IS INVALID' -----

'INVALID DEVICE TYPE' -----

'DEVICE PATTERN INCORRECT' -----

'INVALID OR MISSING STORE COMMAND' -----

YOU MUST COPY CONFIGURE FROM A  
GOOD DISKETTE. THE CONFIGURATION  
DATA ON YOUR DISKETTE IS INVALID

CURSOR POINTS TO INCORRECT AREA

CURSOR POINTS TO INCORRECT AREA

CURSOR POINTS TO INCORRECT AREA

CURSOR POINTS TO INCORRECT AREA

CURSOR POINTS TO INCORRECT AREA

'Y' OR 'N' NOT ENTERED TO  
ANSWER 'STORE Y/N.'

FEATURE DEPENDANT ERRORS

'A-BOX MUST BE DEFINED' -----

'ONLY ONE A-BOX PER STRING' -----

'A1 BOX=NO B BOX. A2=ONLY 1 B BOX' -----

'STRING SWITCH NOT ALLOWED' -----

'3340 CONTROL ADDR MUST BE 0 OR 1' -----

'MAX 4 DISK STRINGS ALLOWED' -----

'8809 MUST BE EXCLUSIV ON FTA' -----

'8809: MAX. DEVICE NUMBER = 6' -----

'8809 STRING MUST BE CONTINUOUS' -----

'8809 STRING MUST START WITH ZERO' -----

XXXX-AX MUST BE DEFINED SOMEWHERE  
IN THE STRING.

FOR 3310 - NO B BOX ALLOWED IF A1  
BOX SPECIFIED. ONLY 1 B BOX ALLOWED  
IF A2 BOX SPECIFIED.

STRING SWITCH CANNOT BE USED WITH  
THIS DEVICE/CONTROLLER TYPE

ONLY 4 CONTROL ADDRESSES ALLOWED

NO DISK ALLOWED ON FTA WITH 8809

CONFIGURE HSC SUBCHANNELS

SUBCHANNELS ARE INSTALLED OR REMOVED IN GROUPS OF 8 ADDRESSES. THESE ADDRESS RANGES ARE SHOWN ON THE 'FROM' AND 'TO' LINES AT THE TOP SCREEN.

EACH SUBCHANNEL GROUP CAN BE SPECIFIED AS UNSHARED OR SHARED SUBCHANNEL ON THE HSC.

A SEPARATE SCREEN IS PROVIDED FOR SUBCHANNELS WITH ADDRESS 00 TO 7F AND 80 TO FF.

SHARED SUBCHANNELS CAN BE SELECTOR MODE OR NOT SELECTOR MODE (BLOCK MODE). THE LINE 'SELECTOR MODE' ALLOWS THE SETTING OF THIS OPTION.

CONFIGURE PROCEDURE

1. DISPLAY THE HSC CONFIGURE SCREEN
  - A. ALT KEY WITH MOD SEL TO GET THE MAINTENANCE SELECTION SCREEN
  - B. SELECT 'UTILITIES/REMOTE'
  - C. SELECT 'HSC CONFIGURATOR'
2. THE HSC CONFIGURATION BLOCK FOR SUBCHANNELS WITH ADDRESS 00 TO 7F SHOULD BE ON THE SCREEN.

SPECIFY THE FOLLOWING FOR EACH SUBCHANNEL:

3. \*\*\* INSTALLED \*\*\*

USING THE 'SYSTEM CHART' ON STM 6019 AS A GUIDE, PUT A 'Y' UNDER ANY ADDRESS RANGE THAT INCLUDES AN ADDRESS USED BY YOUR SYSTEM. A 'N' SHOULD BE ENTERED UNDER ALL OTHER ADDRESS RANGES.
4. \*\*\* UNSHARED \*\*\*

ENTER A 'Y' IN THIS LINE IF THIS ADDRESS GROUP SHOULD FUNCTION AS UNSHARED SUBCHANNEL. ENTER A 'N' IF IT SHOULD FUNCTION AS A SHARED SUBCHANNEL.
5. \*\*\* BEGIN/FOLLOW \*\*\*

ENTER A 'B' IF THE ADDRESS RANGE IS INSTALLED, AND THE CONTROLLER FOR THAT RANGE WILL USE ONLY ADDRESSES WITHIN THAT RANGE OF 8 ADDRESSES.

A CONTROLLER SUCH AS A 3803 CAN USE 32 ADDRESSES (4 RANGES OF 8). IN THIS CASE, A 'B' IS ENTERED UNDER THE FIRST RANGE OF 8 ADDRESSES IN THE GROUP OF 32 ADDRESSES. AN 'F' IS ENTERED UNDER THE 2ND, 3RD AND 4TH ADDRESS RANGES IN THE 32 ADDRESS GROUP. THIS WILL 'CONNECT' THE FOUR RANGES OF 8 ADDRESSES INTO A RANGE OR GROUP OF 32 ADDRESSES TO BE USED BY THE 3803.

6. \*\*\* SELECTOR MODE \*\*\*

THIS BIT IS NORMALLY ON. IT IS SOMETIMES TURNED OFF TO OPTIMIZE SYSTEM OPERATION. YOU SHOULD CONSULT SUPPORT FACILITIES FOR THESE CONDITIONS.
7. \*\*\* DATA STREAMING MODE \*\*\*

FOR CONTROL UNITS SUCH AS THE 3880 THAT ARE CAPABLE OF DATA STREAMING MODE IT IS ESSENTIAL TO:

  1. MAKE SURE THE CONTROL UNIT IS INTERNALLY SWITCHED TO DATA STREAMING MODE
  2. SET THIS BIT TO 'Y' FOR THE SUBCHANNELS CONCERNED. NEVER SET 'Y' FOR CONTROL UNITS NOT CAPABLE OF DATA STREAMING MODE.
8. HIT ENTER. IF THERE ARE NO ERRORS THE SCREEN FOR THE SUBCHANNELS 80 TO FF IS DISPLAYED. ERROR MESSAGES ARE SHOWN BELOW THE SCREEN PICTURE. CORRECT THE ERRORS THEN CONTINUE TO CONFIGURE ADDRESSES 80 TO FF.
9. HIT ENTER. IF THERE ARE NO ERRORS A THIRD PICTURE IS DISPLAYED. ANSWER THE TWO QUESTIONS WITH Y OR N.

'SET 4 MICROSECS SELECT-OUT DOWN'

NORMALLY ANSWERED WITH 'N', ANSWER WITH 'Y' IF TIMING PROBLEMS ARE ENCOUNTERED WITH LOW SPEED CONTROL UNITS, FOR EXAMPLE : 2821.

'START OUTBOUND WITH FULL BUFFER ONLY'

MUST BE ANSWERED WITH 'N'. ANSWER 'Y' IS USED FOR FACTORY TEST CASES ONLY.
10. HIT ENTER. YOU MUST NOW ANSWER THE QUESTION --STORE Y/N--. IF A 'Y' IS ENTERED, WAIT FOR THE DISKETTE TO BE WRITTEN AND GO TO STEP 10. IF AN 'N' IS ENTERED, GO BACK TO STEP 2 TO MAKE ANY NECESSARY CORRECTIONS.
11. ALT KEY AND MODE SEL WILL RETURN YOU TO THE MAINTENANCE SELECTION SCREEN.

THE HSC CONFIGURE ACTION IS COMPLETE.

jm

CONFIGURE HSC SUBCHANNEL

HSC CONFIGURATION BLOCK, CHANNEL ADDRESS 6

| ADDRESS RANGE                           | FROM: 00 TO: 07 | 08 0F | 10 17 | 18 1F | 20 27 | 28 2F | 30 37 | 38 3F | 40 47 | 48 4F | 50 57 | 58 5F | 60 67 | 68 6F | 70 77 | 78 7F |
|-----------------------------------------|-----------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| INSTALLED                               | Y               | N     | N     | N     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | N     | N     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| UNSHARED                                | Y               | .     | .     | .     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | Y     | .     | .     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| BEGIN/FOLLOW                            | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| ENTER: B/F                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| SELECTOR MODE                           | N               | .     | .     | .     | N     | N     | N     | N     | N     | N     | N     | N     | N     | N     | .     | .     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| DATA-STREAMNG MD                        | N               | .     | .     | .     | N     | N     | N     | N     | N     | N     | Y     | Y     | N     | N     | .     | .     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| 370 TIMER: ON    DISK    DATA:    ADDR: |                 |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
| TOD: SEC                                |                 |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |

0700

HSC CONFIGURATION BLOCK, CHANNEL ADDRESS 6

| ADDRESS RANGE                           | FROM: 80 TO: 87 | 88 8F | 90 97 | 98 9F | A0 A7 | A8 AF | B0 B7 | B8 BF | C0 C7 | C8 CF | D0 D7 | D8 DF | E0 E7 | E8 EF | F0 F7 | F8 FF |
|-----------------------------------------|-----------------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|-------|
| INSTALLED                               | N               | N     | Y     | Y     | Y     | Y     | N     | N     | N     | N     | N     | N     | N     | N     | N     | N     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| UNSHARED                                | .               | .     | N     | N     | N     | N     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| BEGIN/FOLLOW                            | .               | .     | B     | F     | B     | F     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| ENTER: B/F                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| SELECTOR MODE                           | .               | .     | Y     | Y     | Y     | Y     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| DATA-STREAMNG MD                        | .               | .     | N     | N     | N     | N     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| ENTER: Y/N                              | .               | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     | .     |
| 370 TIMER: ON    DISK    DATA:    ADDR: |                 |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |
| TOD: SEC                                |                 |       |       |       |       |       |       |       |       |       |       |       |       |       |       |       |

0700

HSC CONFIGURATION BLOCK, CHANNEL ADDRESS 6

SET "4 MICROSEC'S SELECT-OUT DOWN"    N  
ENTER: Y/N  
START OUTBOUND WITH FULL BUFFER ONLY    N  
ENTER: Y/N

370 TIMER: ON    DISK    DATA:    ADDR:

TOD: SEC

0700

DEVICES FOR SHARED/UNSHARED SUBCHANNELS

FOR INFORMATION ON WHICH I/O DEVICES REQUIRE A SHARED/UNSHARED SUBCHANNEL REFER TO THE COMPONENT DESCRIPTION OF THE I/O DEVICE.

HSC CONFIGURATION BLOCK ERRORS

- 'INVALID OR MISSING STORE COMMAND' ----- 'Y' OR 'N' NOT ENTERED TO ANSWER 'STORE Y/N.'
- 'NO VALID HSC SPECIFIED' -----
- 'HSC NOT INSTALLED' ----- MEANS THAT THE FEATURE B/M IS NOT INSTALLED ON THE DISKETTE. FOR FEATURE B/M NUMBERS SEE PAGE PA015 IN VOL. 30.
- 'SPECIFY BEGIN' ----- NO 'B' SPECIFIED FOR 1ST ADDRESS RANGE.

CONFIGURE BMPX SUBCHANNELS

SUBCHANNELS ARE INSTALLED OR REMOVED IN GROUPS OF 8 ADDRESSES. THESE ADDRESS RANGES ARE SHOWN ON THE 'FROM' AND 'TO' LINES AT THE TOP SCREEN.

EACH SUCHANNEL GROUP CAN BE SPECIFIED AS SHARED OR UNSHARED SUBCHANNEL. A SEPARATE SCREEN IS PROVIDED FOR ADDRESS RANGES 00 TO 7F and 80 TO FF.

SHARED SUBCHANNELS CAN BE SELECTOR MODE OR NOT SELECTOR MODE (BLOCK MODE). THE BMPX CONFIGURE SCREEN ALLOWS THE SETTING OF THIS OPTION.

CONFIGURE PROCEDURE

- 1. DISPLAY THE BMPX CONFIGURE SCREEN
  - A. ALT KEY WITH MOD SEL TO GET THE MAINTENANCE SELECTION SCREEN
  - B. SELECT 'UTILITIES/REMOTE'
  - C. SELECT 'BMPX CONFIGURATOR'
  - D. SELECT APPROPRIATE BMPX (1 OR 2)

- 2. THE BMPX CONFIGURATION BLOCK FOR ADDRESS RANGE 00 TO 7F SHOULD BE ON THE SCREEN.

- 3. \*\*\* INSTALLED \*\*\*  
  
USING THE 'SYSTEM CHART' ON STM 6019 AS A GUIDE, PUT A 'Y' UNDER ANY ADDRESS RANGE THAT INCLUDES AN ADDRESS USED BY YOUR SYSTEM. A 'N' SHOULD BE ENTERED UNDER ALL OTHER ADDRESS RANGES.

- 4. \*\*\* UNSHARED \*\*\*  
  
ENTER A 'Y' IN THIS LINE IF THIS ADDRESS GROUP SHOULD FUNCTION AS UNSHARED SUBCHANNEL. ENTER A 'N' IF IT SHOULD FUNCTION AS A SHARED SUBCHANNEL.  
IF A SHARED SUBCHANNEL IS SPECIFIED THREE ADDITIONAL LINES OF CONFIGURE INFORMATION ARE AVAILABLE.  
EACH OF THE 3 LINES IS MENTIONED SEPARATELY.

- 5. \*\*\* BEGIN/FOLLOW \*\*\*  
  
ENTER A 'B' IF THE ADDRESS RANGE IS INSTALLED, AND THE CONTROLLER FOR THAT RANGE WILL USE ONLY ADDRESSES WITHIN THAT RANGE OF 8 ADDRESSES.  
A CONTROLLER SUCH AS A 3272 CAN USE 32 ADDRESSES (4 RANGES OF 8). IN THIS CASE, A 'B' IS ENTERED UNDER THE FIRST RANGE OF 8 ADDRESSES IN THE GROUP OF 32 ADDRESSES. AN 'F' IS ENTERED UNDER THE 2ND, 3RD AND 4TH ADDRESS RANGES IN THE 32 ADDRESS GROUP. THIS WILL 'CONNECT' THE FOUR RANGES OF 8 ADDRESSES INTO A RANGE OR GROUP OF 32 ADDRESSES TO BE USED BY THE 3272.

- 6. \*\*\* SELECTOR MODE \*\*\*  
  
THIS BIT IS NORMALLY ON. IT IS SOMETIMES TURNED OFF TO OPTIMIZE SYSTEM OPERATION. YOU SHOULD CONSULT SUPPORT FACILITIES FOR THESE CONDITIONS.
- 7. \*\*\* 231X ATTACHED \*\*\*  
  
'ATTACHED' MEANS THAT A 2311 OR 2314 DEVICE IS ATTACHED TO THE BMPX. IT DOES NOT MEAN 231X EMULATOR. THE 231X EMULATOR IS ON THE FTA.  
IF THERE IS A 'Y' ON THIS LINE, THE 'SELECTOR MODE' LINE WILL AUTOMATICALLY BE SET TO A 'Y' FOR THAT ADDRESS RANGE.
- 8. HIT ENTER. IF THERE ARE NO ERRORS THE SECOND CONFIGURE SCREEN FOR THE ADDRESSES 80 TO FF IS DISPLAYED. ERROR MESSAGES ARE SHOWN BELOW THE SCREEN PICTURES. CORRECT THE ERRORS TO CONTINUE TO CONFIGURE THE SUBCHANNELS 80 TO FF IN THE SAME WAY.
- 9. HIT ENTER. YOU MUST NOW ANSWER THE QUESTION --STORE Y/N--.  
IF A 'Y' IS ENTERED, WAIT FOR THE DISKETTE TO BE WRITTEN AND GO TO STEP 10. IF AN 'N' IS ENTERED, GO BACK TO STEP 2 TO MAKE ANY NECESSARY CORRECTIONS.
- 10. ALT KEY AND MODE SEL WILL RETURN YOU TO THE MAINTENANCE SELECTION SCREEN.

THE BMPX CONFIGURE ACTION IS COMPLETE.

## CONFIGURE BMPX SUBCHANNELS

| BMPX1 CONFIGURATION BLOCK, CHANNEL ADDRESS 1                                                        |                    |          |          |          |          |          |          |          |          |          |          |          |          |          |          |          |
|-----------------------------------------------------------------------------------------------------|--------------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| ADDRESS RANGE                                                                                       | FROM: 00<br>TO: 07 | 08<br>0F | 10<br>17 | 18<br>1F | 20<br>27 | 28<br>2F | 30<br>37 | 38<br>3F | 40<br>47 | 48<br>4F | 50<br>57 | 58<br>5F | 60<br>67 | 68<br>6F | 70<br>77 | 78<br>7F |
| INSTALLED                                                                                           | Y                  | Y        | N        | N        | Y        | Y        | Y        | Y        | N        | N        | N        | N        | N        | N        | N        | N        |
| ENTER: Y/N                                                                                          | .                  | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| UNSHARED                                                                                            | N                  | N        | .        | .        | Y        | Y        | Y        | Y        | .        | .        | .        | .        | .        | .        | .        | .        |
| ENTER: Y/N                                                                                          | .                  | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| BEGIN/FOLLOW                                                                                        | B                  | F        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| ENTER: B/F                                                                                          | .                  | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| SELECTOR MODE                                                                                       | Y                  | Y        | .        | .        | N        | N        | N        | N        | .        | .        | .        | .        | .        | .        | .        | .        |
| ENTER: Y/N                                                                                          | .                  | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| 231X ATTACHED                                                                                       | N                  | N        | .        | .        | N        | N        | N        | N        | .        | .        | .        | .        | .        | .        | .        | .        |
| ENTER: Y/N                                                                                          | .                  | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| <div> <div>370 TIMER:ON<br/>TOD: SEC</div> <div>DISK</div> <div>DATA:</div> <div>ADDR:</div> </div> |                    |          |          |          |          |          |          |          |          |          |          |          |          |          |          |          |

| BMPX1 CONFIGURATION BLOCK, CHANNEL ADDRESS 1            |                    |          |          |          |          |          |          |          |          |          |          |          |          |          |          |          |
|---------------------------------------------------------|--------------------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|----------|
| ADDRESS RANGE                                           | FROM: 80<br>TO: 87 | 88<br>8F | 90<br>97 | 98<br>9F | A0<br>A7 | A8<br>AF | B0<br>B7 | B8<br>BF | C0<br>C7 | C8<br>CF | D0<br>D7 | D8<br>DF | E0<br>E7 | F8<br>EF | F0<br>F7 | F8<br>FF |
| INSTALLED<br>ENTER: Y/N                                 | Y                  | Y        | N        | N        | Y        | N        | N        | N        | N        | N        | N        | Y        | N        | N        | N        | N        |
| UNSHARED<br>ENTER: Y/N                                  | N                  | N        | .        | .        | N        | .        | .        | .        | .        | .        | .        | Y        | .        | .        | .        | .        |
| BEGIN/FOLLOW<br>ENTER: B/F                              | B                  | F        | .        | .        | B        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        | .        |
| SELECTOR MODE<br>ENTER: Y/N                             | Y                  | Y        | .        | .        | Y        | .        | .        | .        | .        | .        | .        | N        | .        | .        | .        | .        |
| 231X ATTACHED<br>ENTER: Y/N                             | N                  | N        | .        | .        | N        | .        | .        | .        | .        | .        | .        | N        | .        | .        | .        | .        |
| 370 TIMER:ON      DISK      DATA:      ADDR:<br>TOD:SEC |                    |          |          |          |          |          |          |          |          |          |          |          |          |          |          |          |
| 0700                                                    |                    |          |          |          |          |          |          |          |          |          |          |          |          |          |          |          |

### DEVICE TABLE FOR UNSHARED SUBCHANNELS (TYPICAL)

|                                                |                            |
|------------------------------------------------|----------------------------|
|                                                | DEVICE<br>TYPE             |
| 2821-2540, -1403<br>2501, 2520<br>3211, 3203-5 | READERS<br>AND<br>PRINTERS |
| 3274-1A CONTROL UNIT                           | DISPLAYS                   |

## BMPX CONFIGURATION BLOCK ERRORS

```
'INVALID OR MISSING STORE COMMAND' ----- 'Y' OR 'N' NOT ENTERED TO ANSWER
 'STORE Y/N.'
'NO VALID BMPX SPECIFIED' -----
'BMPX NOT INSTALLED' ----- CHECK IF BMPX IS CONFIGURED,
 SEE MES UPDATE, PAGE 6190.
'SPECIFY BEGIN' ----- NO 'B' SPECIFIED FOR 1ST
 ADDRESS RANGE.
'231X NOT ALLOWED' ----- 231x NOT ALLOWED IF HSC
 INSTALLED, OR IF BMPX2
 REFER TO 'DEVICE RESTRICTIONS'
 ON PAGE 6200.
```

### DEVICE TABLE FOR SHARED SUBCHANNELS (TYPICAL)

|                                                                               | DEVICE<br>TYPE | SELECTOR<br>MODE                | 231X                  |
|-------------------------------------------------------------------------------|----------------|---------------------------------|-----------------------|
| 2841-2311<br>2314, 2319, 2312, 2313                                           | DISKS          | Y<br>Y                          | *Y<br>*Y              |
| 2415<br>2803-2401, 2402<br>3803-3420<br>3410, 3411                            | TAPES          | Y<br>Y<br>Y<br>Y                | N<br>N<br>N<br>N      |
| 2250-1<br>2840-2250-11<br>2848-2260<br>3272 CONTROL UNIT<br>3274 CONTROL UNIT | DISPLAYS       | Y<br>Y<br>Y<br>EITHER<br>EITHER | N<br>N<br>N<br>N<br>N |

\* BMPX 1 ONLY  
AND NO HSC  
INSTALLED.

REFER TO DEVICE RESTRICTIONS (STM 6200).

CONFIGURATION OF CA

CA ADDRESSES ARE ASSIGNED BY HARDWARE LOCATION. CONFIGURE FOR THE CA MEANS SETTING CERTAIN LINE OPTIONS DISPLAYED ON THE SCREEN.

THE DETAILED LINE DESCRIPTIONS SHOULD BE FILLED OUT IN THE CTM FEATURES CA SECTION, AND ON THE SYSTEM CHART ON STM 6018.

AN EXAMPLE OF THE CA CONFIGURE SCREEN IS SHOWN HERE FOR REFERENCE.

CONFIGURE PROCEDURE

1. DISPLAY THE CA CONFIGURATOR

A. ALT KEY AND MOD SEL WILL GET THE MAINTENANCE SELECTION SCREEN.

B. SELECT THE 'COMMUNICATION ADAPTER'

C. SELECT THE 'UPDATE CONFIGURATION TABLE'
2. PF1 AND PF2 CONTROL POINTERS ON THE SCREEN.

PF1 CONTROLS ==> AND MOVES IT FROM TOP TO BOTTOM OF THE SCREEN.

PF2 CONTROLS => TO THE RIGHT OF THE PF1 POINTER, MOVING IT TO THE OTHER COLUMN EACH TIME PF2 IS DEPRESSED. THE POSITION OF THE => INDICATES THE PRESENT SETTING OF EACH OPTION THAT APPLIES TO THE LINE CURRENTLY DISPLAYED.
3. DETAILED INFORMATION ABOUT THE CA IS CONTAINED IN THE STM FEATURES, CA SECTION AND IN MAP 88FF.

GO TO MAP 88FF TO COMPLETE THE CA CONFIGURATION

\*\*\* CA CONFIGURATION DATA \*\*\*

PF1 - SELECT NEXT OPTION (==>)

PF2 - OPTION SWITCH (=>)

PF3 - EXIT WITHOUT UPDATE

PF4 - SELECT NEXT CA LINE ADDRESS

ENTER - UPDATE AND EXIT

LINE ADDRESS 32

BSC

BM CLOCK

EIA I/F

1820

==> SWITCHED NETWORK

YES => NO

PERM REQUEST TO SEND

YES => NO

WRAP TEST SELECTION

MODEM => CA I/F

SELECT STANDBY

YES => NO

MODEM ANSWER TONE(HZ)

2025 2100

NEW SYNC

YES => NO

E1B MODE

YES => NO

DATA SIGNAL RATE SEL

LOW => HIGH

HIGH SPEED OPERATION

YES NO

MODEM PROCEDURE

COSTL => DTR

DATA CODE

ASCII => EBCDIC

2MB VSE TIMER:OFF

DATA:

ADDR:

TOD:SEC

0700



Configuration of the Loop

The loop configuration falls into two parts, the loop and the terminal configuration. The loop part is already pre-configured. The terminal part is to be configured by the customer. However, the CE should also be familiar with the configure procedure to be able to give assistance to the customer if requested.

The figure on this page shows how to select the TERMINAL DISPLAY AND UPDATE and the LOOP DISPLAY AND UPDATE screen display. For details how to configure these screens or to change the configuration refer to Section 6 of STM Features, Volume 15. Further information can be found in the following manuals:

- IBM 4331 Multiuse Communication Loop Operating Procedures, No. GA33-1538
- IBM 4331 Multiuse Communication Loop Functional Characteristics No. GA33-1534

The loop is configured by default with the values shown. The screen display in the figure shows the maximum configuration. The actual display shows only the loop(s) that are attached.

\*MODE SELECTION\*

P PROGRAM RESET

C CLEAR RESET

S STORE STATUS

R RESTART

I INSTR STEP

N RESET 1-STEP

Y TOD ENABLE

F LOOP ADAPTER

D DISPLAY/ALTER

L PROGRAM LOAD

A ADDRESS COMPARE

K CHECK CONTROL

J INTERNAL TIMER

M NATIVE DISPLAYS AND PRINTERS

G USER DISKETTE CONTROL

H DISKETTE DEVICE ADDRESS

E COMMUNICATION LINES

MAN

SELECTION:

370 TIMER:ON

TOD:SEC

LOOP MSG

DATA: 0000

ADDR: 000000

LOOP ADAPTER CONFIGURATOR

SELECTION MENU

A TERMINAL PARAMETERS DISPLAY AND UPDATE

B LOOP PARAMETERS DISPLAY AND UPDATE

C INLINE TESTS

MAN

SELECTION:

370 TIMER:ON

TOD:SEC

LOOP MSG

DATA: 0000

ADDR: 000000

LOOP ADAPTER CONFIGURATION

TERMINAL DISPLAY AND UPDATE

PAGE XXXX

DATA LINK 1

PORT ADDR: 0A

| STAT ADDR                            | TERMINAL | SUB-CHNL | LU ADDR | TERM PARA | STAT ADDR                                     | TERMINAL | SUB-CHNL | LU ADDR | TERM PARA |
|--------------------------------------|----------|----------|---------|-----------|-----------------------------------------------|----------|----------|---------|-----------|
| XX                                   | XXXXXXXX | XX       | XX      | XX        | XX                                            | XXXXXXXX | XX       | X       | XX X XX   |
| ..                                   | .....    | ..       | ..      | ..        | ..                                            | .....    | ..       | ..      | ..        |
| XX                                   | XXXXXXXX | XX       | XX      | XX        | XX                                            | XXXXXXXX | XX       | X       | XX X XX   |
| ..                                   | .....    | ..       | ..      | ..        | ..                                            | .....    | ..       | ..      | ..        |
| XX                                   | XXXXXXXX | XX       | XX      | XX        | XX                                            | XXXXXXXX | XX       | X       | XX X XX   |
| ..                                   | .....    | ..       | ..      | ..        | ..                                            | .....    | ..       | ..      | ..        |
| XX                                   | XXXXXXXX | XX       | XX      | XX        | XX                                            | XXXXXXXX | XX       | X       | XX X XX   |
| ..                                   | .....    | ..       | ..      | ..        | ..                                            | .....    | ..       | ..      | ..        |
| XX                                   | XXXXXXXX | XX       | XX      | XX        | XX                                            | XXXXXXXX | XX       | X       | XX X XX   |
| ..                                   | .....    | ..       | ..      | ..        | ..                                            | .....    | ..       | ..      | ..        |
| PRESS PF 1 KEY FOR BUFFER STATISTICS |          |          |         |           | DEC XXX DATA BUFFERS AVAILABLE<br>*) See Note |          |          |         |           |

S

Y

S

T

E

M

A

R

E

A

A  
B

LOOP ADAPTER CONFIGURATOR

LOOP DISPLAY AND UPDATE

PASSWORD: \_\_\_\_\_

NUMBER LOOP MESSAGES: 0050

|        | LOBE 1 ACTIVE | LOBE 2 ACTIVE | PACING T/O | NRZI | HALF SPEED | MODEM WRAP | PERM REQ TO SEND | POLL T/O MASK |
|--------|---------------|---------------|------------|------|------------|------------|------------------|---------------|
| LOOP 1 | Y             | N             | X 10       |      |            |            |                  |               |
|        | -             | -             | X --       |      |            |            |                  |               |
| LOOP 2 | Y             | N             | X 10       |      |            |            |                  |               |
|        | -             | -             | X --       |      |            |            |                  |               |
| LINK 1 |               |               | X 10       | Y    | N          | Y          | Y                | X 0A          |
|        |               |               | X --       | -    | -          | -          | -                | X --          |
| LINK 2 |               |               | X 10       | Y    | N          | Y          | Y                | X 0A          |
|        |               |               | X --       | -    | -          | -          | -                | X --          |

S

Y

S

T

E

M

A

R

E

A

\*) Note: The value is configuration dependent and shows how many data buffers are left.

This page has been  
intentionally left blank



COPY CONFIGURE

COPY CONFIG PROCEDURES ARE PROVIDED SO THAT MANUAL CHANGES ARE MADE ON ONLY ONE DISKETTE. THE UNCHANGED AND NEW DATA CAN THEN BE COPIED TO ALL OTHER DISKETTES, ELIMINATING THE POSSIBILITY OF MANUAL DIFFERENCES BETWEEN DISKETTES.

THIS PROCEDURE IS CONTROLLED BY MAP FE90, AND THE 'COPY CONFIGURATOR' SELECTION FROM THE MAINTENANCE SELECTION SCREEN. THE MAP INTERPRETS THE STEPS DISPLAYED ON THE SCREEN, AND TELLS YOU WHICH DISKETTE TO INSERT FOR EACH STEP. IT ALSO DIRECTS THE TESTING OF THE DISKETTES AFTER THE DISKETTES HAVE BEEN WRITTEN.

COPY CONFIGURATION IS NECESSARY IN THE FOLLOWING CASES:

- 1. INSTALLATION OF A NEW SYSTEM
- 2. CHANGE CONFIG DATA ON ONE DISKETTE
- 3. NEW DIAGNOSTIC DISKETTE
- 4. EC INSTALLATION
- 5. EMERGENCY DISKETTES
- 6. MES WITH CONFIGURE CHANGE

CHARTS ON THE FOLLOWING PAGES DESCRIBE EACH OF THE POSSIBLE COPY CONFIGURATION PROCEDURES. THEY ARE FOR REFERENCE AND ARE NOT NEEDED TO DO THE COPY CONFIGURE.

COPY CONFIGURE PROCEDURE

- 1. DISPLAY THE COPY CONFIGURE SCREEN
  - A. ALT KEY AND MOD SELECT TO GET THE MAINTENANCE SELECTION SCREEN.
  - B. SELECT UTILITIES/REMOTE
  - C. SELECT 'COPY CONFIGURATOR'
- 2. GO TO MAP FE90 AS INSTRUCTED BY THE SCREEN MESSAGE.

THE CONFIGURE PROCESS WILL BE COMPLETED BY FOLLOWING THE FE90 MAP.

LV: 79269212

COPY SYSTEM CONFIGURATOR

NEW CONTROL, OR ALL NEW.....: A

OC->C1->C2->D

NEW DIAGNOSTIC.....: B

C-->D

CHANGE ON CTL, OR INSTALLATION, OR MES-END.: D

C1->C2->D

MES-START.....: G

OC->C1

OPERATE AS INSTRUCTED BY MAP FE90

SELECTION:

370 TIMER:OFF DISK

DATA:

STEP: 00

TOD:SEC

ADDR:

ANSWER

2051

COPY CONFIGURE CHARTS

AT INSTALLATION, THE FIRST CONTROL DISKETTE IS CONFIGURED MANUALLY. THE NEW CONFIGURE INFORMATION IS COPIED TO THE OTHER DISKETTES WITH COPY CONFIGURE OPTION D.

AFTER INSTALLATION, THE 5 COPY CONFIGURE OPTIONS AND/OR MANUAL CONFIGURATION IS USED TO UPDATE THE SYSTEM CONFIGURE RECORD.

THERE ARE 14 VALID COMBINATIONS OF COPY OPTIONS, OLD AND NEW DISKETTES, AND MANUAL CONFIGURING THAT CAN BE USED TO UPDATE THE CONFIGURE DATA.

CHART 1 DESCRIBES ALL OF THE POSSIBLE REASONS FOR USING THE COPY CONFIGURE PROGRAM.

CHART 2 DESCRIBES THE 14 VALID COMBINATIONS OF COPY OPTIONS, OLD AND NEW DISKETTES, AND MANUAL CONFIGURING USED TO UPDATE THE CONFIGURE DATA.

HOW TO USE THE CONFIGURE CHARTS.

TO USE CHART 1, PICK A CONFIGURE ACTION THAT MATCHES WHAT YOU INTEND TO DO. FOR EXAMPLE:

ALL OF YOUR DISKETTES WERE DESTROYED, AND YOUR EMERGENCY ORDER GETS YOU A NEW DISKETTE SET, I. E. A NEW CONTROL (NC), A NEW BACK-UP (NB), AND A NEW DIAGNOSTIC (ND) DISKETTE.

THIS IS OBVIOUSLY AN EMERGENCY, SO LOOK IN THE EMERGENCY SECTION OF CHART 1 AND FIND THE LINE THAT SAYS:

- 1. NO OLD CONTROL AVAILABLE. (YOUR OLD ONES WERE DESTROYED)
- 2. NEW DISKETTES = NC NB ND

THE LAST COLUMN IN CHART 1 GIVES YOU THE ENTRY INTO CHART 2. CHART 2 INFORMATION WILL GUIDE YOU THROUGH THE COPY CONFIGURE ACTION BY TELLING YOU WHICH DISKETTE TO INSERT AT EACH STEP DURING THE COPY CONFIGURE.

THE EXAMPLE IS THE SAME ACTION THAT WOULD BE NECESSARY ON AN INSTALLATION, SINCE NO NEW DISKETTES ARE AVAILABLE AT INSTALLATION TIME. A LOOK AT THE INSTALL LINE ON CHART 1, SHOWS THAT PATH 6 IS ALSO USED FOR INSTALLATION.

CONFIGURE ACTION - CHART 1

| CONFIGURATION ACTION                                   | NEW DISKETTES | DISKETTES NEEDED FOR COPY ACTION | CHART 2 ENTRY |
|--------------------------------------------------------|---------------|----------------------------------|---------------|
| INSTALLATION OF NEW SYSTEM                             | NC NB ND      | NC NB ND                         | 6             |
| CHANGE CONFIG DATA<br>- CONFIG ON OLD DISK SET         | NONE          | OC OB OD                         | 10            |
| NEW DIAGNOSTIC DISKETTE                                | ND            | OC ND                            | 5             |
| EC INSTALL - NOTE 1<br>- COPY WITHOUT MANUAL UPDATE    | NC NB ND      | OC NC NB ND                      | 1             |
| - COPY WITHOUT MANUAL UPDATE                           | NC NB         | OC NC NB OD                      | 2             |
| - COPY WITH MANUAL UPDATE                              | NC NB ND      | OC NC NB ND                      | 11            |
| - COPY WITH MANUAL UPDATE                              | NC NB         | OC NC NB OD                      | 12            |
| EMERGENCY DISKETTES<br>- OLD CTRL AVAILABLE            | NC NB ND      | OC NC NB ND                      | 1             |
| - OLD CTRL AVAILABLE                                   | NC NB         | OC NC NB OD                      | 2             |
| - OLD CTRL AVAILABLE                                   | NC ND         | OC NC ND                         | 3             |
| - OLD CTRL AVAILABLE                                   | NC            | OC NC OD                         | 4             |
| - NO OLD CTRL DISK                                     | NC NB ND      | NC NB ND                         | 6             |
| - NO OLD CTRL DISK                                     | NC NB         | NC NB OD                         | 7             |
| - NO OLD CTRL DISK                                     | NC ND         | NC ND                            | 8             |
| - NO OLD CTRL DISK                                     | NC            | NC OD                            | 9             |
| MES WITH CONFIGURE CHANGE<br>- WITH SOME NEW DISKETTES | NC NB ND      | OC NC NB ND                      | 11            |
| - WITH SOME NEW DISKETTES                              | NC NB         | OC NC NB OD                      | 12            |
| - WITH SOME NEW DISKETTES                              | NC ND         | OC NC ND                         | 13            |
| - WITH A NEW DISKETTE                                  | NC            | OC NC OD                         | 14            |
| - WITH NO NEW DISKETTES                                | NO DISKS      | OC OC OD                         | 10            |

NOTE 1:  
EC INSTRUCTIONS WILL INDICATE IF MANUAL UPDATE IS NEEDED.

| KEY TO DISKETTE TYPE |      |    |      |
|----------------------|------|----|------|
| BACK                 | CTRL | UP | DIAG |
| OLD                  | OC   | OB | OD   |
| NEW                  | NC   | NB | ND   |

COPY CONFIGURE CHARTS (CONTINUED)

COPY CONFIGURE STEPS - CHART 2

| CHART | COPY STEP/DISK |       | MANUAL/<br>DISK<br>NOTE 2 | COPY CONFIGURATION STEP<br>AND CORRECT DISKETTE<br>STEP/DISK |       |       |          |
|-------|----------------|-------|---------------------------|--------------------------------------------------------------|-------|-------|----------|
| 1     |                |       |                           | A1/OC                                                        | A2/NC | A3/NB | A4/ND    |
| 2     |                |       |                           | A1/OC                                                        | A2/NC | A3/NB | A4/OD    |
| 3     |                |       |                           | A1/OC                                                        | A2/NC | A3/NC | A4/ND    |
| 4     |                |       |                           | A1/OC                                                        | A2/NC | A3/NC | A4/OD    |
| 5     |                |       |                           | B1/OC                                                        | B2/ND |       |          |
| 6     |                |       | M /NC                     | D1/NC                                                        | D2/NB | D3/ND |          |
| 7     |                |       | M /NC                     | D1/NC                                                        | D2/NB | D3/OD |          |
| 8     |                |       | M /NC                     | D1/NC                                                        | D2/NC | D3/ND | (NOTE 1) |
| 9     |                |       | M /NC                     | D1/NC                                                        | D2/NC | D3/OD | (NOTE 1) |
| 10    |                |       | M /OC                     | D1/OC                                                        | D2/OB | D3/OD |          |
| 11    | G1/OC          | G2/NC | M /NC                     | D1/NC                                                        | D2/NB | D3/ND |          |
| 12    | G1/OC          | G2/NC | M /NC                     | D1/NC                                                        | D2/NB | D3/OD |          |
| 13    | G1/OC          | G2/NC | M /NC                     | D1/NC                                                        | D2/NC | D3/ND | (NOTE 1) |
| 14    | G1/OC          | G2/NC | M /NC                     | D1/NC                                                        | D2/NC | D3/OD | (NOTE 1) |

| KEY TO DISKETTE TYPE |      |      |    |
|----------------------|------|------|----|
|                      | BACK |      |    |
| CTRL                 | UP   | DIAG |    |
| OLD                  | OC   | OB   | OD |
| NEW                  | NC   | NB   | ND |

NOTE 1:  
ENTRY 8, 9, 13 AND 14 WILL NOT PRODUCE A CURRENT BACK-UP CONTROL DISKETTE.  
THIS SHOULD ONLY HAPPEN UNDER SPECIAL CIRCUMSTANCES, SINCE 2 CONTROL DISKETTES  
SHOULD BE FURNISHED IF THE OLD CONTROL DISKETTE CANNOT BE USED FOR BACK-UP.

NOTE 2:  
THE 'M' IN THIS CHART REFERS TO ANY MANUAL  
KEYBOARD CONFIGURATION. EC OR MES OR INSTALL  
PROCEDURES WILL TELL YOU EXACTLY WHAT TO MANUALLY  
CONFIGURE. EACH SCREEN IS EXPLAINED IN DETAIL IN  
THIS STM SECTION. SEE THE TABLE OF CONTENTS FOR  
ANY PARTICULAR CONFIGURE SCREEN.

This page has been  
intentionally left blank

MES UPDATE WITHOUT A NEW DISKETTE

FOR MES UPDATES WHICH REQUIRE ONLY A HW CONFIGURATOR UPDATE TO MATCH THE SYSTEM HARDWARE CONFIGURATION, NO NEW DISKETTES ARE SHIPPED. THE 'MES UPDATE' SCREEN IS USED TO MAKE THE NECESSARY CHANGES TO THE HARDWARE CONFIGURE RECORD.

CONFIGURE PROCEDURE

- 1. INSERT CONTROL DISKETTE AND DISPLAY THE MES UPDATE SCREEN
  - A. ALT KEY AND MOD SEL TO GET THE MAINTENANCE SELECTION SCREEN.
  - B. SELECT 'UTILITIES/REMOTE'
  - C. SELECT 'MES UPDATE'

- 2. THREE SCREENS WILL APPEAR MOMENTARILY.
- 3. WAIT FOR THE MES UPDATE SCREEN TO BE DISPLAYED.
- 4. ALTER SCREEN AS DIRECTED BY THE MES INSTRUCTIONS.

- 1) ADD OR DELETE FEATURES.

IF CS TYPE 0 IS INSTALLED (2 QAS CARDS) ENTER 'Y' BELOW 32 K FIELD.  
IF CS TYPE 1 IS INSTALLED (1QS2 CARD) ENTER Y BELOW 32K AND QS2 FIELD.

- 2) INDICATE BSM CARD LOCATIONS.

CARD LOCATION ENTRIES ARE IGNORED UNLESS A MEMORY SIZE IS INDICATED WITH A 'Y' in the PUT field under 1).

THERE ARE 8 VALID COMBINATIONS OF BSM SIZE AND CARD LOCATION. THE CARD LOCATIONS PLUGGED IN YOUR BSM BOARD B1 MUST MATCH ONE OF THE COMBINATIONS SHOWN IN THE TABLE BELOW THE SCREEN PICTURE. ALL BSM CARDS ARE 512K PER CARD EXCEPT AS NOTED. SEE PLUGGING CHART IN VOL 30 FOR CARD PART NUMBERS.

NOTE: IF MEMORY SIZE OR CARD LOCATIONS ARE CHANGED FOR DIAGNOSTIC PURPOSES, THIS SCREEN MUST BE USED TO MAKE THE MICROCODE MATCH THE NEW PHYSICAL CONFIGURATION OF THE BSM.

- 5. HIT ENTER TO WRITE THE CONFIGURE DATA ON THE DISKETTE.

IF ERROR MESSAGE IS DISPLAYED, CHECK THE CHART BELOW THE SCREEN PICTURE FOR THE VALID BSM SIZE/CARD LOCATION ENTRIES.

- 6. IML THE SYSTEM. IML IS NECESSARY BECAUSE THE PU IS STOPPED TO DISPLAY THE MES UPDATE SCREEN.

THE MES UPDATE OF ONE DISKETTE IS COMPLETE

MES UPDATE:

1) PUT .=Y/N IF FEATURE INCOMING / OUTGOING

CS: 16K 32K QS2 BSM: 1M 2M 3M 4M NDSEXT: SPI: MPX: BMPX1: BMPX2:

IS: . Y . . Y . . Y Y Y Y N

PUT: . . . . . . . . . .

2) IF BSM IS AFFECTED: PUT .=Y/N IF CARD IS IN/OUT ON LOCATIONS

B1- L2 M2 N2 P2 Q2 R2 T2 U2.

IS: N N N N Y N Y Y

INVALID, SEE STM \*\*> PUT: . . . . . . . .

3) ENTER.

370 TIMER:ON

TOD:SEC

DATA:

ADDR:

STOPPED

0700

ERROR MESSAGES:

'INVALID, SEE STM \*\*>' SEE CONFIGURE SECTION ---CARD LOCATIONS DO NOT MATCH BSM SIZE - SEE CHART FOR VALID COMBINATIONS.

| BSM SIZE ENTERED IN 1) |         | VALID CARD LOCATIONS TO BE ENTERED IN 2)                     |   |   |   |   |   |   |   |
|------------------------|---------|--------------------------------------------------------------|---|---|---|---|---|---|---|
| BSM: 1M 2M 3M 4M       |         | MS CARDS PLUGGED IN BOARD B1<br>LOC: L2 M2 N2 P2 Q2 R2 T2 U2 |   |   |   |   |   |   |   |
|                        | X X X X | X                                                            | X | X | X | X | X | X | X |
| 1M                     | Y X X X | N                                                            | N | N | N | N | N | Y | Y |
| 2M                     | X Y X X | N                                                            | N | N | N | Y | Y | Y | Y |
|                        | X Y X X | N                                                            | N | N | N | N | N | Y | Y |
| 3M                     | X X Y X | N                                                            | N | Y | Y | Y | Y | Y | Y |
|                        | X X Y X | N                                                            | N | Y | Y | N | N | Y | Y |
| 4M                     | X X X Y | Y                                                            | Y | Y | Y | Y | Y | Y | Y |
|                        | X X X Y | Y                                                            | Y | Y | Y | N | N | Y | Y |
|                        | X X X Y | N                                                            | N | Y | Y | N | N | Y | Y |

NOTE 1

NOTE 1

NOTE 1

NOTE 2

NOTE 1 - REQUIRES 1 MB CARDS IN POS T2 AND U2  
NOTE 2 - REQUIRES 1 MB CARDS IN POS N2, P2, T2 AND U2.

This page has been  
intentionally left blank



DEVICE RESTRICTIONS ON THE 4331

- 1. SOME DEVICES ARE NOT SUPPORTED AT ALL ON THE 4331.
- 2. SOME DEVICES ARE NOT SUPPORTED IN COMBINATION WITH OTHER DEVICES. THESE ARE CALLED EXCLUSIVITIES.
- 3. SOME DEVICES ARE SUPPORTED, BUT WITH RESTRICTIONS.

OVERRUN PROBLEMS ARE VERY OFTEN CAUSED BY INCORRECT ADDRESS ASSIGNMENT TO A SUPPORTED DEVICE.

MORE DETAILED INFORMATION IS AVAILABLE FROM THE SALES MANUAL, SYSTEM ASSURANCE DOCUMANTATION. IF YOU THINK YOU HAVE PROBLEMS CAUSED BY INCORRECT DEVICES OR INCORRECT COMBINATIONS OF DEVICES, YOU MAY BE ABLE TO SOLVE THEM BY CHECKING THE INFORMATION IN THIS SECTION. IF YOU STILL HAVE PROBLEMS, CHECK WITH YOUR SUPPORT CENTER, SYSTEM ASSURANCE REP, OR SALESMAN.

NOT SUPPORTED

- 1. 2841/2311 ON BYTE CHANNEL
- 2. 2804

EXCLUSIVITIES

- 1. 14XX EMU WITH VMA
- 2. 3340/3370 STRING SWITCH WITH ANY DISK EMULATOR
- 3. 231X ON BMPX WITH HSC

LIMITATIONS

- 1. FTA/3370 - POSSIBLE PERFORMANCE LIMITATION.  
- SEE CHANNEL CHARACTERISTICS MANUAL.
- 2. 231X ON BMPX WITH CA GREATER THAN 9600 BAUD/SEC - PERFORMANCE LIMITATION.
- 3. HSC WITH CA GREATER 9600 BAUD/SEC - PERFORMANCE LIMITATION.

This page has been  
intentionally left blank



READER'S  
COMMENT  
FORM

This form may be used to communicate your views about this publication.  
They will be sent to the author's department for whatever review and action, if any, is deemed appropriate.  
Comments may be written in your own language; use of English is not required.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

**Note:** Copies of IBM publications are not stocked at the location to which this form is addressed. Please direct any requests for copies of publications, or for assistance in using your IBM system, to your IBM representative or to the IBM branch office serving your locality.

Possible topics for comment are:

Clarity    Accuracy    Completeness    Organization    Coding    Retrieval    Legibility

If you wish a reply, give your name and mailing address:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Please fill in

Subject: \_\_\_\_\_ Page No.: \_\_\_\_\_

Document Title: \_\_\_\_\_ P/N: \_\_\_\_\_

Number of latest Technical Update (if any) concerning this publication (EC): \_\_\_\_\_  
(REA): \_\_\_\_\_

Thank you for your cooperation. No postage stamp necessary if mailed in the U.S.A. (Elsewhere, an IBM office or representative will forward your comments.)

READER'S  
COMMENT  
FORM

This form may be used to communicate your views about this publication.  
They will be sent to the author's department for whatever review and action, if any, is deemed appropriate.  
Comments may be written in your own language; use of English is not required.

IBM may use or distribute any of the information you supply in any way it believes appropriate without incurring any obligation whatever. You may, of course, continue to use the information you supply.

**Note:** Copies of IBM publications are not stocked at the location to which this form is addressed. Please direct any requests for copies of publications, or for assistance in using your IBM system, to your IBM representative or to the IBM branch office serving your locality.

Possible topics for comment are:

Clarity    Accuracy    Completeness    Organization    Coding    Retrieval    Legibility

If you wish a reply, give your name and mailing address:

\_\_\_\_\_  
\_\_\_\_\_  
\_\_\_\_\_

Cut or Fold Along Line

Please fill in

Subject: \_\_\_\_\_ Page No.: \_\_\_\_\_

Document Title: \_\_\_\_\_ P/N: \_\_\_\_\_

Number of latest Technical Update (if any) concerning this publication (EC): \_\_\_\_\_  
(REA): \_\_\_\_\_

Thank you for your cooperation. No postage stamp necessary if mailed in the U.S.A. (Elsewhere, an IBM office or representative will forward your comments.)

Reader's Comment Form

Reader's Comment Form

Cut or Fold Along Line

Fold and tape

Please Do Not Staple

Fold and tape




NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 40 ARMONK, N.Y.

POSTAGE WILL BE PAID BY ADDRESSEE:

International Business Machines Corporation  
Department 812B  
1133 Westchester Avenue  
White Plains, New York 10604



Fold and tape

Please Do Not Staple

Fold and tape



International Business Machines Corporation  
Data Processing Division  
1133 Westchester Avenue, White Plains, N.Y. 10604

IBM World Trade Americas/Far East Corporation  
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591

IBM World Trade Europe/Middle East/Africa Corporation  
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601

Fold and tape

Please Do Not Staple

Fold and tape



NO POSTAGE  
NECESSARY  
IF MAILED  
IN THE  
UNITED STATES

**BUSINESS REPLY MAIL**

FIRST CLASS PERMIT NO. 40 ARMONK, N.Y.

POSTAGE WILL BE PAID BY ADDRESSEE:

International Business Machines Corporation  
Department 812B  
1133 Westchester Avenue  
White Plains, New York 10604



Fold and tape

Please Do Not Staple

Fold and tape



International Business Machines Corporation  
Data Processing Division  
1133 Westchester Avenue, White Plains, N.Y. 10604

IBM World Trade Americas/Far East Corporation  
Town of Mount Pleasant, Route 9, North Tarrytown, N.Y., U.S.A. 10591

IBM World Trade Europe/Middle East/Africa Corporation  
360 Hamilton Avenue, White Plains, N.Y., U.S.A. 10601